




**Performance
Drilling**
TECHNOLOGY •

HawkEye™ for Windows™



USER'S MANUAL

Copyright © 2022 by Performance Drilling Technology

All rights reserved worldwide.

INFORMATION CHANGE NOTICE

Due to application upgrades the details contained in this manual are subject to change without notice. Performance Drilling Technology does not assume any responsibility for discrepancies in this manual.

May 2022

PDT HawkEye™ User's Manual

TABLE OF CONTENTS

I. MAIN SCREEN NAVIGATION	5
1. PURPOSE OF HAWKEYE™	5
2. RECOMMENDED SYSTEM SPECS	7
a. 3D Navigation with Mouse	7
b. 3D Navigation with the Keyboard	9
c. Screen Resolution	10
d. Operating System	12
e. System and Video Memory	12
3. INSTALLING AND UPDATING HAWKEYE™	13
4. CHECK FOR UPDATES	14
5. PROJECT ORGANIZATION	15
a. Files and Databases	15
b. New Project Wizard	16
c. Data Tree	19
6. TOP TABS	25
a. File tab	26
b. Home tab	29
c. Edit tab	33
d. 3D Screen tab	63
e. Tools tab	64
f. Settings tab	69
g. Help tab	74
7. MAIN WINDOW TABS	75
a. 3D View	75
b. Vertical Section (VS) View	78
c. Top View	79
d. Proximity	80
e. Ladder Plot	85
f. Alerts	86
g. Surveys	87
II. PROJECT DATA	92
1. ADDING BASIC PROJECT DATA	92
a. Adding Projects and Structures	92
b. Adding Wells and Sidetracks	96
2. EDITING CRITICAL INFO	97
a. Targets	97
b. Target Planes	108

3. EDITING NON-CRITICAL INFO	110
a. Importing Lease/Hard Lines	110
b. Comments and Annotations	114
III. PROJECTIONS	116
1. WHAT YOU NEED TO KNOW	116
a. Work Mode vs. Proposal Mode	118
b. Appending Projections to Curve	120
2. PROJECTIONS IN FIELD MODE	121
a. Bit Projection	121
b. MD & TVD Projections	122
c. Nudge Projection	123
d. Multi-Nudge Projection	124
e. Horizontal Projection	125
f. Slant Projection	128
g. Aligned Projection	129
h. Back-on-Track (BOT) Projection	132
3. OTHER PROJECTION TOOLS	134
a. The Sight	134
b. Projection to the Crosshairs	137
c. Target at the Crosshairs	138
d. The Waypoint Target	139
e. Interpolation	141
IV. REPORTS	143
1. SURVEY REPORTS	145
2. OTHER SPECIAL REPORTS	150
a. Critical Points Reports	150
b. Least Distance Report	151
c. Interpolate Survey Report	152
d. Criticality Report	153
e. Anti-Collision Report	154
f. Magnetism Report	155
V. PLOTS	156
1. QUICK PLOTS	156
2. PRESENTATION PLOTS	160
a. How the Plot Designer Works	160
b. Vertical Section Plots	164
c. Horizontal Plots	168
d. TVD and TVD Function Plots	170
e. Add a Graphic	171
f. Add Frames: Most Commonly Used	172
g. Add Frames: Screenshots	184
h. Finishing With InkScape™	188

VI. BHA/DAILY	196
1. FILE MENU	197
2. JOB OVERVIEW	198
3. TOOL LIST	200
4. BHA MANAGER	201
5. BHA BUILDER	202
6. DAILY MANAGER	203
7. DAILY ITEMS	204
VII. WELL PLANNING	205
1. WELL PLANNING CONTROL PANEL	206
a. Simple 2D S-Well Profiler	210
b. Simple 2D Slant Profiler	215
c. Find KOP Slant	220
d. Find KOP Aligned	222
e. Default Slant	224
f. Default Aligned	226
g. Default Horizontal	229
h. Tie-Ins	231
2. BUILD A CUSTOM WELL PLANNING TEMPLATE	234
VIII. TORQUE AND DRAG	236
1. OVERVIEW	236
a. Units of measurement	237
b. The Torque & Drag Toolbar	239
2. INPUT SCREENS	240
a. General data	240
b. Drilling parameters	242
c. Hole sections	242
d. Drillstring	243
e. Survey data	244
3. EMBEDDED VERSION	246

I. MAIN SCREEN NAVIGATION

1. PURPOSE OF HAWKEYE™

The idea for HawkEye™ started in 2006 as the 3rd-generation of the successful directional drilling application WinSURV3D™. It is intended to provide directional drilling information to people involved in the workflow of directional drilling within a rich and powerful 3D environment. That workgroup includes directional drilling companies, directional drillers, engineers, geologists and operators.

A DIRECTIONAL DRILLING TOOL

When a workgroup is out drilling a well, HawkEye™ provides a set of powerful tools to meet a variety of goals related to a project. Proper use of the 3D space will allow them to clearly present how they are doing and how far away they are from other wells in a clear and intuitive way. Many folks do not have great internal mental 3D visualization, so having a 3D interface overcomes that problem and HawkEye's 3D environment actually expands greatly a person's spatial visualization of a project.

A directional drilling company will often be charged will planning the geometry of the well and HawkEye™ provides powerful tools to allow them to do that very easily.

Drilling engineers use HawkEye™ to keep up with what is going on, to keep track passively and rest assured of the drilling operation without having to spend a lot of time tracking numbers and visualize things off of list.

Geologists can incorporate their seismic and geologic graphic representation as overlays and visually see where the well is in reference to where their targets are.

Generally there is a gap between what geologists understand about certain drilling engineering restraints and what a driller understands about certain offset data. The friction between the two groups is alleviated with HawkEye™ by creating a common visual workspace in which all data is compiled and easily seen. When a geologist's data is compiled alongside the driller's information, the two groups can forge an optimal and efficient drilling operation.

A WELL PLANNING TOOL

HawkEye™ is a first class well planning tool, allowing for the well planning development of a single well or an entire platform or pad. Virtually all types of wells can be planned with HawkEye™, ranging from simple slant wells to complex 3D wells that twist and turn. The well planning version of HawkEye™ supports the direct generation of wall plots, invoking InkScape™ as the primary graphics editor for the file that HawkEye™ generates. InkScape™ is a widely supported vector graphics editor which specializes in support of the SVG (Scaled Vector Graphics) file standard.

HawkEye™ well planning is template driven. Customized planning templates can be easily created, as can customized plot templates. Once created, these templates can be used to greatly increase productivity.

Included with the Well Planning version of HawkEye™ is a Torque and Drag module. This module allows one to predict the torque and drag characteristics of a given well profile as a function of the variables affect torque and drag. It is easy to use.

THE TWO VERSIONS OF HAWKEYE™

AVAILABLE FUNCTIONS	FIELD	PLANNING
3d Rendered Graphics	✓	✓
Command Line Interface	✓	✓
Advanced 3d Projection Tools	✓	✓
Advanced Geodetics/Magnetics	✓	✓
Integrated Lease/Hard Lines	✓	✓
Lithology Display/Editing	✓	✓
Casing - Lithology Integration	✓	✓
Advanced Proximity	✓	✓
ISCWSA Error Modeling	✓	✓
Winsurv2 Daily/BHA Reporting	✓	✓
Winsurv2 Hydraulics	✓	✓
Excel Survey Reports	✓	✓
Command Line Well Planning	✓	✓
Excel 2010 Scratch Pad*	✓	✓
Large Plot Generation	A3/Ledger	✓
Torque and Drag Program	Optional	✓
Spreadsheet Well Planning		✓
Platform Manager		✓

2. RECOMMENDED SYSTEM SPECS

The most important first step in utilizing HawkEye™ is the having the proper equipment. A laptop with maximum specs that will run the program without a hint of slowdown is still only one-fifth the cost of one copy of HawkEye™ so it makes a lot of sense to get the right equipment.

a. 3D Navigation with Mouse

Certain core aspects of the HawkEye™ interface were designed for optimum 3D navigation with a certain kind of mouse. Although these devices were once “specialty” mice, they can now be acquired at a very reasonable price.

Since the predominant workspace in HawkEye™ is the 3D space, the users find themselves doing a lot of *moving along a curve* in addition to the *zooming* in the plotting modules. It turns out that the art of *zooming* has been perfected in the computer interface world. **High-speed scrolling is best done with Logitech’s Hyper-Fast Scrolling or HyperScroll™ or Ultra-fast scrolling.** This is basically a scroll wheel that is weighted and balanced so that when you flick it, it will spin continuously for some time. But since its weight is calibrated just right, you can stop the spinning with just a touch.



The program in the 3D space requires a frequent number of mouse wheel clicks up and down, and since the standard mouse wheel will actually click at each interval, it becomes an arduous task to navigate up and down a curve if the wheel does not move continuously.

At least with all of the Logitech™ HyperScroll™ models, the wheel itself can be switched between smooth motion and click motion, so the user is not forced to always use continuous motion scrolling. This may prove useful when trying to conduct a fine-tune zoom or for small iteration movement.

HARDWARE SPEC at a GLANCE

Minimum requirements:

- Windows XP Professional or above
- 2 GB RAM
- 1366 horizontal resolution
- 1.8 GHz processor
- 80 GB hard drive
- Logitech™ mouse with Hyperscroll™ wheel

Recommended specs:

- Windows 10 or 11
- 4+ GB RAM
- Any quad-core processor
- **1920x1080 resolution**
- 120+ GB hard drive
- **Logitech™ mouse with Hyperscroll™ or Ultrafast scrolling**

Logitech's HyperScroll™ mouse wheel is recommended for navigating the 3D space in HawkEye™. These models are referred to as Anywhere™, MX™ or VX™ models.

b. 3D Navigation with the Keyboard

For users who do not have access to a mouse with Hyperscroll or ultrafast scrolling, they may navigate quickly and easily with keyboard hotkeys.

The Arrow Keys and W,A,S,D keys are interchangeable in the key list below, so that the user has the option of keeping one hand on the keyboard and one on the mouse.

			
			
	OR		
			
<hr/>			
		Travel curve to surface	
		Travel curve to end	
		Move towards curve	
		Move away from curve	
<hr/>			
	+		Pan point of view down
	+		Pan point of view up
	+		Pan point of view left
	+		Pan point of view right
<hr/>			
	+		Increase curve thickness
	+		Decrease curve thickness
<hr/>			
	+		Zoom in
	+		Zoom out

c. Screen Resolution

HawkEye™ requires a certain resolution. **1920x1080 is recommended.**

Although great advances have been made in available quality and pixel counts for computer displays, companies still sell plenty of low-res screens because many ordinary computer users do not have an explicit need for a massive pixel count and it is a way to keep their costs down. HINT: Although 1366x768 is billed as “HD,” it is only barely adequate for HawkEye™.

At a minimum to run HawkEye™ without interface crowding issues, the monitor should be at least 1366 pixels across. However, the recommended horizontal count is 1920 (commonly as 1920x1080). **The program is optimized for 1920x1080, and using a display with this resolution will greatly enhance all aspects of your work productivity and overall happiness.**

Set to the Best Resolution (1920x1080)

Regardless of the physical dimensions of your monitor, it is nice to have at least a 1600 pixel horizontal to run HawkEye™, but 1920x1080 is best.

Checking your resolution in Windows 7/8:

1. Right-click on the desktop.
2. Select “Screen resolution.”
3. Use the Resolution drop-down menu to get to highest res.


Checking your resolution in Windows 10/11:

1. Right-click on the desktop.
2. Select “Display Settings.”
3. Change the value under “Display Resolution”

Set the Display to 100% Magnification

It is vitally important in Windows 7/8/10/11 to set the screen magnification to 100%. (And not 125% or 150%)

To get to that setting, search for “Display” in the Start Menu search bar. (In Windows 8, search for “Display” under “Settings.”) Open up the panel and select “100%.” If it is not already at 100%, you may need to log out and back into Windows after changing it.



d. Operating System

Operating System	Runs HawkEye™
Windows XP Pro	
Windows Vista 32-bit	
Windows Vista 64-bit	
Windows 7 32-bit	
Windows 7 64-bit	
Windows 8 32-bit	
Windows 8 64-bit	
Windows 10 32-bit	
Windows 10 64-bit	
Windows 11	

e. System and Video Memory

PROCESSOR: Recommended is a quad core processor, but dual core processors are both much more common and usually just as sufficient.

VIDEO MEMORY: On-board video memory on any modern computer with an i5 or equivalent processor and a 1920x1080 screen will be sufficient.

RAM: At least 2GB of RAM is required. Modern computers come with 4 GB at a minimum, and 8 or 16 GB would ensure no slowdown or issues with the program.

3. INSTALLING AND UPDATING HAWKEYE™

Installation of HawkEye™ is a mostly automated process. The program is installed via an internet connection.

Using default installation folders is immensely helpful when troubleshooting and keeping track of files upon reinstallation and using HawkEye™ on multiple machines.

INSTALLATION VIA INTERNET

1. Turn off the UAC (Search “UAC” from the Windows Start Menu, set to 0, then reboot).
2. Make Sure the HASP key is plugged into a USB port.
3. Connect computer to the Internet. NOTE: Don’t disconnect throughout this installation process. If the connection is severed at any point, you will need to and start over.
4. Navigate in any browser to the site:
http://hawkeyert.azurewebsites.net/hawkeye_pdt/hawkeye.msi
This will download an MSI file named “hawkeye.msi.” This is the “installer” of the program.
5. A version of the .NET Framework must be installed on the machine and will do so in the course of the installation process.
6. Several other small applications will install. They may take a few minutes to install, but they are recommended, and in the case of presentation plots and Inkscape, necessary. Click through and accept the default settings where applicable:
 - c. Ssrc SVG - This provides support for the Graphics Designer.
 - d. INKSCAPE – This is a free Vector graphics program.
 - e. CUTEPDF Writer – This is a free PDF printer. It is installed so that the user has access to all page sizes when designing plots.

4. CHECK FOR UPDATES



Click on the “Help” tab on the top right of the main screen to access the following:

- **The Update button to check for updates**
- Open a hotkey map (keyboard shortcuts for the program)
- A link to the Quickstart Guide (16 pages)
- A link to the User’s Guide (this document)

5. Project Organization

a. Files and Databases

All data for each Field/Project is saved to a single database file with the extension “.HawkEye.mdf”. The data is organized and presented in a tree structure hierarchy, a concept much like several other well planning software applications, including Landmark’s Compass.

Briefly, file organization is as follows:

DATABASE FILE (.HawkEye extension) contains:

Collection of FIELDS and or COMPANIES...

Which contain a collection of PROJECTS...

Which contain a collection of STRUCTURES...

Which contain a collection of SLOTS...

Which contain a collection of WELLPATHS that are either proposed plans or actual surveys.

TARGETS are assigned to either a STRUCTURE or a SLOT.

LEASE LINES and HARD LINES are associated with the STRUCTURE.


LITHOLOGY is assigned to the STRUCTURE, but also to the each WELLPATH.

CASING is assigned to each WELLPATH.

JOB INFORMATION is assigned to each WELLPATH.

b. New Project Wizard

In the top left corner of the Main Screen, the first icon is the Wizard. Clicking on the icon brings up the Project Quick Start, a project Wizard that enables the user to create project with a minimum of information in a short amount of time, all in just a few steps.



The screenshot shows the 'Project Quick Start' dialog box with the following fields and options:

- STEP 1** Field Name: HawkEye_12_19_2021 (selected in a drop-down menu)
- STEP 2** Project Name: (empty text box)
- Safety Ruleset: Default (selected in a drop-down menu)
- Unit System**
 - Linear Unit: US FEET (selected in a drop-down menu)
 - DLS = %: 100 (selected in a drop-down menu)
 - Ft: (text box)
 - Geodetic Unit: US FEET (selected in a drop-down menu)
 - Casing Unit: API (selected in a drop-down menu)
- North Reference**
 - Grid North
 - True North
- Vertical Datum**
 - Elevation (ft): 0.00 (text box)
 - RKB (ft): 0.00 (text box)
- STEP 3** Job Information (button)
- STEP 4** Geodetics Information (button)
- OK (button)
- Cancel (button)

STEP 1 Enter the Field Name. If it already exists, it will be in the drop-down menu in STEP 1.

STEP 2 Enter the Project Name. Also choose the type of North Reference as well as the units to be used (feet or meters). Choosing the Safety Ruleset for most users will not be necessary (the rulesets are company-specific separation factors for ellipses of uncertainty). Here the user should also enter the project's elevation and RKB for the structure if known. If this information is not yet known, it can be later entered by right-clicking on the slot or structure in the Data Tree and selecting "Edit" in those menus.

STEP 3 Open the Job Information dialogue and enter information. The information in this dialogue will pull from any job information that has already been entered in the [Daily/BHA](#) portion of the program. Otherwise, the user will create a new Company and Job ID in this step.

The screenshot shows a 'Job Information' dialog box with the following fields and controls:

- Company:** A dropdown menu.
- Job ID:** A dropdown menu with the text 'Select or Enter New Job Name'.
- Available BHAs:** A dropdown menu with the value '0'.
- Curve Name:** A text field containing 'All curves in new project'.
- Lease / Well:** A text field.
- Location:** A text field.
- API JOB #:** A text field.
- Rig Name:** A text field.
- State/Province:** A text field.
- County/Parish:** A text field.
- Country:** A text field.
- Comment:** A text area.
- Buttons:** 'OK' and 'Cancel' buttons are located on the right side of the dialog.

STEP 4 Click on the “Geodetics Information” button and open up the Geodetics dialogue. Choose the Group to be used.¹ If the computer is connected to the Internet, then Google Maps will automatically come up with the current location. If you are working in international territory, it is likely that a UTM will be used, either southern or northern hemisphere. All of these are available in the first pulldown menu at the top of the dialogue. Then click “Save and Exit.”

¹ If you do not have the geodetics information yet, that is okay. Just select “None” from the Group pull-down list. This will simplify the Slot Geodetics dialogue and allow you to work with local coordinates until the geodetics can be entered at a later time.


After completing the final step of the Wizard, click “Ok.” Now you will have a fresh project waiting in the Data Tree. The Wizard provides the following by default:

-  Structure
-  Slot
-  As Drilled Curve
-  Proposal Curve
-  (First) Target

You can delete or edit these initial objects by right-clicking on any of them and choosing an action from the contextual menu.

c. Data Tree

The Data Tree is the basis for navigating through all the immense information that a job contains in HawkEye™. It is intuitively organized to allow the user the easiest method of random access to project information. It is by default on display on the left-hand window of the main screen.



HEIRARCHY: The data hierarchy here should be familiar to WinSURV3D users with some minor changes. From the top down, data in HawkEye™ is organized into:

Data is organized first by FIELD/PROJECT. This is the root of the tree, and could also be conceptualized as the COMPANY (Operator).

Although HawkEye™ could have multiple FIELD/PROJECTIONS open at a time, it will only have one of these FIELD/PROJECT trees *expanded* and displayed at a time.

The next level is PROJECT, of which also only one can be open at a time. Underneath each of the projects are the one or more STRUCTURES.

Under structures are the various SLOTS. From there, PROPOSED WELLPATHS, WORKCURVES and TARGETS are all thrown in at the same hierarchical level, grouped by their slot.


DATA TREE ICONS	
	FIELD/PROJECT
	Project
	Structure
	Slot
	Proposal Wellpath
	Survey (Workcurve) Wellpath
	First Target
	Second Target
	Target

A PROJECT (P) may be composed of any combination of STRUCTURES (S) found in a given FIELD/PROJECT or COMPANY (C). Although the identical tree may appear under each Project, the data for a particular Structure is only written to the database once, and any modifications to it will be in effect throughout all projects in which that Structure appears. However, if you choose to edit a Project by deleting a particular Structure, only that single Project would be affected: the Structure data remains in the database, in the Field and any other Projects it is a part of.

A Project is created and exists within an individual Field. The simplest way to understand the hierarchy is to visualize the case of an offshore drilling program. The Field may be a particular reservoir; there may be multiple platforms (Structures) drilling in that same field; each platform, or STRUCTURE, has the capacity to drill from a number of SLOTS (A) in the template; and finally, there can be any number of Wellpaths (W, P) associated with each Slot.

USING THE SAME STRUCTURE: One Project may be a single Structure; for another you may want to include the next closest structure for anti-collision purposes; a third may include several other structures, and so on. In other words, the *same* structure, or any combination of structures (within a single Field) can be part of any number of different Projects.

COLLAPSING AND EXPANDING: Any level of the tree may be expanded by clicking on the “plus sign” (“+”) to the left of that item. (Conversely, clicking on a “minus sign” (“-”) collapses the tree back up to that level). To whatever degree the complete tree has been expanded, you can collapse it again by clicking on the named level (or the minus sign): everything below that level will collapse from view. If there is no plus sign next to the object, that means there isn’t any data below that level associated with that object.



The highest level of data is the **FIELDS/PROJECT**, under which all other dataforms are organized. Any given **FIELD/PROJECT** can contain an **unlimited number of projects, structures, slots, curves, etc.**

ASSIGNING TARGETS TO SLOTS: Targets can be assigned to specific Slots in a Structure. If they are assigned, you will find them under the slot in which they are associated. If a target is not assigned to a Slot, it will be placed at the bottom of the Data Tree under the last displayed datum in the Structure:

An unassigned Target will be at the bottom of a Structure branch (left). To assign it, just right-click, select “Adjust Target Parameters” and select the assignee slot from the “Slot” pulldown menu (right).

The EDIT PROJECT button will pull up the small Project Information dialogue. The TARGET LIST button brings up the comprehensive Target List manager, which includes the Target Adjuster dialogue and the tools to add, delete and edit all the targets of the project. The CURVE MANAGER button invokes the small Curve List box that allows for turning on and off curve.

TO ADD A CURVE, just click on a blank numbered box, then go down to the Curve Data window and then:


1. Type in a name for that curve
2. Select the type, either proposal or survey
3. Select the slot to be associated

4. Enter location, tie in and direction values
5. Click “ADD.”

The new curve will appear in the first open available square. Any further tweaking of the curve can be done by Right-Clicking on the curve’s numbered box and selecting “Edit Curve” from the curve contextual menu.

SET AS WORK CURVE/SET AS PROPOSAL CURVE: To set a curve as the work curve, or a Proposal curve as the current plan, simply right-click on the numbered box and select the first item on the menu, “Set as Work Curve.” If you make any curve that is not number 0 the work curve, the curve will automatically be the Number 0 curve, otherwise retaining all of its parameters including color.

The former Number 0 curve will be swapped out with the new one such that all other curves keep their number.




Right-clicking on a curve’s box in the Project Control Panel is the same as right-clicking on one in the 3D space, bringing up the comprehensive contextual menu for either the proposal or work curve.


1. Slot/Wellhead

The Slot is the most-used data level of a given project. All curves and targets are associated under a given slot at any given time. The slot in HawkEye is represented with a “rig” icon.

A “Structure” will contain as many slots as are needed, and only lithology information, target planes and hard/lease lines are associated to a structure.




RIGHT CLICK ON THE SLOT: To change slot information, right-click on the rig icon in the Data Tree and select “Edit Slot Data.” Notice that the right-click menu for slots has virtually everything you will need which is slot-related. Only from this right-click menu can you do the following:



- Edit Slot Data (also from large icon, see below)
- Add New Well Path
- Set slot as the reference slot
- Delete the slot

EDIT SLOT INFORMATION: When “Edit Slot Data” is selected, it will open the Slot Information dialogue.

You may also get to the *current* slot’s information by clicking on the large rig icon at the top of the screen. The Slot Information dialogue has all of the location information associated with that slot.




SITE/SLOT NAME: This is the only place where the name of the slot can be changed besides initially in the Project Wizard or the Structure Manager (Well Planning only).

INPUT COORDINATES: All of the parameters inside of the green background are used to define the slot's location, either by local coordinates, Northing and Easting coordinates, or Lat-Long coordinates.

CONVERGENCE: This value is derived from the location data of the slot, and indicates the number of degrees difference between grid north and true north. This number is also displayed in the Geodetics dialogue when defining surface location.

LAUNCH GEOHAWK:


When the "Launch GeoHAWK" button is clicked, it launches a special version of the Geodetics dialogue. In this special version, the user cannot change any surface location data (highlighted on the right). Only the specific location data for the slot can be altered.




The point of GeoHAWK is to utilize the power of the Geodetics dialogue, which uses Google Maps and Google Earth (if installed), for slots. In this fashion, slot location can be defined, visualized and mapped out with great precision.

6. Top Tabs

HawkEye’s main screen is organized by default into three distinct information areas. On the left is the Data Tree. On the right is the 3D space by default. And at the bottom is the Survey List Panel.



To switch to a two-panel mode, click the “Settings” tab and then uncheck the option on the far left that reads “3-Panel Interface.” This will turn off the Survey List Panel at the bottom of the screen.



RESIZING WINDOWS: The proportion of the screen that each window takes can be resized manually. Resize by “grabbing” a border, left-clicking and dragging the border to resize. Just move them around and you will quickly get the feel for them.

a. File tab

At the top left of the main screen in HawkEye™ is the File tab. This menu allows the quick launch of a few core dialogues and modules in the program.

Database vs. Project

HawkEye™ has a flexible method of maintaining projects in database files. It is important to understand the distinction between a “project” and an entire “database file.”

- A *database file* contains a collection of projects.
- Whereas a *project* is a collection of wells/structures that are related to one another on an operational basis.




NEW DATABASE PROJECT: Select

this option to start a new project. The first thing HawkEye™ will ask is for the project file to be named and located. Choose a file location and name the project- it will have a “.HawkEye.mdf” double extension. A database consists of a single .hawkeye.mdb file. There are several important rules of thumb with a HawkEye database file and its name:

- Do not rename anything in the “.hawkeye.mdb” letters themselves
- Do not include special characters in the filename (e.g. drillproject.westtexas.hawkeye.mdf is bad because of that first period)
- Do not include special characters anywhere in the entire filepath

A database file can consist of many hundreds of projects. It is not recommended that hundreds of projects are stored in a database file, however; the reason being that opening and maintaining a large database file consumes more machine time and also putting all your eggs in one basket could lead to some extreme frustration should the “.HawkEye.mdf” file be corrupted by destructive forces such as a power surge, a virus, or just bad luck.



NOTE: The best strategy is to have an assigned folder (i.e. “c:/HawkEye/Data” or your Desktop) in which all of your HawkEye™ database files are stored. Make routine backups of this directory.

A good plan is to keep a group of related projects for a given customer within a single database; if your customer wants to have direct access to your data it is an easy matter to simply send them the file without being concerned over whether or not some other company’s information is divulged.



Open Database:

1. **HawkEye Database:** This will invoke the open project dialogue but will only open files with the “.HawkEye.mdf” extension.
2. **WinSERVE File:** This launches a special dialogue in which the user may either create a new HawkEye™ file, or import WinServe™ files to an existing HawkEye™ project file.
3. **Compass Transfer File:** Opens an .edm.xml file created by Compass, and asks you to specify factors such as North reference



Save As New Database: Any currently displayed and existing project data can be saved over into a new, separate HawkEye™ file. **This is useful for backing up and preserving projects** as they are before venturing into project deviations. When a project is saved as a new file, the project will still be open under the old name. Thus future changes will be saved to the old project while the new one remains untouched.



Merge HawkEye databases: This tool allows for the merging of separate “.HawkEye.mdf” databases. This can be useful in circumstances under which different users are working together on a general group of projects. To use this tool simply use the explorer to point the “.HawkEye.mdf” file you want to merge with the current database already opened within HawkEye™.



Save As / Export Project: Export Project to WinSERVE: This will allow the user to save certain project data to a WinServe™ (.svy) file. Not all project data is saved to a .svy file from a HawkEye™ project. Before the .svy file can be saved, it must

already exist, HawkEye™ does not create the file, it just writes to it. This is because a WinServe™ .svy file has all kinds of data in it that HawkEye™ can't possibly know, like how the plots in WinServe™ should look. All HawkEye™ does is fill in the curve and target data. **NOTE:** If the HawkEye™ project has more than 20 curves, then only the first 20 will be exported to the WinServe™ file. That is because WinServe™ .svy files have a 20 curve limit.



Recent Projects: This list displays all recently opened project files.



Recent Files: This list displays all recently opened HawkEye databases.



EXIT: This will close HawkEye™. The program will always automatically save current data to the currently open HawkEye™ project file. In order to preserve a project prior to changes made before closing out, make sure to save the project as a new HawkEye™ project.

b. Home tab

NOTE: Projections are covered in [Chapter III: Projections](#).

Save Surveys



This will force the program to save all added surveys and changes to any surveys to the current HawkEye database. The program does this by default every five minutes, but you can push the save as often as you want here.

Report



This launches the Report Generator, which is covered in [Chapter IV: Reports](#).

Quick Plot



This launches the Quick Plot module, which is covered in [Chapter V: Plots 1. Quick Plots](#).

Add Survey



This opens the Survey Editor. This is the best way to add surveys in the program individually. In this dialogue all of the surveys for the currently selected well will appear, and several of their parameters may be edited.

The BEST WAY to add a survey is, once inside the Survey Editor, type the Measured Depth, **press ENTER**, then type in the Inclination, **press ENTER**, and then type in the Azimuth and **press ENTER**. After the third "ENTER," your new survey will have been created and added to the Survey List Panel. [See the section on Surveys](#) on how to import and handle surveys.

Survey Editor

Press <ENTER> to advance from MD to INC to AZM. Pressing <ENTER> once again will loop to MD.

Curve Name: Wellbore #1 - Wellbore #1 OK

Measured Depth: 2256.00 Inclination: .40 Azimuth: 323.50 Auto. Increase MD 100 Ft.

MD	Inc	AZM	Type	BHA #	Comment
1391.00	0.30	175.30	COMPASS, Imported	0	
1476.00	0.40	218.40	COMPASS, Imported	0	
1561.00	0.30	195.00	COMPASS, Imported	0	
1645.00	0.40	276.10	COMPASS, Imported	0	
1731.00	0.40	210.40	COMPASS, Imported	0	
1816.00	0.50	240.40	COMPASS, Imported	0	
1901.00	0.50	298.20	COMPASS, Imported	0	
1986.00	0.40	326.00	COMPASS, Imported	0	
2070.00	0.40	325.10	COMPASS, Imported	0	
2156.00	0.40	323.50	COMPASS, Imported	0	

Job Info



Job data is used in the program in several ways, as listed below:

- Job data is how HawkEye™ and its Daily/BHA module communicate
- Job data is displayed in report headers
- Job data is displayed in well plot headers

Company: This should be entered first. If a company name has been entered before, then it will appear in the drop-down menu here.

Job ID: This is the core identifier of the Job as it relates to the Daily/BHA portion of the program.

Available BHAs: This is not editable here, but rather a read-only indicator of how many BHAs have been created under the selected Job ID above.

A screenshot of a 'Job Information' dialog box. It contains several input fields: 'Company' (a dropdown menu), 'Job ID' (a dropdown menu with the text 'Select or Enter New Job Name'), 'Available BHAs' (a dropdown menu showing '0'), 'Curve Name' (a text field with 'Wellbore #1 - Wellbore #1' highlighted in yellow), 'Lease / Well', 'Location', 'API JOB #', 'Rig Name', 'State/Province', 'County/Parish', 'Country', and 'Comment' (a text area). There are 'OK' and 'Cancel' buttons on the right side.

Curve Name: This is not editable here, but rather an indicator of which curve is currently selected for the job being edited here. **Any given “Job” in HawkEye is associated with only one curve.**

All other fields: The remaining fields do not have a data impact in the program, but are rather displayed in report headers.

Target List



See the dedicated section for a [full description of the Target List](#).

For more on Targets generally, [see Chapter II Project Data: Targets](#).

Add Target



Click this to add a target to the current Look-At Point on the current active curve displayed in the 3D space. The default shape is a 100-foot wide, 5-foot thick green cylinder. The Target Adjuster opens for this target so you can adjust these parameters as desired.



Hydraulics

This opens the Hydraulics module. Several points of data need to be in place before launching this, and the program will prompt you if you haven't done so yet:

1. Job ID needs to be assigned to the current curve.
2. A BHA needs to be assigned to the surveys of the current curve.

Assigning a BHA to a curve: This is done in the Survey List Panel, in the BHA ID column, which is by default the second from the left. Any BHA that you select for a survey becomes the selection for all surveys below that survey. (Press Tab after making a selection)

Survey data for well : Wellbore #1 - Wellbore #1											
No	BHA ID	MD (Ft)	Inc Deg	Azm Deg	CL (Ft)	NS (Ft)	EW (Ft)	TVD (Ft)	VS (Ft)	SurvType	DLS */100 Ft
1	0	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	COMPASS, Imported	0.00
2	0	20.00	0.00	0.00	20.00	0.00	0.00	20.00	0.00	COMPASS, Imported	0.00
3	0	141.00	0.70	211.90	121.00	-0.63	-0.39	141.00	-0.63	COMPASS, Imported	0.58
4	0	197.00	0.70	224.80	56.00	-1.16	-0.81	196.99	-1.16	COMPASS, Imported	0.28
5	0	283.00	0.10	107.80	86.00	-1.56	-1.11	282.99	-1.56	COMPASS, Imported	0.87
6	1	369.00	0.30	300.70	86.00	-1.46	-1.23	368.99	-1.46	COMPASS, Imported	0.46
7	1	454.00	0.40	317.80	85.00	-1.13	-1.62	453.99	-1.13	COMPASS, Imported	0.17
8	1	540.00	0.60	327.20	86.00	-0.53	-2.07	539.99	-0.53	COMPASS, Imported	0.25
9	1	625.00	0.20	1.50	85.00	-0.01	-2.31	624.98	-0.01	COMPASS, Imported	0.53
10	1	710.00	0.40	1.20	85.00	0.44	-2.30	709.98	0.44	COMPASS, Imported	0.24
11	1	796.00	0.40	30.80	86.00	1.00	-2.14	795.98	1.00	COMPASS, Imported	0.24
12	1	881.00	0.40	307.10	85.00	1.43	-2.22	880.98	1.43	COMPASS, Imported	0.63
13	1	966.00	0.30	33.50	85.00	1.79	-2.34	965.98	1.79	COMPASS, Imported	0.57
14	1	1050.00	0.30	60.10	84.00	2.09	-2.02	1049.98	2.09	COMPASS, Imported	0.16
15	1	1136.00	0.80	171.40	86.00	1.61	-1.74	1135.97	1.61	COMPASS, Imported	1.11

3. Casing needs to be entered for the current curve.


Entering Casing: Click on the Edit tab in the main screen, then click on the “Casing” icon to enter casing data for the current curve. [Click here for more on Casing.](#)



BHA Daily

This launches the Daily/BHA module of the program, covered in [Chapter VI: Daily/BHA](#). This module is where the user can: Create BHAs and BHA reports, enter Daily Activity and create Daily Reports, and keep track of inventory on a job, generate shipping tickets, and generate end of well reports.

c. Edit tab




The Edit tab contains all of the most used secondary functions in the program.

Add Lease Line / Hard Line



Click on either of these first two icons to create a Lease Line or Hard Line.



The Lease/Hard Line Editor will then open, where you can define a Line by one of five methods, called “Input Modes” on the top left. First select one of these modes.

Then enter the coordinates of each point for your line at the bottom. Depending on which Input Mode you’ve selected, the BLACK CELLS in the bottom will change. Those BLACK CELLS are the only ones that you can edit. The rest are automatically calculated based on what you have entered.



The dark grey window on the right, titled “TARGET ADJUSTER,” allows you to edit the appearance of the Line in the 3D space, but not its mathematical location, which will remain 2D point-to-point lines.

Remember to check the boxes in the 3D View in the bottom middle of the dialogue to turn on the line in the 3D space.

For more details on how to import Lease and Hard Lines, see the section under [Editing Non-Critical Info: Importing Lease/Hard Lines.](#)

Add Target Plane



A target plane is defined by its TVD, Side A and Side B, as well as its Dip Direction and Dip Inclination. Target Planes in HawkEye are used to denote flat planes for a variety of reasons and can be set as the active target when using the Horizontal Projection.

[Click here for more on Target Planes.](#)

Add Side Track



This will create a new curve that stems from the existing active curve in the 3D space. You can see which curve is the parent curve at the top of this dialogue.

The curve can be either Proposal, Work, or both, and the most important information is its tie-in point to the parent curve, defined at the bottom of the dialogue.

You can also choose four different types of projects to base the new sidetrack on by first selecting the projection type in the dropdown menu, then adjusting the parameters on the right.

Paste to End



If you have surveys copied, you can click this to append those surveys to the end of the current, active curve.

Paste as New



If you have surveys copied, you can click this to create a new curve out of those surveys.

Copy Curve



This will copy whichever curve you have selected, to be pasted elsewhere.


Casing



Adding casing in HawkEye™ is a process similar to adding lithology.

It is done layer by layer and each entry can be customized. To get to the Casing Editor, click on the casing icon at the top of the main screen.


The Casing Editor will allow the appending of casing information to the selected curve. The first step is to click the “Add Casing” button. This will add a casing entry to the selected curve, wherein all the vital information can be entered in any order.



The size is defined from a lookup menu of different casing sizes. The selected size will determine the choices for the weight of each casing. The sizes available are as follows:

List of Casing Sizes					
10 ¾	11 ¾	11 7/8	13 ½	13 3/8	14
16	18 5/8	20	24 ½	4 ½	5
5 ½	6	6 5/8	7	7 ¾	7 5/8
8 5/8	9 ¾	9 5/8	Riser		

SET DEPTH ERROR: The Casing Editor will give a “Set Depth Error” if the user tries to add casing with a set depth greater than the maximum MD.




Aside from casing size and weight, which are selected from drop-down menus, other parameters are defined manually.

ID/OD: Internal and Outer Diameter in inches.

TOP MD: This number defines the beginning of the casing from the top down along the wellpath.

SET MD: This is measured depth or TVD to which the casing is run.

COMMENT and COLOR: Click on the Comment field to add any relevant notation to be associated with the casing. The color field opens to a palette when clicked on.




DEFINE CASING BY THE LITHOLOGY: Casing can be defined in the Lithology editor². To do this, right-click on a proposal curve and select “Lithology.” A lithology dialogue will open, but it will be specifically associated with the current proposal curve. You will see the name of the proposal curve in the title bar of the Lithology editor.

Description	Top	Bottom	Lithology	Dip	Dip Dir.	CSG. Size, Weight	CSG. Offset
logy rption	0.00	1000.00	++ + ALKALINE	2.00	0.00	7 5/8, 77.9	0.00
logy rption	1000.00	2000.00	+ F + MARL	2.00	0.00	7 5/8, 20	0.00
logy rption	2000.00	3000.00	SANDSTON	-2.00	0.00	7.38	0.00
logy rption	3000.00	4000.00	X X X ANDESITE	4.00	0.00	7.23	0.00
logy rption	4000.00	5000.00	X P X WELD_TUF	-5.00	0.00	7.20	0.00
logy rption	5000.00	6000.00	BASICIGN	2.00	0.00	6.26	0.00

Once inside the Lithology editor, you will notice two additional columns on the right side of the normal spread of parameters. These columns are where you can add casing that starts and ends with respect to wherever the lithology boundaries are.

The two columns are the Casing Size/Weight, wherein the casing can be defined, and the Casing Offset, where the casing tops can be defined as not having to start exactly at the layer borders.




When casing is defined here in the Lithology Editor, the casing will appear in the normal Casing Editor.

² For proposal curves only, since a work curve will not usually have casing defined by lithology boundaries, despite the best plans of mice and men.

COPYING TO STRUCTURE: When you add casing in the lithology editor, and then click “Copy Lithology to Structure,” it will also copy the added casing. To prevent this, you must delete all casing entries by selecting “none” for the Size/Weight and “0” for Offset before copying to the structure.


DOES NOT WORK ON SIDETRACKS: Adding casing through the Lithology Editor will not work on sidetrack proposals since they do not start at 0 TVD.

Lithology



Lithology in HawkEye™ is a tool that allows

the user to enter known geological data as it relates to the range of the well. The lithology data, graphically represented by colored patterns, appears in the 3D space as well as in the plots and reports if desired. The lithology datasets can either be metaphorical graphical representations or geological snapshots and cross-sections of actual field seismographs (“picture” lithology) if such data is available.




OPENING THE LITHOLOGY EDITOR:

1) Click on the Lithology icon in the Edit tab. . 2) RIGHT-CLICK anywhere in the background of the 3D space or on a curve and select “Lithology.”

TURNING LITHOLOGY ON AND OFF:


1) RIGHT-CLICK anywhere in the background of the 3D space and select “Show Lithology” or “Hide Lithology,” depending on if it’s already on or off.

2) Check the box next to the Lithology icon in the Edit tab labeled “Show Lith.”




THE MANY FACES OF MOTHER EARTH

The function of the Wellpath Lithology editor hinges on lithology layers chosen by drop-down menus. Each new layer will have a material type to be assigned to it. HawkEye™ provides a number of materials to choose from:



NOTE: Any of these patterns can be replaced with custom pattern files by clicking on "Edit Patterns" in the top left of the Wellpath Lithology panel.

LITHOLOGY CONTROLS: At the top of the Wellpath Lithology panel there are a number of functions:



ADD LAYER and CLEAR LAYER: This may be the first place to go when using lithology, where each layer can be added manually or cleared entirely. Each new layer is by default Euclidian and given a depth of 200 ft/m.

EDIT PATTERNS: All of the lithology materials from the layer's drop-down menu have particular pattern associated with them. But they are easily changed out with user-provided pattern files in the Edit Pattern dialogue. The pattern family is HawkEye™ by default but can be switched to the Compass family or customized by group or individually here.

COPY LITHOLOGY TO STRUCTURE: Any given set of lithology data is associated with the select curve, so it must be actively attached or associated with a structure. This button will take the curve's lithology data as currently displayed and copy it to the structure under which the curve is associated.

GET LITHOLOGY FROM STRUCTURE: This button will retrieve the lithology information from the structure and apply it to the current curve. NOTE: There must be a lithology data set copied to the structure first.

(E.g. If a lithology is set up with a proposal curve, it is not automatically going to display when the as-drilled work curve is being followed. To share the lithology between the two, "copy lithology to structure" when it's being displayed along with the proposal curve, then follow the work curve and click the "Get Lithology From Structure" button.)


DEPTH TYPE: It is important to know the method in which the depth for each lithology layer is defined. Subsea depths start from sea level and go down. TVD depth type includes the RKB and the elevation.

DYNAMICALLY POSITION and LITHOLOGY DIRECTION: Either one or the other of these can be selected at a time. These affect the direction the lithology plane is

pointed. With Dynamic positioning turned on the direction is affected by the direction at the current focus point. If the formation has a dip, and there is a significant change in direction such as in a turn zone then the lithology plane will be recalculated after the scroll wheel as stopped moving. If Dynamic Positioning is turned off then the lithology points in the direction specified by the Lithology Direction input.

TRANSLUCENCY: Control the translucency of the currently displayed lithology set. The range is from 0 to 100.

SPLIT LITHOLOGY: This will create two copies of the lithology layer in the 3D space and they will “sandwich” the current look-at point. Use the slide control to move how far away the duplicate layers are from the point of interest. This feature is useful for creating a valley effect in which the well can be referenced against the lithology data from more angles.



SHOW EUCLIDIAN LITHOLOGY (DEFAULT): This allows the lithology to be defined by the basic input list be displayed. Sometimes when using a ‘real’ lithology it is not desirable to show both the Euclidian and real lithologies.


SHOW DESCRIPTIONS: Descriptions are entered in the layer editing segment under the Euclidian Lithology tab. When “Show Descriptions” is selected, a small text box will appear in the 3D space inside of the lithology’s plane on the bottom left corner.



BUILD LITHOLOGY UPWARD: The lithology picture is built by default from the top down. If all dips are the same for all the lithologies then the algorithm for the order in which layers are drawn is irrelevant. However, if the dips are non-zero and some are

greater than others then the order can be potentially important. This is not a really important feature, but it could possibly turn useful.

HORIZONTAL DISPLACEMENT: This slider controls the horizontal span of the entire lithology display in 3D space. It will crunch or stretch the patterns along the horizontal plane. The range is from roughly 1,000 to 25,000 feet.



EUCLIDIAN LITHOLOGY (DEFAULT): Once the Wellpath Lithology panel is open, simply click “Add Layer” on the top left to begin adding lithology data to the project. Each layer will be blank and have a number of drop-down menu or text field to define the layer. Click on each box to edit it.

Euclidian Lithology Picture Lithology

Lithology For Curve: Slot 3 - Survey								
Type	Name	Description	Top Depth	Bottom Depth	Lithology	Dip Angle	Dip Direction	
Euclidian	Name	Lithology Description	0.00	10.00		SA LT	0.00	0.00
Euclidian	Name	Lithology Description	10.00	20.00		AN H...	0.00	0.00
Euclidian	Name	Lithology Description	20.00	30.00		W E...	0.00	0.00
Euclidian	Name	Lithology Description	30.00	40.00		AR K...	0.00	0.00
Euclidian	Name	Lithology Description	40.00	50.00		C O...	0.00	0.00
Euclidian	Name	Lithology Description	50.00	60.00		AR G...	0.00	0.00
Euclidian	Name	Lithology Description	60.00	70.00			0.00	0.00

TYPE: Euclidian or Real. Euclidean is the default type that is displayed, and it is characterized by its straight horizontal borders dividing each layer. “Real” lithology is characterized by its irregular border between layers, the undulating thickness which is a more realistic representation of the geology.

NAME and **DESCRIPTION**: The Name, as of now, is not really used in reports or output, but the Description is used. It is used in the presentation plots and also as a description for interpolated comments

TOP DEPTH and **BOTTOM DEPTH**: Directly enter the depth of the layer. HawkEye™ will not have the layers overlap and will give notice if there is a depth conflict. Each new layer is given a default depth of 200 (ft/m) from the last layer.

LITHOLOGY: Choose from the drop-down menu what type of material the layer represents. The list is comprehensive and should encompass most types encountered in the field.

DIP-ANGLE and **DIP DIRECTION**: Number fields here define the dip of the particular lithology plane.


PICTURE LITHOLOGY: The Picture Lithology tab will allow the user to utilize any available seismographic imagery for use in place of the colored lithology patterns provided. **NOTE**: These slices of 3D seismographic data are not always available from the company in charge of geological survey and assessment.

Click “Browse” to select the bitmap. Be sure to check the “Show Picture Lithology” box to display the custom picture, and define the picture loaded by TVD, Direction, Width and Height in the provided fields. Define the lithology here by one of three modes, selected with each of the respective radio buttons: Lat-Long, Local EWNS, or by Geodetic Grid.

DEFINE CASING BY THE LITHOLOGY: See more in the next section on casing on how to place casing automatically for where a proposal curve crosses a lithology boundary.


HOW TO SET A DEFAULT LITHOLOGY

If you make a target plane (e.g. right-click on any curve and select “Create Target Plane”) for any given reason and you don’t have the lithology set for that TVD, the program will give you this for a texture:




Since this is not a convincing or appealing texture, you may want to set a default other than “Not Available.” Here’s how:

- 1) Open up the Lithology module.
- 2) Click on “Edit Textures” at the top left.
- 3) Scroll down to the texture titled “Default.”



- 4) Double-click on the “N/A” texture.
- 5) Choose your new default texture.




Curve List



Pulls up a list of all curves in either the current project or the current structure/pad, for the purposes of turning on and off their visibility and their labels.

They can also be renamed here by double-clicking on the name itself.



Current Structure




This brings up the Platform/Pad editor for the platform/pad of the current active curve. You can also access this editor by right-clicking on the platform/pad in the Data tree and selecting “Edit Platform/Pad.”

Current Slot



This brings up the Slot/Wellhead editor for the current active slot/wellhead. You can also access this editor by right-clicking on any slot/wellhead in the Data Tree and selecting “Edit Slot/Wellhead.”




Magnetics



MAGNETICS MODELS: Once inside, the first step is to select a magnetic model file. HawkEye™ uses the IGRF (International Geomagnetic Reference Field) and WMM (World Magnetic Model) magnetic models. (Future models will include those developed by National Oceanic and Atmospheric Administration and the British Geological Survey). The BMMG model is available for those users who have a paid license for it, but is currently not available standard with HawkEye™. It is important to have the right model selected. The IGRF2020 model is good until 2025.

SURFACE LOCATION: Magnetics is automatically calculated when a surface location is entered in a project, but that location (Lat-Longs) can be manually changed in the Magnetics panel in the fields highlighted in light green at the top.

PRINTING: Just click the “PRINT” button and a handy one-page Magnetics/Geodetic Report is generated, containing not only all pertinent magnetics information, but several methods of correction based on which north the user needs to correct from.



Geodetics



Accurate mathematical positioning of a well site and the associated targets, lease lines, hard lines and offset wells is extremely important in any drilling operation. With directional drilling the need for accurate positioning is enhanced not only by concerns for the drilling operation with regard to no-drill zones that are defined by hard lines, but also legal concerns that are defined by lease lines. This is true all around the world, of course, but in the U.S. where many wells are drilled to the benefit of many mineral rights owners, this knowledge is even more vital.

Thus, it is important for drilling engineers, geologists and directional drillers to have a functional understanding of the mapping system being employed for their well. The following sections will briefly describe the systems most widely used, first in the U.S. and second in the rest of the world. For anyone interested in expanding their knowledge about geodetics in general, a few hours poking around on the internet can lead to a very interesting learning experience. A good place to start is with www.wikipedia.com.

1. Geodetics Systems Generally

STATE PLANES and the PLSS SYSTEM: If working in the U.S., then you will likely be working with one of the State Planes or Township-Ranges-Sections or both. HawkEye™ does not have support for all states that use the PLSS system, but does fully support the original western states that adopted the system. In some states like Louisiana, Oklahoma and Florida, there are modified TRS systems being used, but available digital information can't be immediately utilized by HawkEye™ because it is not in a standard format. Eventually PDT will convert these non-standard formats for use in HawkEye™.


STATE PLANE COORDINATE SYSTEM

"The State Plane Coordinate System (SPS or SPCS) is a set of 124 geographic zones or coordinate systems designed for specific regions of the United States. Each state contains one or more state plane zones, the boundaries of which usually follow county lines. There are 110 zones in the continental US, with 10 more in Alaska, 5 in Hawaii, and one for Puerto Rico and US Virgin Islands. The system is widely used for geographic data by state and local governments.

Its popularity is due to at least two factors. First, it uses a simple Cartesian coordinate system to specify locations rather than a more complex spherical coordinate system (the geographic coordinate system of latitude and longitude). By thus ignoring the curvature of the Earth, "plane surveying" methods can be used, speeding up and simplifying calculations. Second, the system is highly accurate within each zone (error less than

1:10,000). Outside a specific state plane zone, accuracy rapidly declines, thus the system is not useful for regional or national mapping.

“Most state plane zones are based on either a transverse Mercator projection or a Lambert conformal conic projection. The choice between the two map projections is based on the shape of the state and its zones. States that are long in the east-west direction are typically divided into zones that are also long east-west. These zones use the Lambert conformal conic projection, because it is good at maintaining accuracy along an east-west axis. Zones that are long in the north-south direction use the Transverse Mercator projection because it is better at maintaining accuracy along a north-south axis. The panhandle of Alaska, whose maximum dimension is on a diagonal, uses an Oblique Mercator projection, which minimizes the combined error in the X and Y directions.”³



The figure to the left illustrates an eight-state region showing the NAD27 and NAD83 zones for the SPSC. The dashed lines are county lines. The dark orange lines within the states are the NAD27 zone lines and the light orange lines are the NAD83 zone lines. In this example, only New Mexico has any changes between the two datums. (NAD27 and NAD83) Within each of these zones there is assigned a specific projection method, along with specific references from which grid coordinates are measured.

One common problem in well planning is knowing which zone a surface location is in. Of course the operators should already have recorded this, but more often than not it is not recorded in any immediate records, so it is left up to the well planners or directional drillers to figure it out for themselves.

HawkEye™ makes this very easy; all you need know is what county your surface location is located in, something that is commonly recorded in many records.

PLSS (Public Land Survey System) SYSTEM

³ From Wikipedia.com


“The [PLSS] system was created by the Land Ordinance of 1785. It has been expanded and slightly modified by Letters of Instruction and Manuals of Instruction, issued by the General Land Office and the Bureau of Land Management and continues in use in most of the states west of Pennsylvania, south to Florida, Alabama, and Mississippi, west to the Pacific Ocean, and north into the Arctic in Alaska.”⁴

States with complete BLM (Bureau of Land Management) coverage

Alaska, Arizona, California, Colorado, Idaho, Montana, Nevada, New Mexico, Oregon, Utah, Washington, Wyoming

States with limited BLM coverage

Alabama, Arkansas, Florida, Illinois, Indiana, Kansas, Michigan, Minnesota, Mississippi, Missouri, North Dakota (central and western portions are covered), Ohio, Oklahoma, South Dakota (western part is covered).



Map shows the PLSS coverage in the US (from Wikipedia).

This mapping system was designed to help map out the uncharted territories in a general mathematical way. Numerous meridians were established that are the origins from which Townships and Ranges are measured. They are the black cross hairs seen on the above map. The map is divided up, as a general rule, into 36 one mile square blocks referred to as Townships (not shown) and each square mile is referred to as a Section. Sections are commonly divided into quarter sections and quarter-quarter sections and so on. Now, if you have been involved with surveying for long it shouldn't be much of a surprise to find out that there are exceptions to the 36 square mile rule. There are lots of exceptions, in fact. The boundaries of townships that butt up to a river or a state border are truncated. Sections, in some rare cases, can actually have the same number in the numerical reference system, but not be connected. Let's not stop with the confusion there. The coordinate that measures North or South of the meridian reference line is called Township and the east-west coordinate is called Range. So, a Township's location nomenclature is defined by a (Township, Range) coordinate which seems a bit confusing, but only because two different things are being called by the same name.


Geodetics in the Rest of the World

⁴ From Wikipedia.com

Different countries employ different systems and datums depending upon the particular history of the given country. Each surface location should specify either grid coordinates, and the associated zone, or the geographic latitudes and longitudes down to the 5th or 6th decimal place in seconds. HawkEye™ can accommodate most systems used in the oil industry.

Generally, by selecting the Group, System Zone and datum, one can set up the grid mapping system for most places in the world where the oil field operates. The most common mapping system used in the world is the Universal Trans Mercator, or UTM. HawkEye™ divides this system into two groups, the Northern Hemisphere and the Southern Hemisphere. The diagram below illustrates how the UTM overlays the world.

“The Universal Transverse Mercator (UTM) coordinate system is a grid-based method of specifying locations on the surface of the Earth that is a practical application of a 2-dimensional Cartesian coordinate system. It is a horizontal position



representation, i.e. it is used to identify locations on the earth independently of vertical position, but differs from the traditional method of latitude and longitude in several respects.



“The UTM system is not a single map projection. The system instead employs a series of sixty zones, each of which is based on a specifically defined secant transverse Mercator projection.”

HawkEye’s ability to display a map with Google Earth or Google Maps is a useful tool for many reasons, but one of the most important reasons is that if an input is incorrect such as a positive longitude instead of a negative longitude it will be pretty obvious if the map puts you in the middle of China instead of the US. Geodetics in HawkEye

GETTING TO THE PROJECT GEODETICS:

Geodetics in HawkEye™ is handled from two different perspectives, for projects and for individual slots. The main geodetics dialogue for projects can be accessed in three places:

- 1) By setting up the geodetics through the Project Wizard, or
- 2) At any time by right-clicking on the project in the Data Tree and selecting “Set GeoDetics,” or
- 3) By clicking on the Geodetics icon in the Edit tab at the top of the main screen.




SLOT GEODETICS



The other perspective of geodetics in HawkEye is by slot. To access a slot’s geodetics, be sure to have a well currently selected under that slot, and then click the Slot Editor button at the top of the screen. This opens up the Slot Information dialogue (which can also be opened by right-clicking on the desired slot  in the Data Tree and selecting “Edit Slot Data”). The Slot Editor is used to re-name a slot, as well as specify location data.

LAUNCH GEOHAWK: The purple button at the bottom of the Slot Editor launches GeoHAWK, which is almost exactly like the Geodetics dialogue except that the Group, System Zone, Datum and State/County cannot be edited. It is used to allow slot location data to be tied in with the Google Earth interface.

CHOOSING A GROUP, OR NOT: When a new project is started with the Project Wizard, the user is prompted to set geodetics. At the very top left of the Geodetics box, the drop-down menu allows this. However, if the user does not yet have the geodetics data, the choice “None” can be selected. This will eliminate the display of the Easting/Northing and the Lat/Long fields in the Slot Editor dialogue, thereby making location interaction simpler, at least until the geodetics can be entered for the project later.




DON'T SWITCH IT UP: Since each of these above-mentioned groups has different sets of valid locations, switching between groups is not recommended. Conflicting coordinates as paired with invalid groups will likely crash HawkEye and you may lose all unsaved project data. Best bet is to put the geodetics information in right the first time.

SET STATE AND COUNTY: One powerful method available to help accelerate determining what the proper State Plane to use is the State/County-> Set tool. The control box is located in the upper central part of the Geodetics dialog. To use this, select the State and County where the rig site is located.



Then, be sure to click the **“Set”** button after selecting the desired county. You will note that the program has now automatically selected the proper State Plane and System Zone associated with that county. The coordinates that have been automatically entered for the Lats and Longs and Northings and Eastings are the default values for that county, normally the center of the county.


CHOOSE INPUT: You should select the radio button for either the INPUT GRID or INPUT Lat/Long and enter in the associated site values. The program will determine all corresponding numbers and if you are connected to the internet Google Maps and Google Earth will display the location in the Map tab to the right of the screen.



2. HawkEye’s PLSS Support

HawkEye™ is the only directional drilling program to date that provides powerful PLSS (Public Land Survey System) support, allowing Township, Range, Section and Section calls to be input and in return get the geographic and State Plane coordinates.


Also, geographic coordinates (Lat, Long) can be input and the program will determine the Township, Range, Section, State, County, State Plane Zone and Grid coordinates, and a set of section calls. In addition to that you can automatically create lease lines that show up in the 3D space, charts and presentation plots.



The above screenshot of the geodetics illustrates HawkEye’s PLSS capabilities (older version of the dialogue). The thick black line represents a county line, in this case Arapaho County, Colorado. The blue line represents the Township, the red border represents the Section, Sec 4. The white borders with the yellow thumbtacks are showing all the other sections of the given township. (Invoked by checking the “Show Sections” box).

The complete legal description of the location is Sec4-R62W-T5S 2626.52 FEL, 2607.71 FNL. Translated—Section 4, Range 62 West, Township5 South - Section Call: 2626.52 feet East from East line, 2607.71 feet from North Line.


The screenshot below illustrates the same location, but this time the ‘Show Sections’ is turned off and the thumbtack in Google Earth has been clicked, illustrating all of the different methods of referring to the same location in the white info box.



For users who need to routinely work with TSR coordinates and section calls in the western states this is an invaluable tool.

PLSS INPUTS: With certain states, the user may have the option to input the TRS⁵ data directly. These additional fields, under the “Input Map” radio button and comprising the bottom half of the whole panel, are only available in about eleven states. So when choosing a state and county for the project, these inputs may well not appear in the Geodetics editor.


A FEW QUIRKS: When using the PLSS fields, it is important to remember a few peculiarities about the state survey data. First, each state may have more than one Meridian. Be sure to choose the right meridian when inputting PLSS data.



⁵ (TRS) Township, Range, Section

Second, the Township and Range can be selected by number from a dropdown menu, but the North/South and East/West must be chosen first for each of them. This is because the list of available townships and ranges are different between east, west, north and south.

PLSS OFFSETS: Users can enter offsets in the PLSS data set. Be sure to select the correct reference from the pulldown menu for both the X and Y offsets. FEL is “From East Line.” Thus “FWL, FNL, FSL.”



Using user inputs on reports

MAPX: 1000 FEL

MAPY: 500 FSL

In this particular example, you can see the offset noted by the bottom right thumbtack. It shows a location 1000 feet (FEL) From East Line and 500 feet (FSL) From South Line. This is shown in the Google Earth interface. If you click on the thumbtack itself, a pop-up will appear, displaying all relevant map data, as illustrated on the previous page.




3. Google Earth Support

HawkEye™ can superimpose the 3D curves of a project onto a Google Earth. Make sure to have the Google Earth program installed. Find the link to download the program for free at <http://earth.google.com>.


The Google Earth module will do two principle things. First, it will illustrate over a satellite image of the planet's surface any geodetically section information defined in a project. This boundary is illustrated with a green line and offset with a white line:



The second function of the module is to illustrate the scope and location of a project vis-à-vis its location in a zone. The project information that is displayed on the surface map appears to sit aboveground, although obviously any well would be underground.



With only 3D Curves toggled on, the well will be displayed as ending at the surface of the planet and extending upwards to the sky with a 1:1 scale.




With both 3D and 2D Curves on, a path along the surface will illustrate where the curve walks along the surface as well as the 3D curve going upward.

The Google Earth module requires that Google Earth be installed. It will also require a live internet connection to run. Download the program for free at <http://earth.google.com>

One major setting to keep in mind is the 2D and 3D Curves toggle, found in the bottom left options tree.

By turning on both 2D and 3D Curves, the image will display not only the image of the well with the bottom touching the surface and extending to the sky, but also a line of where the curve travels with respect to the surface.



GOOGLE AND HAWKEYE GEODETICS: As noted in the above section on Geodetics, Google Earth is intergrated as an API inside of the HawkEye geodetics dialogue. Although it is not crucial for entering and editing geodetics information, Google Earth does a tremendous job in helping the user visualize coordinates and other map parameters as they are entered into the program.

Presentation Plots (Well Planning Version)



This icon launches the Presentation Plots module, which is covered in the Plots chapter of this book and which is only available in the Well Planning version of the program.


Structure Manager



The Structure Manager, which is only available in the Well Planning Version of HawkEye, is used to start a multiple-slot project quickly. It organizes any number of initial slot points and numbers them in a user-defined pattern. Their positions can be defined by any of the possible patterns found in the field, and can save a lot of time in getting the slots made in the project database.

OPEN THE STRUCTURE MANAGER: Right-click on the Structure icon  found in the Data Tree on the lefthand side of the main screen. This will open up the Structure submenu.


Select the Structure Manager  from this list. The slots made from here will be associated with that structure that was right-clicked on.




Ord #	Label	Local NS	Local EW	Grid Northing	Grid Easting	Latitude	Longitude	Latitude DMS	Longitude DMS
1	1	0.00	0.00	997687.69	741496.54	33.740040994	-105.455601985	33°44'24.1476" N	-105°27'20.1671" W
2	2	4.10	-11.28	997691.79	741485.26	33.740052512	-105.455638971	33°44'24.1890" N	-105°27'20.3003" W
3	3	8.21	-22.55	997695.90	741473.99	33.740064029	-105.455675957	33°44'24.2305" N	-105°27'20.4334" W
4	4	12.31	-33.83	997700.00	741462.71	33.740075547	-105.455712943	33°44'24.2720" N	-105°27'20.5666" W
5	5	16.42	-45.11	997704.11	741451.43	33.740087064	-105.455749929	33°44'24.3134" N	-105°27'20.6997" W

The panel on the right-hand side of the Structure Manager is dedicated to the placement and labeling of the slots:

GROUP STYLE: The general orientation of the slot group can be rectangular, circular or custom. (NOTE: Custom option is not available in current version).




LABEL STYLE, ORDER & DIRECTION: These options create the way the slots are numbered, and cover all iterations of sequential labeling for rectangular and circular slot groups. The START CORNER radio buttons determine where the sequential labeling begins. Additionally, the slider in the bottom left corner of the picture window toggles label orientation.



SIZING: Bearing and distance between each slot can be defined here.

ASSOCIATE WITH: Any of the slots can be designated as the Reference Slot, and that Reference Slot can be associated with either another slot or the current structure. The Reference Slot can also be given a coordinate offset.



EXCEL: Once a slot group has been set up, click the “EXCEL” button and the slot coordinates will be exported into an Excel spreadsheet, complete with a floating picture of the slots that can be placed anywhere on the spreadsheet.



ADD GROUP: Any set of slot parameters can be saved as a custom group by clicking on the “Add Group” button at the top of the Manager.

CLICK “SAVE” FIRST: Once a structure’s slots are labeled and oriented, click the SAVE button. Then click “APPLY TO SLOTS.” This will close out the Structure Manager and begin building each slot under the current structure. Those slots will appear in the 3D space as well as in the Data Tree.

Each newly made slot will have a survey and proposal curve named after its slot label.




NOTE: After a slot group has been made and curves built from the respective slots, going back to change the orientation and labeling of the slots in the Structure Manager is not recommended. Thus it is best to get the details of the slots correct before beginning to build curves from any of the slots created.

Snapshot



This feature is specifically for Presentation Plots (Well Planning version). It allows the user to capture 3D images for use in the “multishot” element of a wall plot.



Display Settings



This opens the Display Settings tab, which is covered at the end of this subsection under [Settings Tab](#).


d. 3D Screen tab




The 3D Screen tab at the top of the main screen displays some options for the 3D space.



This will toggle on and off Comments and Annotations for all curves in the 3D space. Comments will show up in a Critical Points report, while Annotations will only show up in the 3D space and nowhere else. You can click this “Create Anno.” button to create an annotation at wherever your current Look-At Point is on the curve in the 3D space.



Toggle various 3D visual aid elements with these boxes.



Transparency of all curves, as well as your Zoom Factor are controlled here. NOTE: Your zoom is also controlled by holding down the right mouse button and moving the mouse wheel up and down.



These control how all Lease and Hard Lines are displayed. To turn off individual Lines, uncheck them in the Data Tree.

e. Tools tab



Google Earth



Google Earth is a separate program, and HawkEye uses its API (a software plugin) to display the current Project's curves and hard/lease lines on satellite imagery of the location based on the Project's geodetic information.

NOTE: This plugin feature only works after geodetic information has been entered in the Project's geodetics dialogue. Get to that editor by right-clicking on the Project in the Data Tree and selecting "Set Geodetics."


Interpolation Tool



Interpolation is a method of constructing new data points within the range of a discrete set of known data points. In HawkEye™, the Interpolation tool allows the user to either merely CALL FOR A SURVEY ENTRY into a list one at a time, or to go ahead and use an interpolation point as a TIE-IN POINT for a sidetrack curve.

Once inside the panel, there are two major choices: 1) to invoke either an MD or a TVD interpolation, and 2) whether to merely have that interpolation point or to use the point as a tie-in for a sidetrack curve.

The first step is to enter either the MD or TVD depth in the top left. Then hit TAB and HawkEye™ will calculate the interpolation, filling in all the data down the middle "Interpolate" column. The columns to the left and right are survey stations displayed for reference.



The Interpolation panel breaks down into two choices at the top: 1) MD or TVD as the mode of measurement, and 2) either insert the interpolation or make it tie-in for a sidetrack curve.

The second step is to decide whether to INSERT that interpolation into the survey list, which only requires clicking on the “Insert” button; or making that interpolated point a tie-in point for a sidetrack curve.

By clicking on the “Make Tie In” button, a dialogue will appear for creating a new curve and you can enter the parameters for a sidetrack proposal. Once created, it will appear in the Data Tree just like any other proposal curve, with all the attendant options associated with it.


Interpolating from Lists: The interpolation tool includes two options for interpolating surveys directly from simple text files that could be set up with NotePad or WordPad. Simply input MD or TVD, (comma) comment or formation top, whatever. Input as many lines as you need, then save the file. You can use that file on other curves and save yourself the hassle of interpolating tops for each iteration of a what-if scenario being played out with geologists and drilling engineers that keep changing specifications.

Torque and Drag




This is a 3rd party module that optionally comes with HawkEye Field and always comes with HawkEye Well Planning. The final chapter of this manual covers the functionality of this program. If you do not see this icon, then your license does not contain the rights to this particular module.

.IPM Survey Tool Manager



The Survey Tool Manager is an interface for importing or exporting advanced error modeling files. These files are usually provided by engineers who are familiar with the schema and are generally not tweaked from within HawkEye, although they may if the user is knowledgeable and comfortable with the parameters.

OPENING THE MANAGER: The Survey Tool Manager is found in the Tools tab in the top middle of the main screen.



On the lefthand side of the Survey Tools Manager is a tree-style list of the different models being implemented. Along the top are the fields displaying:

- Vendor (dropdown list)
- Short Name
- Description

IMPORT/EXPORT: The Survey Tool Manager works with the industry standard .ipm files, which may be imported or exported.

DEFAULT SURVEY TYPE: Choose from Magnetic, Gyro, or unknown.

TEMPLATE: Choose from a dropdown list of available .ipm files to load an ISCWSA template.

LOCK/DEFAULT: Check either of these buttons to lock in the current template selection and to make the selection your default, respectively.

NOTE: It is not recommended to change or alter the tool profiles in the Survey Tool Manager unless you understand the various parameters. Since the error models are highly mathematical and settings dependent on one another, simple mistakes could render the error model that you are using unusable or worse.

Refresh Model



This will force the program to recalculate all uncertainty calculations and refresh the 3D space. The program will normally do this automatically but sometimes after adding/editing a survey, it might need refreshing.

Error (Uncertainty) Display Options



This opens a menu from which you can choose a variety of visual modes for the zones of uncertainty in the program. Each of these options is based on the same calculations, and those calculations are based on whichever Survey Tool you have chosen for the surveys. The hotkeys for quickly toggling through each of these view modes is in brackets.

- Display Off [F2]
- Ellipsoid [F3]
- Ellipsoid with Wire Cylinder [F4]
- Wire Cylinder [F5]
- Ellipsoid with Solid Cylinders [F6]
- Ellipsoid with Wire and Solid Cylinders [F7]
- All Solid Cylinders [F8]

Advanced Error (Uncertainty) Display Options



This opens a menu of more advanced zone-of-uncertainty view options for the 3D space.
LD: Least Distance

NE: North-East

HL: Highside-Lateral

All uncertainty displays in the 3D space are based on the Survey Tools listed for each survey, which themselves are based on .IPM error models associated with that tool.

ISCWSA Sigma:

Referenced Ellipsoid Alt+M
With 3D Vectors [Alt+X]
LD Ellipses [Alt+E]
LD Plane [Alt+V]
Pedal Curves [Alt+P]
Compared Ellipsoid [Alt+O]
NE Ref. Ellipse [Alt+N]
HL Ref. Ellipse [Alt+H]

ISCWSA SIGMA: Adjusting this value controls the confidence level to be calculated by the ISCWSA model. For example, let's say the confidence level is 95%, or 2 sigma in statistics jargon. What this means is an ellipsoid displayed along the well will illustrate the volume for which we have 95% certainty that the true survey point is in that volume. The larger the confidence level, the bigger the ellipsoid. Most operators use two sigma or three sigma confidence levels, two sigma being the most common.


From Curve Controls

From Curve:	<input type="text"/>	Start MD:	<input type="text"/>	INC:	<input type="text"/>	Update
F Curve:	<input type="text"/>	Up-Down:	<input type="text"/>	AZM:	<input type="text"/>	Delete


The “From Curve” tool allows you to create an entirely new curve based on the position of an existing curve. This new curve, once created, will show up in the Data Tree as a special “f” curve nested under the parent curve.



f. Settings tab




The Settings tab contains almost all non 3D-space settings, mostly pertaining to the 2D spaces (VS Ciew and Top View). You can easily see the categories by looking for the white text on blue backgrounds at the bottom of each subsection.



3-Panel Interface toggles the main screen's mode. Three panels include both main windows as well as the Survey List Panel on the bottom right. Otherwise it's just the two main windows without the survey window.

Remote View: This opens a dialogue that allows the user to adjust visual settings to accommodate remote access to the computer. Sometimes the 3D space will be too sensitive to mouse controls and appear "jumpy." Options here help to alleviate that issue.

Survey Grid: This opens the Grid Manager, which allows the user to customize the appearance and the columns of the Survey List Panel (which is only visible when 3-Panel Interface is turned on). You can also access this Grid Manager by right-clicking on the colored header of the Survey List Panel itself and selecting "Grid Manager."



Auto Comments: This will automatically create comments at every "critical point" in a curve. NOTE: This is intended for Proposal curves that generally have clean geometry except for a few points (e.g. KOP, Landing, TD). If you click Auto Comments for an as-drilled curve, the program will likely regard every survey as a critical point.

Clear Comments: This will erase ALL comments for the current curve. There is no Undo function in this program, so be careful.



Show tips at startup: This refers to startup tips that are no longer active in HawkEye


Autosave: Set the frequency at which you want the program to save survey data to the current HawkEye database.

Projection Interval length: Set the length between surveys when creating projections.


Include structures: Set the radius from the current structure/pad within which other structure/pads in the project are to be displayed in the 3D space.




Target & Casing Comments: These parameters control the appearance of the Target and Casing comments that float next to those objects in the 3D space.




Information Text: These parameters control the appearance of the text found at the top left of the 3D space. You can toggle that information on and off by pressing "I" while the mouse cursor is hovering in the 3D space. The parameters shown at left here are optimal for viewing this information. Not all combinations of parameters will yield legibility.



3D Axis Font: These parameters control the text shown along the axis of the floor and walls of the 3D space.



Charts Axis Font: These parameters control the appearance of the axis labels in the 2D views (VS and Top tabs).




3D Cage Wall Colors: These parameters control the colors of the 3D space's background "walls" and "floor." The color selections are not straightforward, as they blend with the "BG Color" that is also selectable here.



Label Manager: This opens a separate dialogue that allows the full control of labels in the 2D views (VS and Top tabs).

VS and TOP VIEW: Check any of these boxes to toggle the particular label to show up in the 2D VS view and 2D top view.



AUTO LABEL


FREQUENCY: This section relates to how often you want to have a label generated in the plot. For now the only option is to select every X number of surveys. However, by MD and by TVD every X number of feet or meters should be available in future versions.

SCOPE TO APPLY: This controls to which curves the labeling schema is to be applied, whether it is to all curves or just the proposal curve and or the current work curve.

TEXT PROPERTIES: This section of the panel controls all of the features of the lettering as they are found in the 3D space. To change the fonts, select the “Axis Labels” tab at the top of the panel and click on the “3D Axis Font...” button.

VS VIEW EXAGGERATION: Exaggeration increases the Y-axis interval, which is useful for horizontal wells when trying to better fit the entire well in the graph. The exaggeration is by ratio, so if “1” is 100ft/division, then “2” would be 50ft/division, and “3” would be 33 ft/division.


BOTH PLOTS: Check any of these boxes to toggle the described features which are applied to both the VS View and Top View graphs.




NO GRID: This will remove all background lines in the 2D views (VS and Top tabs).

MAJOR LINE TYPE: This controls the draw type of the background grid’s major grid lines.


MINOR LINE TYPE: When “Major Minor” is selected in the Display Grid, these settings will control the draw type and characteristics of the many smaller, minor lines. Unless the user wants a blotting effect in the background, it is best to keep these lines thin and light in color.




Major Line Type: Controls the color and style of the Major lines in the 2D views (VS and Top tabs).



Minor Line Type: Controls the color and style of the Minor lines in the 2D views (VS and Top tabs).



Top View Axis Labels: Rename the axis labels that appear on the outside of the Top view (Top tab).



VSP View: Rename the axis labels that appear on the outside of the VSP ("Vertical Section Plane") view (VS tab).

g. Help tab



The “Help” tab on the top right of the main screen gives access to the following:

- The Update button to check for updates
- Open a hotkey map (keyboard shortcuts for the program)
- A link to the Quickstart Guide (16 pages)
- A link to the User’s Guide (this document)


7. Main Window Tabs

The tops of the two main windows have tabs that can switch the view mode of those windows.



a. 3D View


The 3D view is open by default on the right-hand window of the main screen. You may need to adjust the window size by dragging the left-hand border to the left to maximize the 3D window.




Navigation tools in the 3D space are many and powerful, and they are [discussed in detail in the next section](#). But here are a few key mouse-based tools to remember:




FUNCTION	MOUSE CONTROL
Zoom in and out	Hold right button and scroll wheel up and down
Pan	Hold left button and move mouse around
Move slider	Move scroll wheel up and down
Access context menu	Right-click on the object (curve, target, plane or background)

The main options for operating the 3D space are found at the bottom of the 3D window against the blue background.



It is important to get acquainted with each of these tools, but often the quickest way is to experiment with them in HawkEye™. Switching between work and proposal curve is utterly essential, as is the zooming tool, but learning the different grid and ellipsis modes will also greatly enhance the user’s abilities to visualize the space around the well.

	<p>Work Mode/ Proposal Mode Toggle: Left-click this button to switch between Work Mode or Proposal Mode. NOTE: There can be only one “Current” work curve and one “Current” proposal curve to follow at a time. To set a new “current” curve, just right-click on the curve and select “Set as Current Work/Proposal Curve.” OR, press “Z” to switch modes while cursor is in the 3D space.</p>
	<p>Driller’s View/ Highside Up: Left-click to reset “Driller’s View,” which always switches to Work Mode on the current work curve, turns the Highside Up mode on, and puts the view at the latest survey station.</p>
	<p>Sight Editor: Left-click on this to open the Sight Editor. You can also toggle on and off the sight in the 3D space with the spacebar (cursor needs to be hovering over 3D space). With the sight on in the 3D, right-click on the sight and select “Sight Editor.” There is a custom sight for the current Work curve as well as the current Proposal curve.</p>
	<p>Sight Toggles: Check and uncheck these to turn on and off the two sights (one for the current Work Curve and the other for the Curve Proposal (Plan) Curve).</p>
	<p>Highside toggle: Turn on or off the Highside Always Up mode of view.</p>

	<p>Look-at Point Depth (MD): In the 3D space, the Look-at Point (POV) is only ever at one point on a curve that can be slid up and down with the wheel.</p>  <p>This is where the Look-at Point is located wherever it is on a curve, defined by current MD. The user can type in the MD, then hit TAB to update.</p> <p>Look-at Point Depth (TVD): The depth of the Look-at Point, displayed by TVD here.</p> <p>NOTE: These depths are also displayed in the top left of the 3D space (Press "I" when cursor is in the 3D space). The user can type in the TVD they want to be at, then press Tab to update.</p>
	<p>Step Interval: This sets the distance of each mouse wheel "click" when gliding up and down the curve. Even with the hyperscroll mouse, it takes a lot of spinning traverse the length of a curve at 1 ft per iteration. But sometimes that's what is needed for precision navigation. Choose from the step speeds: 1, 2, 5, 10, 20, 30, 50, 100.</p>
	<p>Step Slider: This is a way to move the sight up and down the curve aside from the scroll button on the mouse, or W,S or UP, DOWN keys. This slider become more sensitive as the curve gets longer because the ends of the slider are always the top and bottom of the curve. Click either end to skip to the very beginning or end of the curve.</p>
	<p>Curve Menu: Left-clicking this button is the manual version of RIGHT-CLICKING on a curve in the 3D space or Data Tree. It will bring up the contextual menu for whichever is the current curve. This is useful when the MD or TVD specified is exactly what is desired.</p>

b. Vertical Section (VS) View

This is the view that one would have of a well from the side. The view plane is by default 90 degrees from the proposed bottom hole location. The direction which is used to set the Vertical Section Plane (VSP) is the closure direction between the surface location and the end of the well.

Exaggeration decreases the Y-axis interval, which is useful for horizontal wells when trying to better fit the entire well in the graph. The exaggeration is by ratio, so if "1" is 100ft/division, then "2" would be 50ft/division, and "3" would be 33 ft/division.



The icon on the top left  will open the Graphics Properties panel.

The Presentation Plot icon next to it  will open the Presentation Plot module of HawkEye™, with the current Vertical Section view at front and center. (Well Planning version only).

PAN: Holding down the RIGHT mouse button on the 2D window and dragging the cursor around will move the orientation of the grid, allowing the user to navigate along a curve or otherwise change a view perspective along the graph's plane.

ZOOM: Holding down the left mouse button to draw a box onto the graph will zoom the graph into that area. Hold down the right mouse button and scroll the mouse wheel up and down to zoom.

c. Top View


Also referred to as a horizontal view, the Top View is as if looking at the well from above, with north oriented to the top.

The icon on the top left  will open the Graphics Properties panel.

The Presentation Plot icon next to it  will open the Presentation Plot module of HawkEye™, with the current top view at front and center. (Well Planning version only)

PAN: Holding down the RIGHT mouse button on the 2D window and dragging the cursor around will move the orientation of the grid.


ZOOM: Holding down the left mouse button to draw a box onto the graph will zoom the graph into that area. Hold down the right mouse button and scroll the mouse wheel up and down to zoom.



d. Proximity

This plot shows the distance from the reference well (oriented in the center) to the other wells.

CALCULATE PROXIMITY BOX: In order to “turn on” this plot, you have to check the “Calculate Proximity” box. This will activate the relatively resource-consuming calculations. This can also be done by clicking on the blank circle plot itself.



REFERENCED CURVE: This is a display-only box that indicates which curve is the referenced curve that is shown as the center point of the plot. Change the reference curve by changing the current curve selected for the 3D space.

SCALE: Set the radius within which distances between curves is analyzed.

THREE TYPES OF DISTANCES:

TRUE: The closest distance from the reference point to any other well, regardless of what plane it is in. Some references regard this as the “closest spherical distance.” It is important to have this distance type turned on when you are approaching a well, as it is the only tool that can pick up a head on collision with another well.

NORMAL: The plane that the distance is measured on is the plane which is perpendicular to the direction vector where you are currently aimed (current MD, Inc and Azm). This distance is often the most useful when directional drilling; knowing how much to the left or right, or up and down one is determined with this tool. **NOTE: This is the distance type used when adding a UD and RL column to a survey report.**


TVD: The distance measured along the horizontal plane at the TVD of the current reference well location. In vertical wells this tool is most useful.

LEASE LINE DISTANCE: Turning this on will measure the distance to any active lease or hard lines. It will display any user-set offset distance to the lease line, as well as the boundary line distance. **The proximity information generated here is displayed in the 3D info field in the upper left corner of the 3D space.** These distances displayed will have an 'O' and a 'B' appended to the end. The 'O' represents the offset boundary from the lease line and the 'B' represents the actual boundary itself. Only the closest boundary point data is displayed.

You can see a thin line in the 3D space connecting the current point with the boundary lines. (To turn on 3D Info, just open the Graphics Properties panel and select the "3D Options" tab, and click the "Show 3d Info" box).

NOTE- North Arrow v. High Side Arrow:

When following along the reference curve, the Proximity plot will stay oriented to north (as indicated by the red arrow pointing up labeled "North"), but when the look-at point reaches an inclination greater than 1.5 degrees, a black highside arrow will appear to indicate the orientation of the plot, and the red north arrow will remain.




NS/EW and UD/LR: If the look-at point along the curve is somewhere under the inclination threshold (set in the Sight Editor on the bottom right of the form), then distances to the curves will be expressed in terms of **North/South** or **East/West** of that curve. When the look-at point reaches an inclination higher than the threshold, then distances are displayed as **Up/Down** and **East/West** of the curve.

Distance Lines: When "Calculate Proximity" is turned on, distance lines will appear in the 3D space to illustrate the distances calculated in the plot. They are color coded red and black for true distance, Blue and Black for normal distance, and Cyan and Black for TVD distance.

TIP: To get to a specific look-at point for particular proximity analysis, just type in the MD or TVD into the forms then press Tab in the bottom left just below the 3D window.

PROXIMITY INFOCARD: By left-clicking on any of the Distance Lines, an Infocard appears containing all the relevant information of that particular distance calculation from that particular point to the other well.




IN-DEPTH ON THE PROXIMITY LINES:

The directional driller has two references for orienting his drilling motor; the one he uses depends upon the last measured inclination. If the inclination is above a certain low value, normally 2 - 5 degrees inclination, then he orients his motor to high side. (The most intuitive way to think of high side is that it is the way you like airplanes to be flown, right side up – that’s high side in oil field jargon).

Otherwise he orients his motor to the magnetic direction that he wants to move towards. The MWD tool will control the switchover, so when the DD sees an inclination above the Magnetic-Gravity Tool face value he knows that all the tool faces being sent are gravity tool face. The fact is that this is one piece of operational information that must be monitored carefully when sliding at low angles.

In the snapshot of the Proximity Infocard shown below there are two types of proximity described. The following is a description of how to interpret this card. The first proximity type is the proximity to a well and the second proximity type is Next POI (short for Point of Interest).



PROXIMITY – Sight set to [Normal Plane\TVD Plane] or [Gravity TF\Magnetic TF]

This can represent the proximity between the reference well and any other well in the project, depending on which Proximity Line you clicked on.

Type: [True Minimum\Normal Plane\TVD]

This represents the type of proximity values being displayed. The True Minimum values are illustrated by the yellow and black checkered connection bars in the 3D space. The Normal Plane is illustrated by the green and black striped connection bars, and the TVD plane connectors are represented by the Blue and Black lines. The user selects one or all types of proximity under the Proximity tab. It is best to use True Minimum, but the other two are useful under different circumstances.

Reference: Reference well name @ X MD, Inc: X, Azm: X

This is the name of the reference well and the current point.

Comparison: Name of comparison well and MD point of comparison

Distance: Straight line distance for type of distance X

Separation Factor: N/A Sigma: N/A

If separation factor is being calculated the current value and the current Sigma will be displayed here.

For Gravity Tool Face the distances are described:

Reference is X Above or Below the comparison curve

Reference is X Left or Right of the comparison curve

Reference is X is in Front of or Behind the comparison curve

For Magnetic Tool Face the distances are described:

Reference is X North or South of the comparison curve

Reference is X East or West of the comparison curve

Reference is X in Front of or Behind the comparison curve

When vertical or near vertical (when magnetic tool face is used), it is easiest to explain relative positions in terms of normal geographic terms such of North-South and East-West. At higher angles, when gravity tool face is used, the geographic terms become less useful for orientation and steering, so the plane perpendicular to the direction being drilled (the normal plane) is used as the steering guide. The easiest way to describe orientation relative to this plane is by describing it in local human terms, Above-Below, Left Right, in Front and Behind. The normal plane proximity will always lie on the normal plane, the TVD plane proximity will always lie on the TVD plane and the True Minimum proximity will be off those planes almost always. The local descriptions of the true minimum are projected to the normal plane.

NEXT POI: Points of Interest are defined by the comments that are included on the Proposal curve. A POI can be a kick off point or the top of a formation or any other survey that has a comment. **The only time this proximity is displayed is when the current curve is the work curve and there is a plan curve and the plan curve has comments.** Hawkeye will automatically search for the next point of interest and display how far away it is from the normal plane defined by the inclination and azimuth at the point of interest.

The primary purpose of this is to allow for the users to have a heads-up about what is next in line, be that a formation top, casing point, or a critical point in the plan.

e. Ladder Plot

The Ladder Plot is another way of visualizing the distances between curves. This type of plot is also referred to as an 'MD vs Distance' plot.

The distance of each curve is plotted in the vertical scale as a function of the MD (measured depth).

If the two lines overlap one another that should be interpreted as a potential collision problem.

The advantage of this type of plot is that one can instantly spot problem areas by noting the points at which the curves dip down near the baseline.

REFERENCED CURVE: Select the curve to be the baseline reference with this drop-down menu. The dropdown menu contains all curves in a project.


MAX DISTANCE: This is the observed radius from the reference curve, the distance at which HawkEye™ will stop plotting a curve.

COMPARED CURVES: This drop-down will allow the user to check off each or all the curves to be compared.

REFRESH: Hit this button to recalculate any changes made to the Ladder Plot parameters.

DOUBLE-CLICK TO FULL SCREEN: Double-click on this chart to maximize it and get the color legend that identifies each curve by color.

DOTTED LINES: The dotted lines in a chart represent the outer boundary of uncertainty for a given curve.



f. Alerts

The Alerts tab in the bottom right of the main screen provides a criticality number between 1 and 5, with 5 being the most dangerous, according to certain rulesets that are defined by different companies, in reference to proximity. Center-to-center distance between wells, and ellipses of uncertainty (calculated by ISCWSA error model) are used to calculate proximities.

C...	MD	Criticality	Distance	SF	To ...	To Curve
20.00		5.00	0.00	0.00	20.00	Hand 149-92-31C-30H - Plan3
141.00		5.00	0.00	0.00	141.00	Hand 149-92-31C-30H - Plan3
197.00		5.00	0.00	0.00	197.00	Hand 149-92-31C-30H - Plan3
283.00		5.00	0.00	0.00	283.00	Hand 149-92-31C-30H - Plan3
369.00		5.00	0.00	0.00	369.00	Hand 149-92-31C-30H - Plan3
454.00		5.00	0.00	0.00	454.00	Hand 149-92-31C-30H - Plan3
540.00		5.00	0.00	0.00	540.00	Hand 149-92-31C-30H - Plan3
625.00		5.00	0.00	0.00	625.00	Hand 149-92-31C-30H - Plan3
710.00		5.00	0.00	0.00	710.00	Hand 149-92-31C-30H - Plan3
796.00		5.00	0.00	0.00	796.00	Hand 149-92-31C-30H - Plan3
881.00		5.00	0.00	0.00	881.00	Hand 149-92-31C-30H - Plan3
966.00		5.00	0.00	0.00	966.00	Hand 149-92-31C-30H - Plan3
1,050.00		5.00	0.00	0.00	1,050.00	Hand 149-92-31C-30H - Plan3
1,136.00		5.00	0.00	0.00	1,136.00	Hand 149-92-31C-30H - Plan3
1,220.00		5.00	0.00	0.00	1,220.00	Hand 149-92-31C-30H - Plan3

SAFETY RULESETS are chosen at the start of making a project and can be edited at any time by RIGHT-CLICKING on a project in the Data Tree on the left, then selecting “Edit Project” and choosing from the drop-down menu labeled “Safety Ruleset.”


Directional Drillers and drilling engineers should pay close attention to Alerts when drilling in a crowded area.

CRITICALITY LEVELS:

Criticality	Comment
1	Nothing to worry about, proceed drilling.
2	Monitor separation factor as drilling proceeds.
3	Caution, continuously monitor Distance both onshore and offshore. Review the action plan for the possibility that the separation factor falls below 1.5.
4	Drilling operations should take swift, positive action to change drilling direction, increase survey accuracy or other actions to increase the separation factor.
5	Stop drilling. You are in a very high risk situation.

g. Surveys

One of the primary regions on the main screen is the survey grid at the bottom. It displays all the survey information for the currently selected path and has a customizable data spread that behaves like a spreadsheet application.



The surveys in HawkEye™ are displayed in the default main screen along the bottom. The window provides a wide spread of customizable information fields.

CUSTOMIZE COLUMN ORDER AND FREEZE FRAMES: The data columns can be moved left and right by clicking and dragging the column header and dropping it wherever desired. In addition, there is a freeze frame stop control that can also be dropped between any two columns in order to “freeze” all columns to the left such that when the horizontal scroll bar is used, only the columns to the right are moved.

	EW (Ft)	TVD (Ft)	Closure Dir Deg	Closure (Ft)
6.97	6.97	189.28	45.00	9.86
7.76	7.76	194.15	45.00	10.98


The full spread of data in the survey window is extensive, offering 46 different types of data for each survey entry. The following is a list of the data displayed for each survey:

List of Survey Data Columns				
No.	BHA ID	MD	Azm Deg	Inc Deg
NS	EW	TVD	Closure Dir Deg	Closure
Comment	NN (ft ²) *	EE (ft ²) *	VV (ft ²) *	NE (ft ²) *
NV (ft ²) *	EV (ft ²) *	HH (ft ²) *	LL (ft ²) *	AA (ft ²) *
HL (ft ²) *	HA (ft ²) *	LA (ft ²) *	Minor	Major
Vertical	Minor Azm Deg	HLA Major	HLA Minor	HLA Depth
HLA Azm Deg	Survey Type	Subsea	DLS °/100	Build Rate °/100
Walk Rate °/100	VS	TFA Deg	Easting	Northing
Latitude Deg	Latitude DMS	Longitude Deg	Longitude DMS	RKB
CL				

* Measurements may be in feet or meters, depending on project settings.

BEST WAY TO ADD SURVEYS ONE BY ONE: Click the blue plus icon on the far left in the row of projection icons to open the Survey Editor. In this dialogue all of the surveys for the currently selected well will appear, and several of their parameters may be edited.

The BEST WAY to add a survey is, once inside the Survey Editor, type the Measured Depth, press ENTER, then type in the Inclination, press ENTER, and then type in the Azimuth and press ENTER. After the third “ENTER,” your new survey will have been created.




1. Copy and Paste Surveys

Surveys can be imported in HawkEye™ or they can be added and edited manually within the program. One simple way to import surveys into HawkEye™ is to copy them from a spreadsheet and paste them directly into the survey window.

STEP 1 Grab the data from the spreadsheet by selecting it and copying (Ctrl+C or right-click and select “Copy”).

NOTE: HawkEye™ will accept spreadsheet data from Microsoft Excel, OpenOffice and all other common spreadsheet programs.


IMPORTANT: Spreadsheet column order must be in MD, INC and then AZM from left to right in order to paste properly in HawkEye™.



STEP 2 Select a curve from either the Data Tree or the Project Control Panel. **NOTE:** The surface location of the curve must already be established. The recommended method to choose a curve is to use the Project Control Panel. Just left-click once on a curve in the Projection Control Panel to select it. This will bring up the surveys for that curve at the bottom of the main screen.



STEP 3 Paste the data into the curve’s survey list by RIGHT-CLICKING anywhere in the Survey List Window, then selecting “Paste Data.”




As long as the data columns were arranged in the right order in the original spreadsheet (MD, INC then AZM), then HawkEye™ will take that data, extrapolate all additional data and display the curve information in the 3D space.



USE THE RIGHT-CLICK MENU: Another way of bringing in more than one survey at a time is to import them directly into the curve data via the Curve right-click menu. This context menu can be accessed directly in the 3D space, Data Tree or the Project Control Panel by RIGHT-CLICKING on a curve. Depending upon the context in which this menu is invoked the contents will be more or less as you see them here.

If it is a work curve you see, then the “Set as Work Curve” will be the first item instead of “Set as Proposal Curve.” You can change the color, clear all the comments, Auto-comment a curve, add surveys and so on. You should have already become somewhat familiar with most of the items and they are self-explanatory for the most part.



2. Importing and Exporting


Worthy of special mention in the curve right-click contextual menu are the **Export** and **Import** options. Surveys can be exported to five types of files. NOTE: Any additional standard formats that may be required can be included per request by the user.

3. **CSV files** – Comma, Space or Tab Delimited files that can be easily imported into spreadsheets and databases.
4. **SAY files** – A special survey format that works with PDT's other survey products, WinServe™ and WinSurv2™.
5. **MMS files** – A special survey format that for the Mineral and Mines Service in the United States.
6. **DIMMS files** – A special file format to supply survey data to DIMMS, a Landmark rig reporting system.
7. **Compass™ files**- The import options on the menu should be fairly obvious. However, one very important option is not on the menu and that is the import of a Compass™ transfer file.

3. Importing a Compass Transfer File

Compass™ is a widely used Landmark product. This software is similar in function to HawkEye™ and can export a variety of XML transfer files for use within Compass™. HawkEye™ uses the .EDM.XML transfer file.

If you are a user of Compass™, or a company you are working with is a user of Compass™ and you want to get all of that data on a given project into HawkEye™, then create an EDM.XML transfer file in Compass™. Then **drag and drop that file directly on top of HawkEye's 3D space** and if all goes well you will have all the surveys, geodetics, lithologies, targets and casings in HawkEye™. You can also navigate to the following:



II. PROJECT DATA

RIGHT-CLICK ON EVERYTHING


CUTTING TO THE CHASE: Although the functionality of adding various tiers of data into the Data Tree is explained below, a useful general shortcut that must be mentioned is that HawkEye™ is all about right-click menus. Most objects on the screen in HawkEye™ have a contextual menu that can be accessed by right-clicking on it. In these menus lie the power of HawkEye™, where things can be added, edited, deleted, and where relevant jumps to other dialogues and control panels are always found.

1. ADDING BASIC PROJECT DATA


Although the [New Project Wizard](#) is great for getting started, the user will inevitably have to dive into the [Data Tree](#) and add things like slots and curves. But doing so is an intuitive process.

a. Adding Projects and Structures


ADDING FIELD/COMPANY: Starting from the top, in order to add a new Field to the currently open database, right-click on the FIELDS/PROJECTS label at the very top of the Data Tree and select “Add New Field.”




This opens up a small dialogue in which you can enter the Field Name and the Location. Location as entered in this dialogue is not used anywhere in the program, but it is a useful reference datum.



ADDING PROJECT: Once a new Field is added, right-click *on that field* in the Data Tree and select “Add New Project.” This will pull up the Project Information dialogue, where name, units and other basic relevant data can be added. Geodetics can also be set from this dialogue.



NOTE: If you don’t want to set geodetics just yet, you can do it later, but you still have to go into the Geodetics dialogue and then Save and Exit in order to finish the Project Information dialogue.




ELEVATION (To Mean Sea Level) :

The current version allows only one mode of elevation, which is the structure’s elevation plus the RKB height.


Once a Project is created here, HawkEye™ will provide a default Structure/Pad, Site/Slot, dummy Well Path and First Target. The dummy surveys are placeholders waiting for the user to modify them, and will show up in the 3D space as short vertical curves by default.

Once a Project is created, HawkEye™ will provide for it a default Structure/Pad, Slot/Wellhead, Well Path and First Target.


If there was no survey then there would not be a visible component in the 3D space. This is the equivalent of what you commonly see on a data tree that has a ‘+’ to the left of a closed tree item.




ADDING STRUCTURES/PLATFORMS: To add addition Platform/Pads, simply right-click on the Project **P** in the Data Tree you want the Structure to be associated with, then select “Create New Platform/Pad For Project.”



In this dialogue, structure data (name, reference slot, elevation and convergence) and structure original coordinates can be added. To finish, click the “Create” button and the structure will appear in the Data Tree. Along with the new structure, there will be a default Slot and a default slot survey.



ADDING SLOTS/SITES: To add a new Slot/Wellhead, right-click on the Structure , then select “Add New Slot/Wellhead”.



This invokes the Slot Information dialogue, which allows the user to input the Slot/Wellhead name, and add a variety of different coordinates defining it.

The 'Create New Slot/Wellhead' dialog box contains the following fields and options:


- Name:** New Slot Name
- Elevation (ft):** 0.00
- Default RKB (ft):** 25.00
- Site Error (ft):** 3
- Create Proposal Curve:** Proposal
- Create Survey Curve:** As-Drill
- Input Coordinates:**
 - Local EW.NS** (Set as Local (0.0))
 - Local EW - US Feet: 0.00
 - Local NS - US Feet: 0.00
 - GeoDetic Grid**
 - Northing (GRID Y) - Feet: 339261.31
 - Easting (GRID X) - Feet: 1422476.52
 - Convergence: -1.65696
 - Lat-Long**
 - Latitude: 47° 54' 30.3660N"
 - Longitude: -102° 43' 36.1272W"
- Current Reference Slot/Wellhead:** Sausage 151-94-16B-21H
- Buttons:** OK, Cancel, Launch GeoHAWK

Coordinate information can be added via Latitude-Longitude, GeoDetic Grid (Grid X & Y coordinates), or Local EW NS based on the current Slot/Wellhead location.


Click “OK” to save and close out this dialogue.

b. Adding Wells and Sidetracks


ADDING A WELL: To add a well or “curve,” right-click on the associated Slot/Wellhead in the Data Tree to pull up the contextual menu, then select “Add New Well Path”.



In the “Add New Curve” dialogue, you may enter the Curve name, Job No. (new or pulled from existing Jobs already entered), Curve Type (proposal or survey), RKB, tie in point and referenced slot coordinate. The curve will appear as named under the slot you right-clicked on in the Data Tree. **NOTE:** To create a new slot, don’t create a curve and change the surface Tie-in point here. Instead, create a new Slot/Wellhead and create a new curve under that new Slot/Wellhead.

A screenshot of the “Add New Curve” dialog box. It contains the following fields and options: Curve Name: New Curve; Job No.: Sausage 151-94-16B-21H; Curve Type: PROPOSAL; Unit: Feet; VSP (0-360): 0.00; Color: Blue; RKB: 25.00; Apply RKB to all curves in the slot: checked; Tie In Point: Tie In TVD: 0.00, Tin In NS: 0.00, Tie In EW: 0.00; Referenced Slot Coordinate: Northing: 339261.31, Easting: 1422476.52. There are OK and Cancel buttons at the bottom.

ADDING A SIDETRACK: Right-click on the associated curve to pull up the contextual curve menu, then select “Add Side Track Curve”.



In the Create Side Track dialogue, you define the sidetrack curve as an entirely new curve which starts at the defined tie-in point. Additionally, you can define the sidetrack as any kind of projection before creating it, using the “Projection Type” dropdown menu.

NOTE: The most critical parameter of a sidetrack is the Tie-in Point, which is defined either by MD or TVD off the parent curve, so double-check your parent curve and those numbers before creating a new sidetrack curve.


2. EDITING CRITICAL INFO

a. Targets


1. Creating and Managing Targets

Targets in HawkEye™ have several important functions: to act as designation points for the so-called targeted projections (Slant, Aligned, BOT and Horizontal, explained in [Ch. III Projections](#)), to serve as visual aids in the 2D and 3D space as representations of , and to act as placeholders or bookmarks in an active work space.

IN 3D SPACE: Targets appear in the 3D space by way of their own parameters which define appearance, orientation and location. They do not follow curves or other structures and their specific parameters must be re-defined individually to be moved around or changed.



IN THE 2D VIEWS: The targets appear in the Vertical Section and Top Views (VS and Top tabs). Their labels can be customized in the Graphics Properties panel, which can be accessed by clicking on the top left icon  in either 2D window.



The target labels can be moved around in the 2D windows by left-clicking and dragging them.


Any target can be right-clicked on in the 2D views to pull up a quick synopsis of critical target information.

IN THE DATA TREE: Targets  can be found in the Data Tree where they are associated with a particular structure/pad or slot/wellhead. When the [New Project Wizard](#) is used to start a new project, the Wizard will create a single default target under the default slot. Otherwise, a target must be added manually. Any new target can be found in the [Data Tree](#) as well as the [Target List](#).

ADDING TARGETS: There are several ways to add a target to a project:

1.  **In the Target List:** Click on the bottom row of the list and a new target will appear. (More on the Target List later in this chapter).
2.  **In the Curve Menu:** Right-click on any curve and select “Create Target at This Point” and the target will appear at that exact point.
3.  **In the Crosshairs Menu:** Right-click on the red Crosshairs found on the Sight and select “Save as Permanent Target.” It will appear in that exact spot.

TARGET RIGHT-CLICK MENU: The target contextual menu is pulled up by right-clicking on a target name in the Data Tree or the target in the 3D space. All of the primary functions of the target can be found in this right-click menu.



- **TARGET ADJUSTER:**  This option in the right-click menu will open the TARGET ADJUSTER panel, which is the primary main screen platform for editing targets. This control panel is explained in detail in the next subsection.
- **TARGET LIST:**  This option in the right-click menu invokes the TARGET LIST, which is a comprehensive, interactive list of all targets in a project and includes the TARGET ADJUSTER PANEL. This control panel is explained in detail in one of the following subsections.
- **EDIT 3D FONT:**  This opens the Graphics Properties Manager, on the 3D Cage tab. (Here you can edit not just the target labels, but also the labels for other information and the attributes of the 3D walls).
- **HIDE:**  A target can be hidden by right-clicking on it in the 3D space and selecting “Hide.” Targets can also be hidden by unchecking the checkbox to the left of its name in the Data Tree.

- **ADD NEW HARD LINE:**  This will first prompt the user to enter a name for the new hard line, then that hard line will appear in the Data Tree. To edit the hard line coordinates, RIGHT-CLICK on the hard line in the Data Tree and select “Edit Hard Line Coordinates.” For more information on hard lines, see the section following this one.
- **ADD NEW LEASE LINE:**  This will first prompt the user to enter a name for the new lease line, then that lease line will appear in the Data Tree. To edit the lease line coordinates, RIGHT-CLICK on the lease line in the Data Tree and select “Edit Lease Line Coordinates.” For more information on lease lines, see the section following this one.
- **CLONE TARGET:**  Select this option in the right-click menu to duplicate the target and all of its parameters. The depth is automatically made 100 length units deeper than the target being cloned, so this will probably need to be changed along with the target coordinates.
- **GO TO TARGET:**  This right-click option is a navigation tool for the 3D space. It will take the Look-at Point or current point of view and center it on the selected target. This is useful for zooming around and getting spatially adjusted in the 3D space quickly.
- **SET AS THE FIRST TARGET:**  This right-click option is a critical tool in using the targeted projections. Under any Structure, there is only one designated First Target at a time. Any target can act as the First Target as long as it is designated as such. When it is set, the First Target is a designation point for the projection calculations of Slant, Aligned, BOT and Horizontal projections. If any of these projections are attempted without a First Target, HawkEye™ will prompt the user to set a First Target before continuing.
- **SET AS THE SECOND TARGET:**  This right-click menu option is used only for Aligned Projections, which may require a second registered target for certain calculations. When a Second Target is required yet not set, HawkEye™ will prompt for the designation of one.
- **DELETE TARGET:**  This option will instantly delete the target from the database. NOTE: To make a target invisible but retain it, just select “Hide” from the right-click menu or uncheck its box in the Data Tree.

HORIZONTAL TARGET RIGHT-CLICK MENU: You can create a horizontal target by clicking on the large Target icon in the main screen and selecting

“Add Target Plane.” 

Then right-click on the target plane either in the 3D space or the Data Tree. The menu is almost identical to the normal target right-click menu, except that here you can also designate the target plane as the “Horizontal Target Plane,” which is used with the Horizontal Projection.

2. Target Adjuster


The panel that appears inside of the 3D space to the right contains all of the parameters associated with a target. Its name, assigned slot, color, texture, general shape, orientation and location can all be changed through this panel.

Pull up the Target Adjuster by right-clicking on a target in the Data Tree or 3D space and selecting “Target Adjuster.”  This panel will also always appear in the TARGET LIST, which is a panel explained in a following subsection.

The top four icons in the Target Adjuster are the same options found in the right-click menu:

Set as First Target, Set as Second Target, Go to Target and Clone Target.

NAME, SHAPE, SLOT: The next three fields allow the user to edit some critical information. The “Name” field is an open field and the target can be called anything. The “Shape” drop-down menu will instantly shape the target into one of several default 2D or 3D shapes: cylinder, cube, polygon, circle, ellipse, square, circle, ellipsoid, point and other. The “Slot” drop-down menu contains all slots in a structure to choose for a target’s assignment.




TVD: A Total Vertical Depth can be entered manually, and must either be defined as a subsea or an RKB TVD.

COORDINATES: The coordinates for the target are either Local or Grid and the NS and EW values can be input manually.

MAP: The “Map” button will invoke a separate control panel in which specific, advanced location data can be entered for the target. The target “Map” panel will allow the user to control specific coordinate and mapset information. On the right is the Google Earth view by default.⁶

⁶ Google Earth is a separate program that needs to be installed on the local machine. It is free and can be found at earth.google.com.



The **magnetics icon** in the top middle will launch the Magnetics dialogue, which controls the magnetics adjustment data for the entire project. This can also be launched from the main screen through the same icon at the top.

Group, System Zone and Datum are displayed, but not editable. These can only be changed at the Project level, through the Geodetics dialogue.

Current Slot Reference: allows the retrieval of a project's coordinates; this can only be changed at the Slot level by selecting the desired slot, and then right-clicking and selecting the Set as Reference option.


Launch GE: This launches a separate instance of Google Earth loaded with the current coordinates. If the Google Earth program is already running separately, this button will send the program the current geodetic information.

Coordinates can be entered either by Grid coordinates or Lat/Long coordinates. Select the option first and enter the values.










At the bottom, several more parameters are displayed which are relevant to the grid system being utilized. They are not editable. Below, a brief description of what each parameter is.











- **Convergence:** The angle of difference in degrees between grid north and true north. This is measured from True North to Grid North.
- **Scale Factor:** The error associated with the map projection as a result of approximating the surface of the earth as a plane instead of the curved surface it actually is.
- **Projection Type:** This is the type of mathematical projection system used. Nearly all systems utilized are either Lambert or Transverse Mercator. Many projections systems are used in cartography, but most legal systems around the world involve at least a variation of one of the two mentioned systems.
- **Earth Radius:** This is the radius from the earth’s equator to the center of the earth.
- **Flattening:** This is a mathematical constant representing the amount of flattening the earth has as a result of its rotation. The earth is not completely spherical mostly because of the fact that at the equator it is moving 1000 miles an hour and the centrifugal force causes the earth to bulge at the equator.

The remaining parameters in the Target Adjuster can be changed by the drop-down menu arrows in increments of 1, or values may be manually entered to any specificity unless otherwise noted. Length units are either in feet or meters, depending on which unit is chosen for the project.



CL-DIR: Direction from the surface location to the Target center	
CLOSURE: Horizontal distance from the surface location to the target center	
DIAMETER: Controls the total width of the circular ends (of cylinders only).	
ROTATION (THICKNESS): This parameter does not apply to any shapes, but in its place “Thickness” appears when a hardline or leaseline is selected.	

<p>THICKNESS: This controls the amount of vertical space which the target occupies. (Not applicable to 2D shapes.)</p>		
<p>SIDE A AND B: These two parameters control the length of the default x-axis and y-axis sides of a non-circular shape. (Side B is not applicable to 2D shapes.)</p>		
<p>DIP/DIRECTION: This controls the degrees in which the target is turned from its geometric center (i.e. its azimuth). Pictured is 0 and 45 degrees, with the target rotating clockwise.</p>		
<p>DIP/INCLINATION: This controls the degree of tilt that the target shape assumes. Pictured is 0 and 45 degrees, with the top of the target tipping to the left.</p>		
<p>DIR. OFFSET: This controls the directional offset of the target, which is the distance along the hole, up or down. Pictured is 0 and -200, where the target appears to drop in elevation.</p>		

<p>X OFFSET: This value, in units of length, displaces the target off of its defined location on the X-axis. Pictured is the Top View and an X Offset of 300.</p>		
<p>Y OFFSET: This value, in units of length, displaces the target off of its defined location on the Y-axis. Pictured is the Top View and an Y Offset of 300.</p>		
<p>OPACITY: This controls the translucency factor of the target, ranging from 5-100.</p>		
<p>COLOR: Although the entire palette of colors is available for targets, there may be discoloration depending on the underlying texture chosen for that target.</p>		
<p>TEXTURE: A wide variety of default textures are available for the targets. In addition, user textures can be selected from the file explorer on the top left of the dialogue.</p>		


3. Target List



The Target List is the comprehensive control center for all targets associated under a slot or structure. It includes the Target Adjuster within it.

<input type="checkbox"/> Check All	Target Name	Target Shape	RKB TVD	Subsea TVD	N-S Coordinate	E-W Coordinate	Closure Direction	Closure Distance	INC From Last Target	AZM From Last Target	Slot	Visible
<input type="checkbox"/>	Target 2	SQUARE	5004.00	2804.00	464.00	112.00	13.5704	477.33	0.0000	0.0000	Sausage 15...	<input checked="" type="checkbox"/>
<input type="checkbox"/>	Target 1	CYLINDER	10693.06	8493.06	-7730.36	1830.95	166.6750	7944.24	55.8048	168.1528	Sausage 15...	<input checked="" type="checkbox"/>
<input type="checkbox"/>	Target 3	SQUARE	81354.00	79154.00	1521.00	1122.00	36.4152	1890.06	7.4807	355.6179	Sausage 15...	<input checked="" type="checkbox"/>
<input type="checkbox"/>									178.6321	216.4152		<input type="checkbox"/>

OPEN THE TARGET LIST: Access the Target List by right-clicking on a target in either the Data Tree or the 3D space, then selecting “Target List.” Regardless of the target clicked on, the Target List will display data on an entire slot or entire structure’s target array.



You can also launch it by clicking on the Target List icon under the Home tab.

TARGETS ON: Choose either “Current Slot” or “Current Structure” to select the range of targets to be displayed in the list below.

SORT BY: Organize all displayed targets by either “TVD” or “Closure Distance.”

SHOW TARGET ARRAY: This toggle will turn on the “Target Array” fields, which allow the user to select any sequence of targets for multiple-target projection setups. Such a setup can only be taken advantage of in the HawkEye™ Command interface. See the section on HawkEye™ Command (Ch. IV. Section 4) for more details.

PARAMETERS: Targets are defined in the List across 11 parameters, each of which can be changed in this panel. The order of the columns is not changeable.

Target Name	Target Shape	TVD ▲	N-S Coordinate	E-W Coordinate	Closure Direction	Closure Distance	INC From Last Target	AZM From Last Target	Slot	Visible
-------------	--------------	-------	----------------	----------------	-------------------	------------------	----------------------	----------------------	------	---------

TARGET ADJUSTER: The Target List contains the [Target Adjuster](#) within it. As described in the previous sub-section, simply click on the name of the target in the list and its specifics will appear in the Target Adjuster panel above, where they can be changed.

4. Target Array


The Target Array is used only in a specific projection sequence in which a number of targets are hit with a series of tie-ins that are created simultaneously in the Proposal mode.

b. Target Planes



Although the Horizontal Projection will generate a target plane when you activate the projection, you can also generate a target plane from scratch.


Do this by clicking on the Target Selector icon (large red and yellow target icon in the main screen) and selecting “Add Target Plane.” This will bring up a Target Adjuster dialogue where you can define the size, dip and direction of the target plane. The default target plane is going to be at 3500 TVD and 0,0 local. To change the parameters, right-click on the target plane in the Data Tree or 3D space and select “Adjust Target Plane.”



To use a custom made target plane as the horizontal projection target, right-click on your target plane either in the 3D space or the Data Tree and select “Set as Horizontal Target Plane.”


The target plane created here is defined as through the parameters in the Target Plane Adjuster dialogue. It will take on the texture that is found at that TVD from the lithology of the structure or slot with which it is associated.

CREATE A TARGET ON THE TARGET PLANE: You can create a target directly centered on the plane by grabbing the blue “handle” that is located at the center of every target plane. Simply drag the blue handle to the place on the plane where you would like the target to be generated, then right-click on the handle and select “Save As Permanent Target.”



To get the exact location you want before making this target, check your Handle Coordinates which appear when you drag the handle around. The Handle Coordinates are located on the top right inside the 3D window.

When a new target is created, the blue handle resets to the middle of the target plane for future service.



3. EDITING NON-CRITICAL INFO

a. Importing Lease/Hard Lines

Hard lines are boundaries beyond which one does not wish to drill, a no-go zone. Lease lines are legal boundaries that often have to be visually incorporated into a well plan to illustrate how far the well is from the lease line or its offset line. For all practical purposes, HawkEye™ treats the creation of both lines almost identically for most practical purposes.


TWO WAYS TO CREATE LEASE/HARD LINES:

- 1. IMPORT THE SPREADSHEET OR TEXT:** Lease line boundaries can be very complex. The data for building them normally comes from data a survey company the operator has utilized to specify the surface location of a well. If you can obtain a spreadsheet with the coordinates of the points specified in any one of several styles, you can cut and paste the data into the spreadsheet editor used to input hard/lease line data. **This is by far the easiest and best way to input this kind of data because it is very quick and it reduces the likelihood of input errors** that can be confounding with a long list of lease line coordinates.
- 2. COPY-PASTE THE SPREADSHEET OR TEXT:** The other way is to copy-paste from a delimited text file that has the data arranged in lines with the values separated by commas, tabs, or spaces. This process involves more steps than the first method but has the advantage of reducing input errors, same as the first method.

The first step is to copy the data from the spreadsheet or text. The data usually comes in one of several common formats: Local Coordinates, Grid Coordinates, Direction-Distance or DMS-Distance.

Once the data is copied, create a new hard/lease line in HawkEye. Do this by just right-clicking in the **Data Tree** on either the **Project**  or the **Structure**  under which the line is to be associated. Then select one of the two options at the bottom of the right-click menu.

This will open up the Lease Line or Hard Line editor. Right-click in the table section on the bottom half of the




editor and you will be given a number of choices on how to paste the data. **NOTE: How you paste the data here needs to match how the data was oriented in the original spreadsheet or text file.**

The first seven options when pasting in hard/lease line data are composed of two columns. The last option, DMS-Distance, is a five-column format. Choose the method of pasting and the data will import and get calculated. Each of the numbers are editable once entered in this fashion.




ADJUST THE LINE: There are two aspects to any hard/lease line: its coordinates and its 3D display properties. To edit a hard/lease line's coordinates, right-click on the line in the Data Tree and be sure to select the "Edit Hard Line Coordinates" option.



If you want to edit the way the line will be displayed in the 3D space, such as editing thickness of the line, then select "Adjust Hard Line Parameters," which will open up a Target Adjuster box for that line.

SEE THE LINE IN 3D: To see the lease/hard line in the 3D space as more than just 2D lines, click on "View" at the top of the screen, go to Hard/Lease Lines, and check the "Show 3D Object" box. If this box is not selected, then any parameter changes in the line's target adjuster won't show up as a 3D object in the 3D space. You can also toggle this 3D display box in the Lease Line or Hard Line Editor.




DIY: If you do not have access to a spreadsheet or text file with the data and you have a lot of points, you can create one by the old fashion way, by doing it yourself. Maintaining data in one of those forms makes it much easier to edit. However, if you

only have a few points to enter, then using HawkEye’s editor to input the values is not a problem.

The following screenshot shows the Lease Line Editor open, and the lease line displayed in the 2D space with a 500 ft internal offset represented by the dotted line.

Note that there are four different Input Modes, which are also the coordinate display modes:


- Local Coordinates
- Grid Coordinates
- Direction-Distance and
- DMS (Degrees, Minutes, Seconds) – Distance.



Next to the Input Mode box is the Boundary offset box. Internal and external offsets can be set by entering the distance and then selecting the radio button for what you want (Inner or Outer). HawkEye™ will calculate the line and display it. The ‘Close Line’ option is for when the last point is automatically set to the first point, so that a closed lease line can be more easily input. The 3D View box has options on how to display the line in the 3D space.

In the example shown the data was automatically generated by HawkEye™ from a PLSS Township, Range, Section definition. To enter data manually it is usually best to count the number of points you will be entering and the use the “Add Point” button that many times, creating a blank spreadsheet in the Editor that has all the space you will

need. Next, decide what Input Mode you will be using. If it is Local Coordinates, Grid Coordinates or Longitude, Latitude coordinates all you need do is enter each pair of coordinates, either line by line or by going down each column and entering all the EW coordinates, for example, and then proceeding to the next column and filling in all the NS coordinates.



ANCHOR POINT: If you are inputting coordinates in Direction-Distance, the most important thing to remember is to **FIRST**, input the starting Xpoint, Ypoint. This is the “anchor” point, and is labeled line “0” in the coordinates table. From that point on you will only need to enter the direction and the distance.

MOSTLY THE SAME: Mostly everything that is true for Lease Lines is true for Hard Lines. With Hard Lines you can also have offsets if you so desire.

MULTIPLE HARD LINE PASTING: However, with the spreadsheet cut and paste option with Hard Lines, there is an option you are presented with when pasting the data to the grid which **allows a list of independent hard lines to be added simultaneously**. In this mode, each successive pair of points constitutes a single line. HawkEye™ will automatically generate a Hard Line definition for each pair of points. You can then edit them independently for color, names and offsets by editing their target parameters if you so choose. When you paste in the data, HawkEye™ will prompt you for this option.


b. Comments and Annotations

1. COMMENTS


ADD COMMENTS: Comments are generated in HawkEye at any given survey, either in the Work Mode or Proposal Mode. They can be entered manually at the survey by typing in the comment in the List Panel below in the space for comments.




AUTO-GENERATE COMMENTS: Comments may be generated automatically for proposal curves by right-clicking on the desired curve for comment in the Data Tree, and selecting “Auto Comments For This Curve.” This will create a comment at each critical point in the proposal (e.g. KOP, Begin Build, Begin Turn, PBHL). You cannot generate auto-comments for a work curve since each survey would be considered a critical point due to its irregular, non-geometrical nature.



When a comment is created, it will appear in the 3D space at the point on the curve on which it was created, marked by a green sphere.




DELETE A COMMENT: To delete a comment, erase the text from the Survey List Panel at the bottom of the main screen (the field in black as pictured above). Or to delete ALL the comments of a curve, go into the curve’s menu and select “Clear Comments.”





2. ANNOTATIONS

Annotations are slightly different from comments in that they can only be generated manually. In other words, there is no way to auto-generate annotations. Think of them as personalized notes outside the bounds of what is to be included in a plot or report.


ADD ANNOTATION: To add an annotation to a curve, go to that curve's menu and select "Add Annotation."



The Enter Annotation box has a number of options, including choosing the exact depth and type of depth at which the annotation will appear along the curve, as well as the font and color of the annotation.



DELETE AN ANNOTATION: The only way to delete an annotation is to right-click on the blue sphere where it resides on the curve, then select "Delete."



NOTE: Sometimes it is tricky to get the right-click menu to come up for the annotation, and may require adjusting the point of view and zoom in order to nail the sweet spot on the blue sphere.

III. PROJECTIONS

TWO MODES: There are two overall modes in HawkEye. The Field Mode is default and available in both versions. It is used for directional drillers who are not creating much in the way of complex proposals or well plans. Whereas the Well Planning Mode, available only in the eponymous version, is used to create complex well plans.

VERSION OF HAWKEYE	MODES AVAILABLE	
	Field	Well Planning
Field Version		
Well Planning Version		

1. WHAT YOU NEED TO KNOW

HawkEye’s Field Mode offers nine types of projections that can be used by directional drillers as well as well planners. They are:

- Bit (Compound)
- Measured Depth (Straight Line)
- Total Vertical Depth (Straight Line)
- Nudge
- Multi-Nudge
- Horizontal
- Slant
- Aligned
- Back on Track (BOT)

MODES: FIELD v. WELL PLANNING

The main difference to keep in mind between the Field Mode and Well Planning Mode is that, although they both have the same arsenal of projections which can be appended end to end, only in the Well Planning Mode can a projection be edited at any segment and have the rest of the curve recalculate.

In other words, in the Field Mode, only the last appended projection can be edited, so that in order to edit a part further up the curve, the user must delete all appended parts of the curve made subsequent to that higher up part before editing it. In the Well Planning Mode, all parts of the curve are editable at all times.

Each of these projections can be quickly generated and edited from the main screen by clicking on the corresponding icon:



These can be broken down into two broad categories of projections. The “Targetless” projections can be created from any point on a curve without having to select a target. “Targeted” projections, on the other hand, require a target toward which a projection is created.

TWO GENERAL FAMILIES OF PROJECTIONS

TARGETLESS PROJECTIONS:

- **MD & TVD Projections-** Hold a particular inclination and azimuth and go in a straight path for a certain user-defined distance.
- **Nudge and Multi-Nudge Projections-** Mimics minimum curvature calculations but allows for the nudging of a variety of different parameters.
- **Bit or Compound Projections-** Allows a projection to be strung to a bit from where your survey position is. From there you can append other kinds of projections to the end.


TARGETED PROJECTIONS:

- **Slant Projections-** a.k.a. DLS projections, Build-and-Hold Projections. Can solve for a hold angle by providing a dogleg severity or solve for dogleg severity by providing a hold angle.
- **Aligned Projections-** Set two dogleg severities, as well as desired inclination and azimuth at target.
- **Back-on-Track (BOT) Projections-** Set two dogleg severities and a minimum distance in order to intersect your proposal.
- **Horizontal Projection-** Will project to a horizontal plane, which is considered a 2D target. Horizontal plane is defined by an RKBTVD, a max dip angle and a max dip direction.

a. Work Mode vs. Proposal Mode




The most important thing to understand when in HawkEye's 3D space is that there are two modes for building and navigating between your curves: the Work Mode and the Proposal Mode. You can toggle between the two modes by clicking the corresponding cursor icon just below the 3D window:




WORK MODE: The primary difference between the two modes is that the Work Mode will allow you to follow along the currently selected Work Curve.⁷ Also, when you make a projection, it is automatically starts from the end of the work curve, but will not stay there unless you append it. See more on appending projections to your curve in the following section.

On the right we see our Work Curve (Survey Curve) in red, and a slant projection made from the Projection Panel in light green. When this projection is made, we can slide along and look at all the *projected* surveys to see what kind of DLS or inclination we need to hit. But the green projection is not part of the workcurve. And it is replaced by the very next projection we make.



⁷ Set any survey curve in your Data Tree as the "Work Curve" by right-clicking on it and selecting "Set as Work Curve."

The very next thing we did was make a Quija projection from the panel. Just like all projections, it starts from the end of our Work Curve in red. But it replaced our previous projection. We can travel along this new projection to explore its parameters, but it, too, will be replaced by the next projection we make.



The idea is for the driller to be able to make short-term predictions from where the well is already drilled.

PROPOSAL MODE: In the Proposal Mode, you are able to follow the Proposal Curve.⁸ **When you make projections in the Field Mode, your new one will replace whatever you have in place previously.**

There are exceptions to this, however. You can build up proposal curves projection by projection with the following two methods: 1) **Append to Curve**- after a projection has been generated, click on the “Append” button at the right-hand end of the row of projections, 2) **HawkEye Command**- type in a direct alphanumeric command that instantly generates and appends the projection (see last section of this chapter).

NO BIT PROJECTION IN PROPOSAL MODE: You will notice that the Bit Projection (Bit to Sensor Projection) is not available in the Proposal Mode. The icon is simply not displayed while in Proposal Mode.

This is because the Bit Projection is assumed to only be used with the Work Curve. It adds a certain length of measured depth at the end of any projection in order to simulate the course length to the bit not yet reached by the sensor.

⁸ Set any proposal curve in your Data Tree as the “Proposal Curve” by right-clicking on it and selecting “Set as Proposal Curve.”

2. PROJECTIONS IN FIELD MODE

APPEND TO BUILD: It is worth repeating here that you can append each of these projections permanently to the end of either your Work Curve or Proposal Curve by using the Append button, described in the preceding section.

a. Bit Projection




NOTE: BIT projections are only available in the Work Mode. You cannot access the BIT projection in the Proposal Mode at all. As the name implies, the Bit projection will make a projection to the bit. It can be created in two

ways:

1. Straight line projection
2. Nudge projection (w/ DLS and TFO)

APPENDING/COMPOUNDING PROJECTIONS: The Bit projection works with most of the other projections by being able to be appended to. This allows for a projection past the estimated current bit location. It works by 1) opening the Bit projection dialogue and creating the initial Bit projection, 2) opening the dialogue for the secondary projection (take your pick).



Bit projections can be made as straight line or nudge-style projections.

Open the Bit Projection panel to make an initial projection then open another projection panel to append to the Bit Projection. Make corrections on the fly on either panel to nudge the compound projection into place.

b. MD & TVD Projections



Measured Depth and Total Vertical Depth projections are of the simplest kind of projections available. They simply add a straight

extension for a given distance, holding for the existing inclination and azimuth.

The only difference between the two projections is the type of depth measurement used, with either measured depth or total vertical depth. The mechanics of the projection calculations are identical.

To make the projection, just enter an Added Depth to add how much from the endpoint you wish to progress in a straight line. OR put in a Total depth value and HawkEye™ will figure out how much added is required.

Clicking “Turn On Projection” will trigger the calculations and activate the projection in the 3D space.

Press the TAB button after entering a value to get HawkEye™ to recalculate a parameter.

MD PROJECTION	
<input type="checkbox"/> Turn On Projection	
ADDED MD	1500.00
TOTAL MD	1600.00
Color	

TVD PROJECTION	
<input type="checkbox"/> Turn On Projection	
ADDED TVD	100.00
TOTAL TVD	200.00
Color	

MD and TVD projections simply add a certain amount of straight distance from a point, holding the existing inclination and azimuth.

c. Nudge Projection




The Nudge projection is the best way to nudge a curve and may be the first kind of projection used when setting about to making a proposal curve. It is also useful for predicting how the motor and rotary steering system will behave by setting up the known parameters. Seeing this projection rendered in 3D space helps to visualize a job with the information already in hand.



Driller's View: Since the Nudge projection is targetless and relatively hands on, you will want to get started in the right place. The right place to get started is in the Driller's View. This view mode will put you at the end of the current work curve with Highside up.

Once Driller's View is set and Sights toggled off, you can select the Nudge tool from the row of projections and open up the dialogue. There are three solve modes, each allowing for the entry of up to three parameters at a time out of six: DogLeg Severity, Tool Face Orientation, Delta (change) Measured Depth, Inclination, Azimuth and Total Vertical Depth.



The Nudge projection interface allows for maximum manual manipulation of a curve. The task is divided into three distinct solve modes.

d. Multi-Nudge Projection



The Multi-Nudge allows the user to string together an infinite number of Nudge projections. These nudge “segments” can be one of four solve modes:

- **INC/AZM/DLS:** Where Inclination, Azimuth and Dogleg Severity are defined.
- **DMD/DLS/TFO:** Where Delta Measured Depth, Dogleg Severity and Toolface are defined.
- **DMD:** A straightline segment that holds for a defined Delta Measured Depth
- **HOLDTODMD:** Another straightline segment that holds until an MD is reached

You can create a new segment by simply selecting the solve mode in the bottom line of the first column. In the screenshot below, all four types of segments have been created and a fifth segment is on the verge of being created.

The screenshot shows a software window titled "MULTI-NUDGE PROJECTION" with a "Turn On Projection" checkbox. Below the title bar are tabs for "Option1" through "Option8". A table displays the configuration for each option, with columns for Projection, DMD, INC, AZM, DLS, TFO, and MD. The rows are color-coded: Option1 (Green), Option2 (Red), Option3 (Blue), Option4 (Green), and Option5 (Blue). A dropdown menu is open for Option5, showing the four projection modes: INC/AZM/DLS, DMD/DLS/TFO, DMD, and HOLDTODMD.

Option	Projection	DMD	INC	AZM	DLS	TFO	MD
Option1	INC/AZM/DLS	0.00	0.0	0.0	0.00	0.0	0.00
Option2	DMD/DLS/TFO	0.00	0.0	0.0	0.00	0.0	0.00
Option3	DMD	0.00	0.0	0.0	0.00	0.0	0.00
Option4	HOLDTODMD	0.00	0.0	0.0	0.00	0.0	0.00
Option5	▶*	0.00	0.0	0.0	0.00	0.0	0.00

The segment colors always alternate Green, Red, Blue, and repeat after that. The cells in white are editable, while the colored cells are calculated for you.

The “Option” tabs at the top allow users to create up to eight templates, so they don’t have to rebuild a particular array of nudge segments over and over.


e. Horizontal Projection




Although Horizontal projections are “targeted projections,” they require horizontal target planes rather than the normal targets to be set as the anchored tangential object.

The three parameters describing the horizontal plane itself are:

1. The RKB TVD, which is the depth below the surface location all the way to the point of intersection with the plane.
2. The Max Dip, which has a positive value for leaning toward the observer and a negative value for leaning away from the observer. NOTE: The quickest way to understand this value is to change it a few times and look at the difference in HawkEye’s 3D space.



3. The Max Dip Direction is defined in 360 degrees counting clockwise. Visualize looking from the top down on a well and simply define the direction as one would an azimuth. The formation would thus lean into that direction.



Horizontal Projection ✕

Turn On Projection

RKB TVD	3000
Max Dip	0
Max Dip Dir.	0


User defined Strike Inc
 User defined Strike Azm

Strike Inc	90
Strike Azm	30
Extension	0
DLS (NBR)	5.73

Color
Make Target Plane


Horizontal projections are a more hands-on projection requiring several user-generated parameters, calculated by defining a horizontal plane.

CREATE A TARGET PLANE: To set a horizontal plane, RIGHT-CLICK on a straight (tangent) section of a curve, then select “Create Target Plane.” A two-dimensional target plane will appear in the 3D space along the tangent. Now RIGHT-CLICK on the target plane itself and select “Set as Horizontal Target Plane.”





NOTE: It always helps to put an extension (tangent) on a horizontal projection (just add some length in the Extension field in the panel). This elongates the projection and allows for better visualization of where the projection and the attendant target plane will be situated. Also note that the texture of the plane itself reflects the data entered in the LITHOLOGY panel.

NOTE: When creating a target plane, it will be generated from zero closure towards the active direction in which the projection is made. So if you then take the projection 180 degrees in the other way, there won't be any target plane in that direction.




To extend the target plane in the other direction, just repeat the process of selecting the curve, RIGHT-CLICKING on it, and select “Make Target Plane.” This will extend the target plane in your new direction and link up with the first one.





Horizontal projections will allow the user to enter either the strike azimuth or the strike inclination.

BORE DOWN JUST UNDER THE FORMATION: The Horizontal projection panel will only allow for the change of either strike inclination or strike azimuth at any one time. But they can be modified in succession. To get the projection to get right under the formation and cruise along underneath, simply determine the proper strike azimuth, then enter a user-defined Strike Inclination of anything a little over 90 (because a 90 degree strike inclination will put the projection directly on the formation plane).



Entering a Strike Azimuth of 93 can put the projection just under the formation, yet not deviate too far down away from the plane.

NOTE: Although you cannot define the DLS in this mode, it is the all-important number to keep an eye on after every parameter change and is thus highlighted in green.

f. Slant Projection




Unlike the Back-on-Track projections, the Slant projections (a.k.a. “Build and Hold” projections, “DLS” projections) do not take the proposal curve into consideration. You give it either a Hold Angle or a DLS to shoot for and it will create the smoothest possible curve to the target.


To create the Slant projection, RIGHT-CLICK on a target and select “Set as First Target,” then open up the Slant projection dialogue. You can either choose a DLS or a Hold Angle, allowing HawkEye™ to solve for the other. Then click “Auto Calculate.”

Clicking “Turn On Projection” will trigger the calculations and activate the projection in the 3D space. You can also hit the TAB button after entering a value to get HawkEye™ to recalculate a parameter.

Since the job may not always call for being exactly on the proposal line, the Slant projection might be a favorable option for planning a smooth and easy path with minimal dogleg severity and maximum straightaway distances.



Select a target and set it as “First Target,” then use a Slant projection to get a smooth curve to that target, ignoring any proposal curve.




The Slant projection here (in green on the left) took a user-defined hold angle of 41.24 and came up with a 2.44 DLS to get the easiest ride to the target, outside of the proposal.

g. Aligned Projection




The most powerful and complicated of the projections, the Aligned projection requires user input for both dogleg severities and the desired inclination and azimuth at the first target.

HIT CALCULATE: After any change in parameters, the "Calculate" button must be pushed. This is in order to cut down on unnecessary and unwanted rendering of calculations:




The following examples illustrate the basic functions of the Aligned projection panel. However, the full potential of this tool, like all the rest of the projections can only be discovered by tweaking and experimenting with the parameters to see how they behave.

The VS view (VS tab in the main screen) is used to illustrate this projection.



The Aligned projection panel is the most powerful of them all. Skewer two targets.



1. At the start, there are two targets, with a proposal curve going through each.



Aligned Projection ✖

Calculate

Turn On Projection

DLS1	2	
DLS2	2	
Inc @ Target	0	
Azm @ Target	0	

Set DLS1 = DLS2

2. Here's a DLS of 2 for both turns (arrows), and 0 for inclination and azimuth at target for a vertical orientation. The projection goes to the first target. Make sure to set first target in the target's right-click menu.



Aligned Projection ✖

Calculate

Turn On Projection

DLS1	2	
DLS2	2	
Inc @ Target	0	
Azm @ Target	0	

Set DLS1 = DLS2

Tangent	0.00	
---------	------	--

Line up to hit 2nd Target


Extend Before	500	
Extend After	1000	

Extend to 2nd Target

Color

3. Putting in an Extension Before of 500 makes a straight line for 500 feet BEFORE hitting the target, thus the second turn (big arrow) comes earlier. With a 1000 for Extend After, the projection will go straight for 1000 feet after the target.


USE VECTOR TO SECOND TARGET: The Aligned projection tool can line up to hit two targets with relative ease. To get the aligned projection to line up in anticipation for a second target, the first step is to go to the DATA TREE, then RIGHT-CLICK on a target and select “Set as Second Target.”



1. It might take a long time to manually nudge this projection directly into the second target at the bottom.

■ Line up to hit 2nd Target

2. Check “Line up to hit 2nd Target” in order to get the curve lined up for Target 2.



3. Then hit CALCULATE and the projection will do the work of hitting both targets.

4. Add an Extend Before length and the final turn will come earlier (big arrow, 500 ft before the first target), while the Extend After will be a straightaway. >>>>>>>

Extend Before




h. Back-on-Track (BOT) Projection



Back-on-Track projections will create a curve that will try to realign itself with the current Proposal Curve within two turns equal or as close to the DLS provided, within the minimum distance given.

The program will increase the DLS values as necessary when calculating the minimum curvature to get back on track.



BOT Projection ✖

Turn On Projection

Fixed Dynamic

BOT To Way Point


Set DLS1 = DLS2

DLS1	0
DLS2	0
Min Dist.	1400.00
Tangent	0

Color

BOT projections require two dogleg values and a minimum distance in


Clicking “Turn On Projection” will trigger the calculations and activate the projection in the 3D space. You can also hit the TAB button after entering a value to recalculate a parameter.




Fixed vs. Dynamic: The Fixed option will solve for a solution back to plan based on your DLS values. The Dynamic option will solve based on wherever your Look-At Point is on the current Proposal Curve (the program needs to switch to Proposal Mode in order to do this).

Back On Track to Way Point: Checking the “BOT to Way Point” will turn on a projection that ends at the current Way Point position, while using the two DLS values and minimum distance that you have provided.

Set the Way Point position by going into Proposal Mode and moving the red Crosshairs to the position where you want it, then right-clicking on the red crosshairs and selecting “Move Way Point to Here.”



Once the blue Way Point has been set, turn on the BOT projection with the “Back On Track To Way Point” box selected and the projection will go to the Way Point rather than back into the Proposal Curve.




Set DLS1=DLS2: This forces the solution to have the same DLS on both turns back onto plan.

3. Other Projection Tools

a. The Sight




The Sight is a critical part of the 3D window in HawkEye™, a visual aid that follows the user's Point of View or "Look-at Point" along a curve. It is highly customizable and can also quickly be toggled on and off.




The Sight is an integral part of the 3D space in HawkEye™, allowing for on-the-fly proximity visualization as well as precision POV recognition.

TWO SIGHTS: There are two Sights in HawkEye™. One is associated with the Work Curve and the other with the Proposal Curve. Each may be toggled on or off with their own Sight icon next to the respective Curve Mode icon just below the 3D window. Each of the Sights is only visible in their own mode, and each retains their own customization settings (e.g. diameter, colors). A Sight may be toggled off also by right-clicking on it and selecting "Hide This Sight." Or by pressing the Spacebar when the mouse cursor is hovering in the 3D window.

SIGHT EDITOR: Either Sight can be edited by RIGHT-CLICKING on the icon, or RIGHT-CLICKING on the 3D space and selecting "Sight Editor." The Sight Editor allows for the customization of every aspect of the current Sight and changes are automatically saved.





The Sight Editor controls all of the appearance options of the Sights for both the Work and Proposal curves. The parameters are:


- **Curve Type-** Choose either the Work or Proposal Curve Sight to edit.
- **Style-** Choose either contiguous circles or a quartered stagger.
- **Background-** Choose from a combination of either two colors, two textures or one of each. The colors to choose from run the entire visible spectrum, and there are about 100 default textures to choose from. But the user may provide a custom texture by choosing the folder location when prompted.
- **Text Back Color-** Choose the background color of the numbers on the Sight.
- **Size-** This feature defines actual size of the Sight and dictates the distances defined by the numbers on Sight itself.
- **Mag->Highside-** This drop-down menu ranges from 0.0 to 5.0 in .5 intervals and defines the inclination the user wants to switch from Magnetic Tool Face to Gravity Tool Face. When the inclination exceeds this value the sight will be oriented so that the top is at Tool Face 0. When the inclination is less than or equal to this value the top of the sight will be pointed due north.

Click “OK” to save all changes to the Sight.


THE DIRECTIONAL COMPASS: The floating Directional Compass can be turned on and off through the Sight Maker options dialogue. When turned on, it is a compass that follows the Look-At Point to constantly show either True North or Grid North, depending on the current project's settings.

The Directional Compass will always be the size of the Sight, and will always be oriented horizontally.

It can be toggled by pressing the “,” (comma) key while the mouse cursor is hovering over the 3D space.



b. Projection to the Crosshairs




The crosshairs can be used in the projection mode to act as a First Target for targeted projections. In order to have the Crosshairs active on the screen, HawkEye™ needs to be in Proposal Curve Mode with the Sight turned on. Switch to Proposal Curve Mode by clicking on the yellow “W” cursor below the 3D window. If the icon displays “P” then you are in Proposal Mode. Toggle the Proposal Sight on by clicking on the “Plan Sight” checkbox next to the “P” cursor.

COLOR: The Crosshairs is always red, and is always sized along with the diameter of the curve.

MOVE THE CROSSHAIRS: The Crosshairs appears by default in the center of the Sight, hugging the active curve. To place it anywhere on the Sight, just left-click and drag it to the area, then drop it. Right-click on it and select “Put in Center” to re-center.


SET AS A TARGET: Pull up the Crosshairs contextual menu by right-clicking on it.

When The Crosshairs object is set as First Target (or Second), it becomes a target for projection purposes only and is not a listed target that can be found in the Target List or Data Tree.




PROJECT TO CROSSHAIRS TARGET: Once the Crosshairs are set as a target through the right-click menu (see above), any targeted projection (Slant or Aligned) can be made to the Crosshairs. **The projection will be redrawn constantly as you move the Sight up and down your reference curve.**

Right-click on the new curve and select “Set as new proposal” to create a new curve which goes to that current point.



c. Target at the Crosshairs

SAVE AS PERMANENT TARGET: Right-click on the Crosshairs and select “Save as Permanent Target.” A name prompt will appear and then the target will have been created at the exact current location of the Crosshairs. In this fashion, the Crosshairs can act as a Johnny Appleseed of targets, making it easy to drop simple targets near a proposal curve without having to input coordinates or offsets.



Select “Save as Permanent Target” from the Crosshairs right-click menu and a target will be generated in that very spot.

ALSO NOTE ANOTHER WAY TO GENERATE TARGETS QUICKLY


Select “Create Target at This Point...” from the CURVE right-click menu and a target will be generated in the exact look-at point.

These targets, like any real target, can be found in the Data Tree and Target List. They are associated with the slot under which the current proposal curve is located.


d. The Waypoint Target

A quick-use target can be set anywhere on the Sight in order to quickly drop in an intermediary target for projection purposes. This target, called the Waypoint, is set by right-clicking on the red Crosshairs and selecting “Move Way Point To Here.”

The Waypoint will appear as a blue object in the 3D space.




It will also appear as a target in the Data Tree under the name “WP*”. It may be deleted via the Data Tree right-click menu, or if it is repositioned through the Crosshair menu, it will simply exist in a new location.




NOTE: There is only one Waypoint in the 3D space at any given time.


PLACING THE WAYPOINT: As mentioned above, to place the Waypoint, just move the red Crosshairs anywhere on the Sight, right-click on the Crosshairs and select “Move Way Point To Here.” The blue Waypoint will appear exactly where the Crosshairs is located. Even if the Sight is moved away, the Waypoint will remain in the original placement location.



PROJECTING TO THE WAYPOINT: To actually use the Waypoint, first place it, then simply right-click on it and “Set as First (or Second) Target.” The targeted projections will treat it like a designated target in this fashion, and it can act as a quick way to make a sort of anchor between locations.




SET AS NEW PROPOSAL: Just as with regular targets, if a projection is made to a Waypoint and then that projection is made into a “proposal curve,” the curve will remain there even if the Waypoint is deleted or repositioned somewhere else.



e. Interpolation

1. Interpolating Lithology, Casing and Targets via Survey Report


The [survey report is covered in detail elsewhere](#) in this documentation, but it is worth mentioning here that interpolation of Lithology, Casing and Target points can be implemented 'on-the-fly' in the survey reports. A small icon is placed next to each comment, indicating the type of comment. The snapshot below shows a section of the report screen. The box labeled Interpolation Options shows the choices available for interpolation. The survey report itself shows the icons and how they are displayed in the report:



2. Interpolating an Entire Curve from Critical Points

The Interpolated Report can be used to generate an entire curve from just a few critical points. Just follow these steps:

1. Enter the critical points as surveys into a new or existing curve.
2. Go to Report Generator and select “Interpolate Survey” as the report type.
3. Define the increments of interpolation you want for the curve.
4. Click the “Keep Curve” button. NOTE: This will save over all existing surveys of the current curve in the Report Generator.



The screenshot shows a software interface for generating reports. At the top, there is a dropdown menu for 'Paper Size' set to 'Letter'. Below this is a section titled 'Report Type' with several radio button options: 'Survey', 'Projection Only', 'Critical Points', 'Interpolate Survey', 'Criticality', and 'Anti-Collision'. The 'Interpolate Survey' option is selected, indicated by a filled radio button. To the right of this option is a button labeled 'Keep Curve'. Below the radio buttons, there are two input fields: 'Straight: 100 ft.' and 'Curve: 100 ft.'. A red rectangular box highlights the 'Interpolate Survey' radio button, the 'Keep Curve' button, and the two input fields.

IV. REPORTS

Reports in HawkEye™ can be produced for five different dataforms: survey, critical points, criticality, least distance and interpolated survey reports.

FIVE TYPES OF REPORTS IN HAWKEYE

1. **Survey Reports-** This is the default type of report, which presents all of a curve's surveys under critical points headings.
2. **Critical Points Reports-** This report displays only the geometrically defined critical points and user comments for a curve.
3. **Interpolated Survey Reports-** A report with survey interval options that can generate a new set of surveys based on user-parameters.
4. **Criticality Reports-** A special kind of least distance report where several different wells can be compared to determine dangerous proximities.
5. **Anti-Collision Reports-** A more comprehensive least distance report that contains separation factor values and secondary related numbers.





OPENING THE REPORT GENERATOR: There are four ways to get to the Report Generator in HawkEye™.

1. In the top left of the main screen, second from the left, click on the Report Generator icon. The survey which appears is of the well path that is the current center of focus in the 3D space
2. RIGHT-CLICK on any curve in the Data Tree and select "Show Survey Report." This will bring up the surveys for that particular curve selected.

NOTE: Right-clicking on a curve brings up a long list of curve-related options, and in fact, these such contextual menus are the basis for navigating the various functionalities of HawkEye™.

3. RIGHT-CLICK on a curve in the 3D space, then select “Show Survey Report.” This will bring up the surveys related to that curve.
4. RIGHT-CLICK on the colored bar just above the Survey List Panel (located at the bottom portion of the main screen) and select “Show Survey Report.” This will bring up the survey related to the currently focused well.




1. SURVEY REPORTS

TEMPLATES: Any of the 41 data types found in the blue columns on the left can be added to a report template in any order, and any number of templates can be saved and loaded. This is useful for various customers with different specs for their reports. To add a data column, LEFT-CLICK on it from the left hand blue column and it will appear in the display list column. To remove, select it on it in the right hand column by left-clicking on it, then RIGHT-CLICK on it and it will disappear.

Available Columns	Current Columns
Measured Depth	#
INC	Measured Depth
AZM	INC
TVD	AZM
EW	TVD
NS	NS
VS	EW
Closure	VS
Closure Dir	DLS
Tool Face	LR/EW From-Plan
Walk Rate	UD/NS From-Plan
Build Rate	
DLS	
Comment	
Tool Type	
Covar11	
Covar22	
Covar33	
Covar12	
Covar23	
Easting	
Northing	
LR/EW From-Plan	
UD/NS From-Plan	
Subsea TVD	
Major Sigma	
Minor Sigma	
#	
Latitude Dec.	

To place them in a certain order, they must be removed and “stacked” or re-added to the righthand column in the desired order.

PRINTING REPORTS: Printing a report is as simple as clicking the “Print” button at the top of the Report Generator panel, or by clicking the printer icon at the top of the panel. A user may also print from a certain depth. To do that, they would simply select the starting survey from which to print from the drop-down menu, then click “Print.” This is useful for avoiding having to print out an entire battery of surveys when for example only the last ten are needed on paper.



PRINTING TO PDF: HawkEye™ installs with CutePDF, a program which allows anything which can be printed onto paper to be printed into a PDF instead. Using this is as simple as selecting “CutePDF Writer” as the printer in the print settings and then selecting a target folder for the file when prompted.

COVER PAGE: A cover page can be added, and may contain any of three major elements: a logo, a title or comment, and a snapshot from the 3D space.



To add a cover page, first select the “Cover Page” checkbox in the top left. To add a logo, click “Load Logo” in the top left and select a graphic that will appear on the top left and right of the cover page.


To add comments, simply type in whatever desired text into the “Cover Page Comment” text field in the bottom left of the Report Panel. It will appear instantaneously on the cover page.

SNAPSHOT: By turning on the Snapshot option, the cover page will show the last 3D view seen before opening the Report Generator. So to adjust the snapshot, the user simply closes the Report Generator and navigates the 3D space to get just the right angle, then opens the Reports back up again.



CENTERED HEADER: A block of additional header text can be added to the first non-cover page of a report simply by adding text to the “Centered Header” text field in the bottom left of the Reports panel. Any added header text will appear above the mandatory header information that always appears in the header zone of a report.

NORTH ARROW: Toggle on the North Arrow with the checkbox in the top left and such an arrow will appear in the first non-cover page of the report. This arrow set displays True north, grid north and magnetic north. (For more on this arrow, see the Magnetics Report section at the end of this chapter).



BOX COMMENTS: Comments for each survey can be added here and are usually a necessary part of reports. To add box comments, just click the “Box Comments” checkbox and a column of comment fields will appear in the report.

PAPER SIZE: Choose from Letter or A4.

EXTRA DATA: Additional supplemental data can be appended to the bottom of a report by checking them in the “Extra Data in Report” panel. When selected, the corresponding data will be generated, organized and displayed under any displayed surveys.

11843.00	37.10	252.50	11383.92	-1994.51	1552.88	-1994.51	2527.75	142.10	0.00	0.27
11906.00	37.10	252.50	11434.17	-2005.94	1516.63	-2005.94	2514.75	142.91	0.00	0.00
Projected										
12002.00	37.10	252.50	11510.74	-2023.35	1461.41	-2023.35	2495.93	144.16	0.00	0.00
GEODETTIC INFORMATION										
Latitude: 31°48'43.5024" N						Geodetic Zone: None				
Dec. Latitude: 31.81208399						Geodetic Datum: CLARKE 1866				
Longitude: -95°38'50.7877" W						Easting: 0.00				
Dec. Longitude: -95.64744102						Northing: 0.00				
Geodetic Group: None						Convergence: 2.41				
TARGET DATA										
Name	Shape	Northing (Ft)	Easting (Ft)	TVD (Ft)	NS (Ft)	EW (Ft)	Side A (Ft)	Side B (Ft)	Diameter (Ft)	
Target 1	CYLINDER	-939.42	767.27	10130.00	-939.42	767.27	200.00	0.00	200.00	
TURN PT	CUBE	-1571.78	1517.20	10991.69	-1571.78	1517.20	50.00	50.00	30.00	
Target 2	CYLINDER	-2516.42	2055.27	11950.00	-2516.42	2055.27	200.00	0.00	200.00	

Curve List
Cover Page
Centered Header
Extra Data

Extra Data In Survey Report

GeoDetics

Lithology

Lease Lines

Magnetics

Casings

Hard Lines

Targets:

Mining Mode

Easting, Northing

Latitude, Longitude

REPORTS NAVIGATION:


The tools at the top of the

Report Generator panel controls the view modes and zoom. Reports may be viewed one, two, three, four or six pages at a time. The currently displayed page can be controlled here as well.




NOTE: Pages can also be navigated by scrolling the mouse wheel up and down while the cursor is over the report page itself. Also, left-clicking on the report itself will zoom out one step, while right-click once will zoom in one step.

SELECTING SURVEY OR PROPOSAL: Select the curve on which to base the report by clicking on it in the bottom left window of the panel. You may either choose a survey or proposal curve. They are automatically numbered by the sequence in which they are listed in the project's database. When a curve is clicked on, the report will be immediately generated via all the parameters specified in the Report Generator panel.



REPORT TYPE: Choose your report type in the middle left of the panel. A survey entry can be generated at different frequencies depending on whether the path section is straight or curved. That frequency input is located in the same window where the report type is selected and can be entered manually.




The default Survey Report will display each of the survey readings of a curve. The survey entries are organized readings under critical point headings that describe each part of the curve.

ENTERING SURVEYS: Surveys are not entered in the Report Generator, but rather only displayed in a report. Surveys can be entered manually in the survey window at the bottom of the main screen or in the Survey Editor, which can be opened by clicking on the blue plus icon on the far left end of the projection icons.


Up/Down and Left/Right: Of the many columns of data that can be added to a survey report, often favored are the UD/LR columns. When these are added to a report, they will always compare the referenced curve against the Current Proposal Curve, whichever that may be.

Furthermore, the values will be expressed as UD/LR only in surveys where the inclination is above a certain threshold (which can be set in the Sight Editor on the bottom right corner of the form). If a survey contains an inclination under the threshold, then the distances are expressed in terms of North/South and East/West of the proposal curve.

INCLUDE PROJECTION: The default survey report has a checkbox which allows the user to include any projections that were active in the 3D space at the time the Report Generator was launched. In the picture to the right, there are two projections activated, a Bit and a Nudge projection. By leaving them on and launching the Report Generator, you have the option to include them in the survey report, as illustrated below.




Just check the “Include Projection” box in the Report Type area, and the surveys for the projections will be automatically added and labeled at the end of the as-drilled surveys.



	1264.00	1.32	273.53	1263.90	-0.44	-1.88	-1.88	1.93	-32.45	1.00	0.66 (N)	-13.68 (W)
	1296.00	1.32	286.93	1295.90	-1.16	-1.75	-1.75	2.10	41.88	0.00	0.59 (N)	-12.95 (W)
	1328.00	1.32	304.99	1327.89	-1.81	-1.43	-1.43	2.31	56.44	0.00	0.34 (N)	-12.27 (W)
End of real surveys	1358.00	1.01	325.12	1357.88	-2.24	-1.02	-1.02	2.46	67.10	-1.03	-0.02 (S)	-11.80 (W)
Begin first projection	1391.00	0.70	343.62	1390.88	-2.47	-0.58	-0.58	2.54	56.06	-0.94	-0.42 (S)	-11.54 (W)
	BIT PROJECTION - Begin Build and Turn @ 1400.00MD, 2.00"/100 Ft											
	1400.00	0.63	356.44	1399.88	-2.49	-0.48	-0.48	2.54	0.00	0.00	-0.52 (S)	-11.51 (W)
	1405.00	0.70	2.20	1404.88	-2.49	-0.42	-0.42	2.53	115.25	1.49	-0.58 (S)	-11.50 (W)
	1410.00	0.78	6.83	1409.88	-2.49	-0.36	-0.36	2.51	92.52	1.60	-0.64 (S)	-11.50 (W)
	1415.00	0.87	10.58	1414.88	-2.47	-0.29	-0.29	2.49	75.01	1.68	-0.71 (S)	-11.51 (W)
	1420.00	0.96	13.66	1419.88	-2.46	-0.21	-0.21	2.47	61.54	1.74	-0.79 (S)	-11.52 (W)
	Begin Build and Turn @ 1425.00MD, 0.00"/100 Ft											
Begin second projection	1425.00	1.05	16.21	1424.88	-2.43	-0.12	-0.12	2.44	51.13	1.79	-0.87 (S)	-11.53 (W)
	QUILA PROJECTION - Begin Build @ 5.00"/100 Ft											
	1430.00	1.14	18.36	1429.88	-2.41	-0.03	-0.03	2.41	0.00	0.00	-0.96 (S)	-11.55 (W)
	1435.00	1.39	18.36	1434.88	-2.38	0.07	0.07	2.38	0.00	5.00	-1.07 (S)	-11.57 (W)
	1440.00	1.64	18.36	1439.88	-2.33	0.20	0.20	2.34	0.00	5.00	-1.20 (S)	-11.60 (W)

Page # 1 <Wellpath: Work Curve>

You may also generate a report that contains ONLY projection surveys by clicking on the “Projection Only” button in the Report Type.



2. OTHER SPECIAL REPORTS

a. Critical Points Reports

There are two kinds of critical points in HawkEye™, the geometrically defined critical points and user-created comments. With a Critical Points report, each of these survey points are put into a report, ordered by depth.

To create a Critical Points report, select “Critical Points” from the Report Type, then select the reference curve on the bottom left. The report will be immediately generated, displaying all the geometrically defined points as well as user-generated comments for that curve.

Measured Depth (Ft)	INC Deg	Major Axis (Ft)	Minor Axis (Ft)	Major Sigma (Ft)	TVD (Ft)	AZM Deg	EW (Ft)	NS (Ft)	VS (Ft)	Closure (Ft)	Closure Dir Deg
Begin Nudge / 200 TVD, Build @ 2.50°/ 100', 130° Azimuth											
200.00	0.00	0.00	0.00	0.00	200.00	0.00	0.00	0.00	0.00	0.00	0.00
Begin Hold @ 5.00°, 130.00° Azm											
400.00	5.00	0.43	0.40	0.43	399.75	130.00	6.68	-5.61	-5.61	8.72	130.00
9 5/8" casing											
771.67	5.00	1.44	1.26	1.28	770.00	130.00	31.50	-26.43	-26.43	41.11	130.00
Begin Drop @ -1.50°/ 100'											
1200.00	5.00	2.62	2.26	2.27	1196.70	130.00	60.09	-50.42	-50.42	78.45	130.00
Vertical											
1533.33	0.00	2.23	1.65	1.65	1529.61	130.00	71.23	-59.77	-59.77	92.98	130.00
Begin Curve / Build @ 10.00°/ 100', 158° Azimuth											
6037.72	0.00	11.54	11.42	11.42	6034.00	158.00	71.23	-59.77	-59.77	92.99	130.00
Target / Begin Turn @ -5.00°/ 100'											
6937.79	90.00	18.08	13.11	12.99	6607.00	158.00	285.88	-591.05	-591.05	656.56	154.19
End Turn / Hold @ 130.93° Azimuth											
7479.20	90.00	26.64	13.35	13.02	6607.00	130.93	597.64	-1027.54	-1027.54	1188.70	149.82
Proposed End of Lateral											
10980.52	90.00	106.65	34.06	14.32	6607.00	130.93	3242.94	-3321.36	-3321.36	4641.99	135.68

The Critical Points report will display all relevant data points of a curve. Simply select “Critical Points” as the report type and select the desired reference curve.

In addition to the standard comments, additional comments for Lithology, casing and targets can be included in the critical points report. In order to include those, just click the associated check box for the Interpolation Options. An icon for lithology, casing or a target will precede the description.

If two critical points are defined by the same point then all the comments are joined and the icon provides a visual cue as to the nature of the comment.

b. Least Distance Report


A Least Distance report will generate a list of surveys comparing any two curves, as well as a ladder plot to help discern any dangerous proximities. Any well that is close to the base line of the plot indicates a potential problem at that measured depth.

SELECT TWO REFERENCE CURVES: To create a least distance report, just select “Least Distance” in the Report Type window, then select the two reference curves from the drop-down menu that will appear just below. After selecting the two curves, click “Create Report.”

The first non-cover page of the Least Distance report is the ladder plot comparing the two curves, then the subsequent pages contain the survey list. This list will have a criticality column with a number from 1 to 5 which will indicate any dangerous proximity between the two reference curves. 1 represents minimal or no danger, so a long string of “1”s in this column is always the desired look for a Least Distance report.

Criticality Distance (Ft)	
1	711.88
1	620.96
1	531.70
1	445.10
1	362.33
1	285.48
1	219.75
1	176.37
1	171.20
1	205.42
1	262.93
1	267.24

The next column over shows the distance between the two reference curves at each survey point. The actual closest approach may likely be between survey points, and can be inferred from this data.




A Least Distance report will generate a color ladder plot comparing any two curves in a project. Y-axis is proximity and the X-axis is the measured depth.

c. Interpolate Survey Report

Additional interpolated surveys can be generated for either survey or proposal curves.

When a survey curve is selected under the Interpolate Survey report type, an Increment field appears within which the user may define an interpolation interval. When a proposal curve is selected, the interval fields allow the user to define both the straight segment and curve segment frequency of interpolated surveys.



The screenshot shows a software interface for generating reports. The 'Report Type' section has several radio button options: 'Survey', 'Projection Only', 'Critical Points', 'Interpolate Survey', 'Criticality', and 'Anti-Collision'. The 'Interpolate Survey' option is selected. To its right is a button labeled 'Keep Curve'. Below these options are two input fields: 'Straight: 100 ft.' and 'Curve: 100 ft.'. A red rectangular box highlights the 'Interpolate Survey' radio button, the 'Keep Curve' button, and the two input fields.

The reason proposal curves have two interpolation intervals to define and regular surveys is because frequently customers want to see a proposal with the curve section interpolate by one value, say 30 feet and the hold sections interpolated every 100 feet. A proposal can be represented by simply inputting the critical points as surveys. A proposal's critical points will calculate exactly the same closure and coordinates as the same proposal that is interpolated every foot. Another way of stating this is that if we took the proposal that had surveys every foot and removed all the surveys except for the critical points and calculated that we would come up with the same answer.

KEEP CURVE: The Interpolated Report can be used to generate an entire curve from just a few critical points. This process takes the critical points and extrapolates them into a usable proposal curve. Just follow these steps:

1. Enter the critical points as surveys into a new or existing curve.
2. Go to Report Generator and select "Interpolate Survey" as the report type.
3. Define the increments of interpolation you want for the curve.
4. Click the KEEP CURVE button.



The interpolated surveys will be added as part of the current curve.

d. Criticality Report

The Criticality report will graphically represent any dangerous proximities on a distance plot. All curves in a project are shown with a key at the bottom of the graph.

Be sure to select the desired reference curve from the drop-down menu at the bottom left of the panel when “Criticality Report” is selected. A Maximum Distance can be set, a range to which criticalities will be displayed. When a new reference curve is selected, click “Create Report” in order to refresh the graph.

SHOW PROJECTION: Check the “Show Projection” box to show any curve’s projection in the graph. It is recommended that the projection be made a different color than the preceding curve in order to enhance visibility in the graph




A Criticality report presents all curves against a reference curve in order to assess any dangerous proximities or criticalities.

The text output associated with the criticality report will highlight only Criticality 3, 4 or 5. Criticality 1 and 2 are ignored. This helps to keep the report to a manageable size.

e. Anti-Collision Report

The anti-collision report is the program's most comprehensive report and analysis of possible collision issues between wells. It's data columns are set rather than customizable. Just like the Criticality report, it is important to first select the report type, and then choose the Reference Curve and Compared Curves in the bottom left.



The screenshot shows a software window titled "Proximity" with a yellow background. It contains the following controls:

- Referenced Curve:** A dropdown menu with the text "Sausage 151-94-16B-21H - Wellbore #1 - Plan #2".
- Compared Curves:** A dropdown menu with a checkbox and the text "Check All".
- Maximum Distance:** A text input field containing the number "2000".
- Criticality Level >=:** A dropdown menu with the number "1".
- Show Projection:** A checked checkbox.
- With Interpolated Surveys:** A checkbox followed by a text input field containing "100 ft.".
- Show Forward Only:** An unchecked checkbox.
- Generate Report:** An orange button.

The first page of every anti-collision report is a ladder plot of the selected curves. To get to the first page of listed data, navigate to Page 2 using the page navigation tools at the top of the screen.



Anytime any parameters are changed for this report, you must press the "Generate Report" button to regenerate the report. Due to the potentially massive amount of data being processed, this report may take several long moments to load after each re-generation.

f. Magnetics Report



Magnetics is particularly important when taking magnetically measured surveys, for example determining applied declination, etc. HawkEye™ allows for a high amount of customization in magnetics configuration.

To get to the Magnetics dialogue, click on the magnet icon at the top center of the main screen.

MAGNETICS MODELS: Once inside, the first step is to select a magnetic model file. HawkEye™ uses the IGRF (International Geomagnetic Reference Field) and WMM (World Magnetic Model) magnetic models. (Future models will include those developed by National Oceanic and Atmospheric Administration and the British Geological Survey). The BMMG model is available for those users who have a paid license for it, but is currently not available standard with HawkEye™. It is important to have the right model selected. The IGRF2010 model is good until 2015.

SURFACE LOCATION: Magnetics is automatically calculated when a surface location is entered in a project, but that location (Lat-Longs) can be manually changed in the Magnetics panel in the fields highlighted in light green at the top.

PRINTING: Just click the “PRINT” button and a handy one-page Magnetics/Geodetic Report is generated, containing not only all pertinent magnetics information, but several methods of correction based on which north the user needs to correct from.




V. PLOTS

There are two kinds of plots in the program: Quick Plots and Presentation Plots. Quick Plots are available in all versions of HawkEye, and allow for smaller “Plan-versus-Actual” type of plots. Presentation Plots are available only in the Well Planning version, and allow for large “wall plots.”

1. QUICK PLOTS



QuickPlots in HawkEye are used to create “Plan-versus-Actual” plots on regular-sized paper (letter or A4). The only place where you can launch this module is the “Quick Plot” icon in the Home tab of the main screen.



The Essential Options: There are many different options and parameters to mess with in the QuickPlot, but only a handful of the most essential ones in order to get a decent PvA plot as quickly as possible. Here they are in the recommended order of tending to:

- 1. Sort the Header Information:** In order to access the header information, hover over the header and press the right-mouse button. This will open Job Info for the current curve. Resize the header itself by dragging the bottom border with the left mouse button. Text size will automatically resize as you resize the window.


- 2. Choose the Plot Type:** Select your plot type in the top right. There are two orientations: Portrait (on the top) and Landscape (on the bottom). The V stands for Vertical, meaning a Vertical Section Plane plot, or side view. The H stands for Horizontal, or top view.



VH is a combination of both side and top view, as pictured in the screenshot of the previous page.


The TC plot is a completely different type of plot called a Travelling Cylinder.

- 3. Choose the Curves to be displayed:** Click on the “Curves” button to turn on and off which curves you actually want displayed on the QuickPlot. After hitting “OK,” the plot will update.




- 4. Fix your labels:** Click on the light blue “Graph Properties” button in the same area to open the options window.

This window is bristling with options, but in most cases you will only need to worry about four things. In this step, find the “Font Size” options on the bottom left with yellow background and make those sizes larger as needed. They will instantly update in the plot, so you can see how large you need the label fonts to be.



- 5. Fix the curve thicknesses:** The other two parameters on this screen that you may want to tweak are the Curve thicknesses, which are the top two numbers on the top right. These control how thick the curve lines appear in the plot

- 6. Double-check your VSP:** If you are using a V or VH plot, then make sure that your Vertical Section Plane is set to the correct value.



- 7. Choose your objects:** There are about 20 different “objects” or data windows and elements that you can add to your plot. Check or uncheck these as desired. NOTE: You can right-click on the word in many cases here and instantly edit the data.

Navigating the plots:

- **Zoom in and out:** Use the mouse wheel while hovering over the plot itself
- **Cursor mode:** Double left-click anywhere on the plot to switch between the two cursor modes:
 -  **Ruler Mode:** for drawing a temporary measuring line by holding down the left mouse button.
 -  **Magnification Mode:** hold down left mouse button to draw a rectangle that becomes the new zoomed in area.
- **Resize the Top View:** When using the VH mode, resize the smaller, inner Top View window with the small red square in the bottom corner of the window.

Save Template: If you've put a lot of work into getting your QuickPlot just the way you or your company needs it to be, save all of your choices by clicking "Save Template." (Blue button at the bottom of the righthand panel). This will save your configuration to a special .hawkplot file that you can load back into QuickPlot by clicking "Get Template."

Reset All: The red "Reset All" button on the bottom right is a way to get back to default settings if you have unintentionally gotten all the settings messed up in some way.

2. PRESENTATION PLOTS

a. How the Plot Designer Works

The Presentation Plot Designer in HawkEye™ is one of the most powerful and complex aspects of the program. It utilizes scalable vector graphics (SVG) when generating wall plots, making for very clean and precise visual representations of the native data retrieved from the project database.

But SVG also allows a high degree of flexibility as far as zooming and resizing. The SVG is in fact handled by a dedicated program called InkScape™, which installs with HawkEye™. InkScape™ itself a tremendously powerful SVG editor that, when even only minimally understood, will produce very professional and sharp presentation-caliber plots.

SCALABLE VECTOR GRAPHICS (SVG)

SVG has been in development since 1999 by a group of companies within the W3C after the competing standards Precision Graphics Markup Language (PGML) were submitted to W3C in 1998. SVG drew on experience from the designs of both those formats. SVG drawings can be dynamic and interactive. SVG allows three types of graphic objects: vector graphics, raster graphics and text.

Graphical objects, including PNG and JPEG raster images, can be grouped, styled, transformed, and composited into previously rendered objects. Text can be in any XML namespace suitable to the application, which enhances search ability and accessibility of the SVG graphics. The feature set includes nested transformations, clipping paths, alpha masks, filter effects, template objects and extensibility.

The SVG Specification contains provisions for rich graphics, and is unlike XHTML, whose primary purpose is communication of content, not presentation, and therefore specifies objects to be displayed but not where to place such objects. Conversely SVG is an ideal PDL for print-oriented uses, as it contains all the functionality required to place each glyph and image in a chosen location on the final page.

WORKFLOW FOR A PLOT

The Plot Designer in HawkEye works in conjunction with other software in order to make complex plots. The process cannot be described as simplistic, but nor is it too arcane. There is a division of labor here amongst the programs. Here is the sequence generally:

STEP ONE: HawkEye

- **Add** all the graphs, charts, lists, graphics and components that you want.
- **Tweak the data** aspects of graph grids, lists, as well as and colors.

[Click “Edit w/Inkscape”]

STEP TWO: Inkscape

- **Position** the various items to where you want them.
- **Tweak non-data elements** like label placements and indentations, etc.

[Print to PDF]



STEP THREE: Adobe Reader


- **Choose** your paper size once your PDF is open.
- **Print** to paper.

OPENING THE PLOT DESIGNER: The Presentation Plot module is opened by clicking on the “Present. Plot” icon under the Edit tab. This is only found in the Well Planning version of the program.




FILE MENU: In the top left of the screen is the “File” menu. It contains all the essential plot file management options:

- **Save Template:** This will save whatever frames are currently displayed in the plot designer as a template file (.plt). User can define the name and location of the template file. The default location where all default HawkEye™ templates are stored is c:/HawkEye™/plottemplates.
- **Get Template:** This simply opens a file launch dialogue to load any template (.plt) file into the Plot Designer.



MAIN CONTROL PANEL: Although the Plot Designer has individual panels for each element of a plot which can be opened and closed, there is a Main Panel that always stays at the top left. It is broken into two tabs, the Graph Objects and Edit Frame tabs. Under the Graph Objects (default open) tab, the user may select printer, paper size and orientation, as well as templates, adding frames and adding other elements to a plot.

Click “Save PDF File” to get an instant PDF of whatever is currently displayed without using Inkscape. This is useful for quick plots containing relatively few elements (e.g. VS v. Horizontal view)



PRINTING: The Print button, located just next to the paper selection drop-down menu, allows for a wide variety of print sizes. When the CutePDF Writer is selected as the printer, this selection contains virtually all print sizes. However, only in the Well Planning version of HawkEye™ will the larger wall plot sizes be available for printing. In other words, the Field version of HawkEye™ only has the conventional non-plotter sized options for a paper sizes up to A3. Also note, a paper size is simply not available if the selected printer will not support it.

PRINTING PLOTS: FIELD v. WELL PLANNING VERSIONS

The difference between the Field version and Well Planning version of HawkEye™ with plotting is that only in the Well Planning version will the larger wall plot sizes be available for printing and exporting. Only the smaller paper sizes are available in the Field version since it is assumed that users of the Field version will not need a plot printout larger than A3.

Exclusive Well Planning version print sizes include: A4, A2, 11x17, ISO A0-2, ISO B1, B1-B4(JIS), ARCH A-E1, Folio [8.5x13in], 22x36in, 24x48in, 24x60in, 24x72in, 24x84in, 24x96in, 24x108in, 36x42in, 36x60in, 36x72in, 36x84in, 36x96in, 36x108in and PostScript Custom.

PROJECT PLOTS: Each project is given up to four customizable templates. Select 1-4 from the Project Plots drop-down menu in order to open a template, and to save to it, just have it selected and click the “Save” button next to the drop-down menu. The template names can be changed to whatever descriptive name the user wants.

ADD COMPONENTS: There are dedicated buttons in the plot designer’s main control panel for adding certain components:

- **Add Vertical-** add a Vertical Section view graph to the plot
- **Add Horizontal-** add a Horizontal view graph to the plot
- **Add MD or TVD vs ??-** Add a graph which charts MD or TVD against any given parameter you chose.
- **Add Graphic-** Drop any sort of image file into the plot. **NOTE: Any graphic located within a folder path that contains special characters such as “&” will not load into the SVG environment!**
- **Add Frame-** This button encompasses a long list of additional types of frames which can be selected from the drop-down menu in the sub-panel created. Those frames include:
 - Header
 - Footer
 - General Data
 - Critical Points
 - Hard Lines
 - Lease Lines
 - Lithology
 - Casing
 - Job Data
 - Slot Data
 - Text
 - Last 3D View
 - 3D Perspectives
 - Geomagnetism
 - Geodetics
 - North Arrows

See more in the last two sections of this chapter titled “Add Frame.”

SHOW LITHOLOGY: This checkbox will display any entered lithology data as the background of a graph.

LEFT SIDE: When the user does not want to display the lithology across the entire width of a VERTICAL SECTION graph, the “Left Side” toggle will limit the display to only the left side of the displayed curve. This is useful for when the lithology data only includes tops, which do not actually define dips across an extended horizontal plane.

TRANS: This is a translucency control that will determine opacity of the lithology background, ranging from 1-100.

SHOW REAL LITHOLOGY: This toggle will overmap any data entered into the lithology which reflects thicknesses, vertical section departure etc, from the surface location.

PRINT PDF FILE: This button will pull up the print dialogue and automatically select the CutePDF Writer as the printer for PDF export of the plot as it appears.


EDIT W/ INKSCAPE™: This button launches the all-important InkScape™ application, which utilizes scalable vector graphics (SVG) in order to move, place and resize all the existing elements of the plot. It cannot be used to edit the plot’s actual data, however.

TEMPLATE FILE: The “Save” button under “Template File” will save the current plot configuration to a template file (.PLT). Clicking “Get” will open the folder where template files are stored. HawkEye™ installs with about a dozen default templates to choose from.

b. Vertical Section Plots

The vertical section frame is normally included in the default plot templates since it is staple information for plots. But for a user wanting to start from scratch on building a plot, the VS frame is easily added.


Add a graph depicting a vertical section view of a project to the plot by clicking the “Add



Vertical” button in the main control panel. Depending on the nature of the wells, either Landscape or Portrait may be more appropriate. However, if the plot is very large this preference will not hinge on the shape of the vertical section frame alone.

GRID FEATURES: The checkboxes in the blue field of the sub-panel will control whether any of the grids or the outer frame is displayed. Click on the circle to the left of any of the grid boxes to open a color dialogue and select a color for the element from the palette.

RESIZING: Height and width can be changed with the drop-down menus. The boxes in between these menus toggle whole-page vertical and horizontal expansion of the graph. The “Outer Scale” slide control will resize the frame as a whole. Further fine-tune resizing can be done in InkScape™. (Launch InkScape™ by clicking the “Edit w/ InkScape™” button in the main control panel on the top left quadrant of the Plot Designer).



PLACEMENT: The 9-circle grid on the top right will control the general placement of the graph. However, for fine-tune placement (as well as resizing), InkScape™ is used. This grid is only for rough draft placing.

AUTO CALC: When this is toggled on, the Plot Designer will calculate the best way to fit the relevant portion of the VS view into the graph space displayed. When turned off, several manual fields are activated, including the vertical exaggeration factor and the “Div/Tick” drop-down menu, which allows the user to define the number of graph ticks per division. By increasing the ticks per division, there is a zoom effect on the graph. By default, graph treats each tick as one inch, but to “zoom out” and increase the distance per division, just slide down the “Inner Scale” slide control in the sub-panel.


VIEW CHANGES: VSP will change the angle at which the vertical section are being seen, by degrees. The Start VS and TVD fields control the depth at which the curves begin on the graph. Adjusting these two parameters when AutoCalc is turned off allows the user to position the graphics within the grid.

GO TO CHART: The “Go to Chart” button allows the user to leave the Plot Designer for a moment and re-adjust the positioning of the graph in the main HawkEye™ environment. The “chart” launched is merely the VS View, where zooming and panning can be done in order to get a better view. To get back out of the VS View and

back to the plot, just click the “View Plot” button at the top of the window. The next step is to click the “PLOT FROM CHART” button. This button will take whatever immediately preceding adjustments made in the VS View and implement them in the current VS plot frame.

LABELS MANAGER: Click the “Labels Manager” button at the bottom of the sub-panel to launch the standard Graphics Properties Labels controller. This general panel controls both VS and Top view label and grid characteristics.

In order to get VS and Top view graphs to look exactly as desired, it is important to experiment with and understand this control panel. At the bottom, all settings can be applied to this plot, all plots or all charts.



VERTICAL SECTION WITH LITHOLOGY

Lithology information of a project can be graphically displayed as the background of a vertical section plot within the Plot Designer. The first step is to make sure there is lithology data entered the way the user wants it into the project's database. (See section on Lithology, Ch.3).


Once a vertical section plot frame has been created (Click "Add Vertical" in the main control panel of the Plot Designer), the option to "Show Lithology" will appear as a checkbox. Toggle on the "Show Lithology" and the rest of the controls will appear.




TRANS: This is a translucency control that will determine opacity of the lithology background, ranging from 1-100.

SHOW REAL LITH.: This toggle will overmap any data entered into the lithology which reflects thicknesses, vertical section departure etc, from the surface location.

LEFT SIDE: When the user does not want to display the lithology across the entire width of the vertical section plot, the "Left Side" toggle will limit the display to only the left side of the displayed curve. This is useful for when the lithology data only includes tops, which do not actually define dips across an extended horizontal plane.



The "Show Lithology" checkbox in the Plot Designer main control panel will project lithology data as the background of a graph.




c. Horizontal Plots

A horizontal plot is simply the “Top View” found in the main HawkEye™ module. A horizontal plot can be added to a plot by clicking “Add Horizontal” in the main control panel. Be sure to select the desired Paper Size and orientation above.



Once the frame has been created, its sub-panel will appear below under the header “Horizontal Plot.”

GRID FEATURES: The checkboxes in the blue field of the sub-panel will control whether any of the grids or the outer frame is displayed. Click on the circle to the left of any of the grid boxes to open a color dialogue and select a color for the element from the palette. The “ADD” button will add an entirely new generic frame.




RESIZING: Unlike many other frames in the Plot Designer, the Horizontal Plot frame (as well as Vertical Section View frame) is resized and edited to a great degree without InkScape™. The controls in the Horizontal Plot sub-panel contain most of the tools needed. Click the boxes between the Height and Width fields to maximize the Horizontal plot vertically or horizontally. Both boxes checked means that the graph will occupy the entire plot.

AUTO CALC: When this is toggled on, the Plot Designer will calculate the best way to fit the relevant portion of the Horizontal plot into the graph space displayed. When turned off, several manual fields are activated, including the Origin grid. X and Y Offset fields, and the “Div/Tick” drop-down menu.

DIV/TICK: By increasing the ticks per division, there is a zoom effect on the graph. By default, the graph treats each tick as one inch, but to “zoom out” and increase the distance per division, just slide down the “Inner Scale” slide control in the sub-panel.

d. TVD and TVD Function Plots

The Plot Designer can create graphs which plot the measured or total vertical depth of a curve as a function of another parameter. To add this kind of frame to a plot, just click “Add MD vs ??” or “Add TVD vs ??” and the frame’s sub-panel will appear below.



From the “vs” drop-down menu in the respective sub-panel, the user can choose which measurement to add the depth as a function to. By making the selection here, the graph is generated automatically in the plot and can be resized or moved around.

GRID FEATURES: The checkboxes in the blue field of the sub-panel will control whether any of the grids or the outer frame is displayed. Click on the circle to the left of any of the grid boxes to open a color dialogue and select a color for the element from the palette. The “ADD” button will add an entirely new generic frame.

PLACEMENT: The 9-circle grid on the top right will control the general placement of the graph. However, for fine-tune placement (as well as resizing), Inkscape™ is used. This grid is only for rough draft placing.

DIV/TICK: By increasing the ticks per division, there is a zoom effect on the graph. By default, the graph treats each tick as one inch, but to “zoom out” and increase the distance per division, just slide down the “Inner Scale” slide control in the sub-panel.

e. Add a Graphic

ADD A GRAPHIC: To add pictures and graphics to a plot, first click the “Add Graphic” button in the main control panel. This will create a sub-panel labeled “Picture” with a sequential number. Then click the “Get File” button at the bottom of the sub-panel to open the file selection dialogue through which any graphic file format can be selected. HawkEye™ installs with a number of logos to choose from (default folder: c:/HawkEye™/oilfield.logos) but any image file may be added to the plot.

To add a second graphic, simply click the “Add Graphic” button again and another “Picture” subpanel will appear.

RESIZING: Resizing the graphic is done in two ways: either manually adjusting height and width in the sub-panel, or by sliding the “Outer Scale” slide control on the right. (Fine-tune resizing is done in InkScape™. Click “Edit w/InkScape™” in the main control panel to launch).



ADJUSTING TRANSLUCENCY: By sliding down the “Inner Scale” slide control, a graphic’s opacity is reduced. This is useful for creating watermarks on a plot.

PLACEMENT OF GRAPHIC: The 9-circle grid in the sub-panel will give the graphic a rough placement on the plot, but any fine-tune placement and resizing of the graphic and of any frame is done in InkScape™, the scalable vector graphics program attached to the Plot Designer. Click the “Edit w/ InkScape™” button in the main control panel to launch the program. (More on InkScape™ below).

f. Add Frames: Most Commonly Used

Most of what can be added to a presentation plot falls under the “Frame” category. The list of frames that can be added are the following:

- Header
- Footer
- General Data
- Critical Points
- Hard Lines
- Lease Lines
- Lithology
- Casing
- Job Data
- Slot Data
- Text
- Last 3D View*
- 3D Perspectives*
- Geomagnetism
- Geodetics
- North Arrows

* Explained in the following section “Add Frame: Screenshots”


This following sections detail the most commonly used frames:

1. **Add/Edit/Delete Frames**
2. **Header**
3. **Lithology, Casing and Target Lists**
4. **Targets List**
5. **Critical Points List**
6. **Geodetics, Magnetism and a North Arrow**


1. Add/Edit/Delete Frames

ADD FRAME: After clicking the “Add Frame” button from the main control panel, a component bar appears below the main panel labeled “Frame.” In this sub-panel, the frame type can be selected from the “Frame” drop-down menu. There are 17 types of frames to choose from.


Most of the frames, once chosen and placed, will have the same set of controls for editing. That control set will be located in this very same sub-panel, but there will be slight variations on the controls depending on which frame is selected.




SELECT FRAME: Only one frame can be selected at a time for editing. To select a frame, click on the circle to the left of the component header. When not selected, this circle is pink. When a frame is selected, its circle is green and its sub-panel is expanded.




DELETE FRAME: To delete a frame, just click on the red box on the right end of the sub-panel header. This will instantly remove the frame and all of its settings from the current plot, so make sure to have any templates saved before killing a frame.



EDITING FRAMES: Once a frame has been created, you can use the “Frame” submenu to edit its CORE properties. (For more fine-tuning, you will click the “Edit Frame” tab on the top left). Use the radio buttons to pull up their corresponding options dialogues: background color, font color and frame color. You may toggle whether a colored frame outlines the frame itself by toggling the “Show Frame” box. You may also toggle “Section Lines,” which will show if there is more than one column in the frame itself. Frame size and width is also controlled in this sub-panel, as is the font properties found in the header. Click “Font” to pull up the font properties. The Outer Scale meter will automatically resize the frame, font and all. Click “Save” to save all the current settings to default for future frames of that type.




EDIT FRAME TAB: The other tab in the main control panel of the Plot Designer is the Edit Frame panel. It is used for more fine-tuning of any given frame. The first step is to select the object to be edited from the Frame Objects drop-down menu. This will dictate the kinds of options that will be available in the rest of the panel.




Thus there are two levels in which to edit plot frames in HawkEye™ and they are each found in their own tab of the main control panel of the plot designer. The colors, fonts and outer scale is edited under the “Graph Objects” tab, where such frames can also be added. Under the “Edit Frame” tab, specific spacing parameters can be entered, as well as section divides and section styles.

2. Header

The first step in creating a presentation plot from a blank slate is to add a header. To do that, click the “Add Frame” button from the main panel, then in the “Frame” drop-down menu select “Header.” A standard header will appear at the top of the plot with graphical logo on the left and seven lines of header text to the right of the logo. You may edit the basic characteristics of the header frame as described above, but you may also click the “Job Information” button to edit the actual information found in the header.



To edit a header more closely, select the “Edit Frame” tab on the top left. Then select “Header” from the “Frame Objects” drop-down menu. You will now see the breakdown of how the header is built in this panel. By default the header is composed of three sections, which can be changed. To change the relative widths of each section, you will **manually enter the ratio** in the “%” field. Each of these numbers represents the percentage of the total width of the header at each section divider.



So in the following example, the ratio of “0, 12, 88, 100” divides a header that looks like so:



The three sections are 1) the graphic section, 2) the “text flow” section and 3) another graphics section. The dividers come at 0% width, 12% width, 88% width and at the end at 100% total width. The next picture shows a ratio of 1,9,91,100:




To edit any of these sections, use the “SECTION SELECTOR” to move the number up and down. Sections are numbered from left to right, so the first graphic section above would be “1.” It is characterized under the “Section Style” drop-down menu as a “Graphic.” To change this particular graphic, make sure the Section Selector is on “1,” then click “Browse” to select a different graphic for that section.

NOTE: Any graphic located within a folder path that contains special characters such as “&” will not load into the SVG environment!


Hit “Apply” after selecting any new graphic or making any changes.

To edit a “Text Flow” section, use the Section Selector to select it. In this case it would be “2.” Once selected, the entire panel will change to display all the text flow options. The most salient options are the number of rows and columns. Just like with section width ratios, the spacing of these columns are controlled by manually entering ratios. However, notice that the ratios are specified by default as decimals up to the hundredth power, so mind the punctuation in this field.



ADDING DATA COLUMNS: Further below in text flow editing panel are the data type selection columns. There you can choose which kinds of data will appear in the text flow section. On the left are all the available data types that can be added.

To add one, left-click on it, and it will appear at the bottom of the right-hand column. The right-hand column, likewise, displays in order from top down which data types are displayed from left to right on the plot (restarting from top left on subsequent rows and columns).




To remove a data type, left-click and then right-click on the word. To re-order the data, you must remove each of them and re-stack them in the desired order.

In the following example, there are 14 data types, 7 rows and 2 columns. The columns are given width ratios of 0,50,100. Remember that the width ratios within a text flow area only apply to that section, not the entire frame.



Here is another example. The text flow section is given three columns, with 8 rows per column. But the width breakdown is a little different: 0,20,80,100.




This creates columns within the text flow section that are not symmetrical, which is what the user may want:




MAKE DEFAULT: Once all changes have been made to spec, be sure to click “Make Default” at the top of the Edit Frame panel.

SAVE AS TEMPLATE: To save any component or frame settings in one of the four template slots, just click the Graph Objects tab at the top, then use the pulldown menu to select which slot you want to save under, then click the “Save” button to the right. Remember, saving in a slot will erase the old template in that slot, so keep track of your templates.




3. Lithology, Casing and Targets Lists

The lithology, casing and targets frames are the kinds found under the general frames list, so to add them to a plot, just click “Add Frame” in the main control panel on the left side of the Plot Designer. A “Frame” sub-panel will appear, and from the “Frame” drop-down menu, select Lithology. It will automatically appear. Don’t click the “Add” button unless you want a *second* frame of that type.



SAME PROCESS: This creation process is the same for casing and targets, and all of the controls described below are also identical.

PROXY CONTROL: Once the lithology frame has been created, it will appear on the plot. Below the plot will also appear a proxy control. This proxy control emulates the selected frame (select any frame by clicking on its sub-panel on the left) and allows the user to resize columns by clicking and dragging borders. So when a column width is resized in the proxy control, its respective frame is resized.





Certain frames like lithology, casing and targets have a proxy control that appears below the plot, where by adjusting the proxy chart column widths, the frame’s column widths are adjusted.

All the characteristics besides column width are controlled in the frame's sub-panel. Click on the radio button to pull up each respective dialogue.

NOTE: To trigger changes made to the frame here, sometimes another change must be made. The easiest way to do this without making unwanted changes is to check the "Show Frames" box twice.

ANCHOR CONTROL: The 9-circle grid on the top right of the panel is an anchor control which delineates which quadrant of the plot the frame will be placed. Sometimes the frame will not be placed in the absolute corner of a plot when told to do so because of the spacing priority logic of previously placed frames or objects. But this anchoring control is only for rough placement anyway. All final placements on a plot are done in InkScape™. (To get to InkScape™, just click "Edit w/ InkScape™" at the top of the main control panel).




Frames are placed via the 9-circle grid of their respective subpanels. However, they will be stacked on top of other frames if the spot is already taken. This is because the anchor is only for approximate placement. All final placements of frames and objects are done in InkScape where they can also be warped, resized, drawn and commented on.

4. Targets List

Further editing of a grid-style section can be done under the “Edit Frame” tab, selected from the top of the main control panel in the Plot Designer. Changing a frame without making it a default will have the changes only apply to the current plot. Once Make Default is selected then the changes will be reflected in all newly generated plots. One of the most common grid style sections in plots is the Target List. To fine-tune edit such a list once it has been created in the plot, just click the “Edit Frame” tab, then select “Targets” from the “Frame Object drop-down menu. Then be sure to select “Grid” from the “Section Style” drop-down list.

OTHER GRID-STYLE FRAMES: Lithology and Casing lists are also grid-style lists, so they can be fine-tune edited under this tab by selecting them under Frame Objects drop-down menu and selecting “Grid” for the section style.




The font, number of columns and overall width of the frame is controlled in this panel. Check the “Show Grid Lines” box to display the lines along each of the columns.

COLUMN WIDTHS: The column width field allows the user to define widths by percentage from the left. The number of percentage values given depends on the number of columns in the frame. Each value defines where a column division is placed, with the first and last values (0 and 100) representing the outer edges of the frame. The following target list has 6 columns with a column width percentage of 0, 16.67, 33.33, 50, 66.67, 83.33, 100:

TARGETS					
NAME	TVD	Northing	Easting	NS	EW
INTERSECTION POINT	5601.96	622187.73	2868031.68	1699.47	646.74
K BISC Target	8000.00	623943.26	2868784.94	3455.00	1400.00
Target2	9000.00	625019.80	2869498.03	4531.54	2113.09

The column width percentages will automatically generate to equal spacing when a new number of columns is selected for the frame.

ADDING DATA COLUMNS: Further below in text flow editing panel are the data type selection columns. There you can choose which kinds of data will appear in the text flow section. On the left are all the available data types that can be added. To add one, left-click on it, and it will appear at the bottom of the right-hand column. The right-hand column, likewise, displays in order from top down which data types are displayed from left to right on the plot (restarting from top left on subsequent rows and columns). To remove a data type, left-click and then right-click on the word. To re-order the data, you must remove each of them and re-stack them in the desired order.




APPLY/MAKE DEFAULT: Be sure to click the “Apply” button after making each change to the frame so that it will appear in the plot. Once all the parameters of a given frame type have been set up to personal spec, then click the “Make Default” button to save them as such.

5. Critical Points List

Critical points frames are the kind found under the generic “Add Frame” button in the main control panel.

To add a critical points list to the plot, click the “Add Frame” button, which will create a new sub-panel below labeled “Frame.” From its “Frame” drop-down menu, select “Critical Points.” This creates the frame in the plot.

RESIZING: Resizing the critical points list is done in two ways: either selecting a width in the sub-panel width drop-down menu (height is determined by the content of the list itself), or by sliding the “Outer Scale” slide control on the right. In addition, a frame’s column widths may be altered with the proxy grid just below the plot window.



RESOLVING TEXT OVERLAP: The critical points list, like many of the other informational list-based frames in the Plot Designer, may display overlapping text and numbers when initially placed. This is resolved in three ways:

- Resize and/or change the font by clicking the “Font” button.
- Enlarge the frame by increasing width in the sub-panel.
- Resize the frame and/or its components in InkScape™:

InkScape™ allows each of the elements in a frame to be resized and manipulated, so resolving individual instances of text overlap is as easy as clicking on the trouble line and resizing it.

CRITICAL POINTS - PROP3				
Comment	MD	Inc	Azm	T
Surface location @ 503558.60 Ft Easting, 739180.35 Ft Northing	0.00	0.00	1.54	500
Begin Build @ 5000.00 MD, 2.50°/ 100 Ft	5000.00	0.00	24.50	34.00
Begin Build @ 0.00°/ 100 Ft	5980.00	24.50	34.00	595
Begin Hold @ 25.00°, 34.00° Azm	6000.00	25.00	34.00	596
Begin Drop @ -2.00°/ 100 Ft	8009.50	25.00	34.00	778
Begin Hold @ 0.00°, 188.13° Azm	9259.51	0.00	188.13	906
PBHL @ 10000.51 Ft TVD	10259.50	0.00	188.13	1000

NOTE: InkScape™ will not alter the actual information itself. Such changes must be made in the project itself in HawkEye’s main interface or in the Plot Designer editing field below the preview window.

CRITICAL POINTS - PROP3				
Comment	MD	Inc	Azm	T
Surface location @ 503558.60 Ft Easting, 739180.35 Ft Northing	0.00	0.00	0.00	
Begin Build @ 5000.00 MD, 2.50°/ 100 Ft	5000.00	0.00	1.54	500
Begin Build @ 0.00°/ 100 Ft	5980.00	24.50	34.00	595
Begin Hold @ 25.00°, 34.00° Azm	6000.00	25.00	34.00	596
Begin Drop @ -2.00°/ 100 Ft	8009.50	25.00	34.00	778
Begin Hold @ 0.00°, 188.13° Azm	9259.51	0.00	188.13	906
PBHL @ 10000.51 Ft TVD	10259.50	0.00	188.13	1000

6. Geodetics, Magnetics and a North Arrow


The Geodetics, Magnetics and North Arrow frames all have identical sub-panel controls, and they are among the simplest of all the frames that can be added to a plot.

ADD THE FRAME: To add any of these frames, click the “Add Frame” button in the main control panel of the Plot Designer, then select any of the bottom three selections from the “Frame” drop-down menu in the sub-panel.

FRAME FEATURES: The user may control background, font and frame color, as well as height and width of the frame. If a font size or type becomes larger than the background of the frame itself, there may be clipping. This is resolved by increasing the dimensions of the frame size. The Inner Scale slider is inert, but the Outer Scale slide controls the overall size of the frame. Click “SAVE” to save the current settings to the default for that particular kind of frame.



RESIZING AND PLACING: Although resizing is mostly done in the Plot Designer, fine-tune resizing and placement is done in InkScape™. (“Edit w/InkScape™” button).



The Geodetics, Magnetics and North Arrow frames all have an identical sub-panel control set. These feature controls are the simplest of all the frames.

g. Add Frames: Screenshots


There are two special frames that can be added to the plot which take images from the 3D space. The Multishot will take four screenshots of a single point, and the Last 3D View will take the very last 3D view that you see before the Plot Designer is opened.

1. 3D Perspectives (Multishot)


HawkEye™ can take four snapshots of the same 3D space from the four cardinal directions and place them in a plot. To do this, the user must align the 3D window view to the desired portion of the curve to be captured. Once the Look-at Point is positioned to the desired place, select the snapshot mode in the “Mode” drop-down menu just under the 3D window. The choices are Vertical M.S., Custom M.S. or Snapshot.



VERTICAL M.S.: This mode takes four screenshots of the current Look-at Point from a flat angle, looking straight across. It is essentially a 3D vertical section view of the Look-at Point from 0, 90, 180 and 270 degrees azimuth.




CUSTOM M.S.: This mode will take four screenshots of the current Look-at Point, but from any inclination up or down that the POV is currently positioned at. The shots are still taken with the north, south, east and west direction.



SNAPSHOT: This mode allows the user to take a single screenshot of the currently displayed view in the 3D window to later load as a graphic in the Plot Designer. When taken, it requires the user to enter a file name for the snapshot.

TAKE THE SHOTS: Once the multishot mode is selected, click the Snapshot icon to the right of the drop-down menu.  This will take the four shots in the case of the Vertical and Custom M.S. and the single shot if the Snapshot mode is selected.




SELECT THE SET: For Vertical M.S. and Custom M.S. modes, up to ten different sets of shots can be saved. After taking the shot, the Graphics Set prompt will appear. Choose the slot to save the current set to, from 1 to 10. This set of screenshots is later chosen in the 3D Perspectives sub-panel before loading into the plot.

Vertical Lines (droplines) can also be added here to each of the curves with the checkbox at the bottom. They would be generated here and saved permanently in the screenshots.

3D PERSPECTIVES FRAME: Launch the Plot Designer  from the top left of the main screen.

The Multishot frame is treated as a generic frame, so to add it, just click “Add Frame” in the main control panel. Then select “3D Perspectives” from the “Frame” drop-down menu. This will immediately generate the multishot frame in the plot window on the right.



The frame is called “3D Perspectives” because the sub-panel allows for the multishots as well as a snapshot to be loaded into the plot.

Once the frame is created, the multishot sub-panel will allow for certain setting adjustments. The colors can be adjusted by clicking the circle to the left of the color labels.

PLACEMENT: The 9-circle grid on the top right will control the general placement of the graph. However, for fine-tune placement (as well as resizing), InkScape™ is used. This grid is only for rough draft placing.

RESIZING: The Width drop-down menu is the primary way to resize the multishot frame, whereas height does not control the size nearly as much. The Outer Scale slider control will shrink the frame while keeping aspect ratio. To further resize this screenshot frame, launch InkScape™ by clicking the “Edit w/ InkScape™” button in the main control panel above.

LAYOUT: Select “Horizontal” to line the four screen shots in a row on the plot. “Vertical” will stack them in a column. “Rectangle” is the default and will arrange them in a 2x2 orientation.



TYPE: Select either Ver. MS, Cus. MS or Snapshot in order to instantly change the set of screenshots displayed in the frame. HawkEye™ will pull the set from the type as they were captured in the 3D space. There will be no changes to the frame if a screenshot set for that type has not been taken yet.

SET: This drop-down menu allows the user to select the graphic index 1 through 10, loading the respective index into the frame itself. These indexes are available for Vertical M.S. and Custom M.S. and the prompt to choose the index always appears after taking the shot in the 3D space.

IND AND CAPTION: This drop-down menu selects the “index” from 1 to 4, selecting the caption field to be edited. The captions under each screenshot can be edited by selecting a number from this menu and then editing the text in the “Caption” field. (The default is: 1 -“North View,” 2- “East View,” 3- “South View,” and 4- “West View.”) Click on the “FONT” button to edit the font characteristics of the captions.

AUTO SCALE: Checking this box will attempt to resize the SNAPSHOT, if there is one loaded in the plot, into a size comparable to surrounding loaded screenshots.

FILE: This field becomes active when the “Snapshot” Type is selected. Click the “Browse” button to load either the snapshot taken from the 3D space or ANY graphic file to load. NOTE: To load custom graphic files, the “Add




Graphic” button in the Plot Designer main control panel will launch a dedicated picture frame sub-panel.

SAVE: Click the “Save” button to lock in the current settings as default for every time a new 3D Perspectives (“multishot views”) frame is created in the Plot Designer.

2. Last 3D View

Any time the Presentation Plot Designer is launched from the main screen, it grabs the last 3D view that is being displayed in the 3D window. To customize the screenshot itself before launching the Plot Designer, the user simply resizes the window and calibrates the 3D view itself to reflect whatever view is desired. Once set up, just click the Presentation Plot icon at the top.



The next step, once inside the Plot Designer, is to click “Add Frame” and select “Last 3D View” from the “Frame” drop-down menu of the new sub-panel. This will automatically drop the 3D screenshot into the plot.

TEMPLATE: In order to always have the Last 3D View dropped into a plot, just add this frame to a plot and save as a template. The Plot Designer will treat that space as any other template-designed frame and fill it in with the actual last 3D view displayed.

RESIZING: Height and width can be changed with the drop-down menus. The “Outer Scale” slide control will resize the graphic as a whole. Further fine-tune resizing can be done in InkScape™. (Launch InkScape™ by clicking the “Edit w/ InkScape™” button in the main control panel on the top left quadrant of the Plot Designer).



PLACEMENT: The 9-circle grid on the top right will control the general placement of the graph. However, for fine-tune placement (as well as resizing), InkScape™ is used. The grid is only for rough draft placing.



h. Finishing With InkScape™

The InkScape™ program is installed with HawkEye™ as a companion program which acts as an empowered module for extremely professional plot layouts. Although the program installs with HawkEye™, you may also download it to any computer as a standalone SVG application by going to <http://InkScape.org/download>.

WHAT IS INKSCAPE?


Inkscape is an open source vector graphics editor, with capabilities similar to Illustrator, CorelDraw, or Xara X, using the W3C standard Scalable Vector Graphics (SVG) file format.

Inkscape supports many advanced SVG features (markers, clones, alpha blending, etc.) and great care is taken in designing a streamlined interface. It is very easy to edit nodes, perform complex path operations, trace bitmaps and much more. Its creators also aim to maintain a thriving user and developer community by using open, community-oriented development. As such, it has become an extremely polished SVG editor that is the product of tens of thousands of dedicated manhours over the course of ten years.


1. Primary Functions

InkScape™ is used in HawkEye™ primarily to RESIZE plot frames and the alphanumeric elements within, as well as PLACE those frames in exact positions for a fine-tuned plot layout.


OPENING INKSCAPE™: You can open InkScape™ at any time from the Plot Designer by clicking on the “Edit w/ InkScape™” button. This will launch InkScape™, but make sure to have all frames of the plot already placed. Such elements can only be added in the Plot Designer. InkScape™ allows for the adding of additional graphics and comments, as well as editing text and numbers, but is not integrated with the database information of a project in HawkEye™.



When InkScape™ opens, all of the elements that have been placed in the Plot Designer will appear in the same paper size but in SVG layers. Although it may appear a jumble, now each of the elements can be moved about freely and precisely. If the plot in InkScape™ appears small, hit “5” to automatically fit the plot to screen width and height.




LAYERS: The SVG elements (plot frames and graphics) in InkScape™ are treated as sets of layers, which can be selected individually, in groups or even linked together. Select a layer by double-clicking on it in the graphic window. By double-clicking again and again on an element, different layers within that element are selected. Double-click on any blank space in the graphics window to get back to the root layer. The layer indicator appears at the bottom left of the screen.




ZOOM: Select the magnifying glass icon on the left side of the screen to go into zoom mode and simply draw a box over any portion of the graphics window to zoom into that area. To get back to the whole page view, hit “5” on the keyboard. Advanced zoom preferences can be explored in the Preferences panel (File>Preferences or Shift+Ctrl+P) which allow for things like zooming with the scroll wheel.

MOVING OBJECTS: To move an object, it must be selected. Since InkScape™ works in SVG, there are often multiple layers to each object. A singular element may be selected when trying to move an entire object, resulting in fragmentation. When this occurs, simply hit Ctrl+Z to undo the move, then double-click on the object until it is selected in its entirety. After a little practice, this becomes second nature. And sometimes particular layers of a list or grid will need individual nudging, so it’s a valuable tool. One hint is to keep an eye on the layer name at the bottom and get accustomed to how the layers are labeled.




RESIZING: When an object is selected, arrows will appear at its corners and sides. These are “handles” which can be clicked on and dragged to resize the object. One major issue with resizing an object is the aspect ratio. (Ctrl+Z to undo unwanted resizings). Inkscape™ has two methods of retaining aspect ratio when resizing an object. 1) Hold down SHIFT while dragging a corner handle of an object, or


2) Click the “Lock” icon at the top while the object is selected. This will permanently lock the aspect ratio for that selected object. Be sure that the entire object is selected and not just one layer in it.



GROUPING: Two or more objects can be “grouped” or locked in an orientation and moved as one object. This is useful for when getting graphs placed on top of each other and not wanting to re-place the graphs when moving them around the plot. To group objects, they must all be first selected at once. To select multiple objects, select one then HOLD SHIFT while selecting another. Or draw a box over all the objects to be selected with the black arrow selector tool and they will be simultaneously selected. Then as a final step, click the “Group” icon at the top of the page to marry all the objects together. Any group will be moved and resized as if it were one object.



SENDING LAYERS TOP AND BOTTOM: Since all objects are layers, they are stacked from front to back, or “top” to “bottom.” Layers that are closer to the top are displayed when overlapping any layers that have a lower status or designation. In laying out a complex plot, there will be objects that overlap each other and usually the smaller elements will need to be on top so that they are not covered by the larger ones. To control the layer status of an object, just select it, then go to the four icons at the top of the screen. They will either 1) Lower selection to bottom, 2) Lower selection down one level, 3) Lower selection up one level, or 4) Lower selection to top.



ADDING TEXT AND NUMBERS: Inkscape™ allows for the adding of comments, as well as the editing of text fields within lists that have been added from HawkEye’s



Plot Designer. The first step is to set up the font and size settings. Do this by clicking on the Text and Font panel box at the top of the page or hit Shft+Ctrl+T. Click “Set as default” in the panel to make those settings permanent.


Then select the Text Tool on the bottom of the left side (or hit F8). As with all specialized tools in InkScape™, the cursor will change to indicate which mode the user is in. Here the cursor is a crosshair with the letter “A.” Use the Text cursor to draw a box on the graphics window. This will create a text box in which text can be entered.




PASTING TEXT: Once this text box is drawn, simple text can also be pasted into the box from other programs. But note, InkScape™ will only display simple text and none of the more complex formats. Any changes to font, size and color must be done after pasting into the textbox.

Color of the text can easily be changed by 1) selecting the text box itself, then 2) clicking on a color along the color palette bar that stretches along the bottom of the screen.

Editing the text field within a list is as simple as clicking on that field and typing in or deleting whatever data is there. But remember that InkScape™ is not integrated with the project database information itself, so whatever data changes are made in InkScape™ are neither saved to the project nor verified by HawkEye™ in any way.



ALIGN TOOLS: To make sure that any or all objects are aligned correctly, select any or all objects and click one of the alignment options found on the right-hand side of the screen. If the options are not displayed, then hit Shift+Ctrl+A for them to appear.



PRINTING: The recommended way to print the final plot is to first SAVE AS A PDF (File>Save As, then select “Portable Document File” as filetype). After saving the file as such, open it with Adobe Reader, which is free and should be installed on any computer, and select print options from there.


2. Tips and Tricks

a. Setup Tips


As with HawkEye™, spending a little time to explore Inkscape™ will pay back in spades. In the case of Inkscape™, the better one is with its interface, the more advanced and professional-looking a plot will have the potential to be. There are many great tutorials online for Inkscape™. A basic starter is found at <http://Inkscape™.org/doc/basic/tutorial-basic.html>. There are certain preferences and tricks in Inkscape™ which grease the wheels navigation and of enhancing plot-design. Here are a few setup tricks:

SCROLL ZOOM: Zooming in and out with a scroll wheel is convenient and can save a lot of time with large plots. Since HawkEye™ users should be using a hyperscroll mousewheel, the zooming can become a convenient second-nature activity. But the option needs to be turned on.

All preferences are found under File>Preferences (Shift+Ctrl+P), and each of them is divided into categories on the left column in the preferences panel. To turn on the Scrollwheel Zoom feature, click on “Scrolling” in the Preferences window. Then check “Mouse wheel zooms by default.” Another useful option to turn on here is LEFT MOUSE BUTTON PANNING. Just check the box labeled “Left mouse button pans when Space is pressed.” This option will do just that.



FIT TO PAGE: Set Inkscape™ to always fit to page when opening by going to File>Preferences (or Shift+Ctrl+P), then in the Preferences scroll down the left column to “Windows” and check the “Zoom when window is resized” box. Also remember, hit the number “5” on the keyboard to autofit everything to the screen in its entirety. You may also click on the “Fit to Page” icon at the top of the screen.





b. Drop Shadows

Adding graphical flourishes to plot objects is the whole point of InkScape™ in HawkEye™. One essential such embellishment is the drop shadow, which gives a frame a sense of depth.

To add shadow to a frame, first select the frame by clicking on the Rectangle Selector, then with the plus-rectangle cursor, click on the frame.



Once the frame is selected, go to Filters>Shadows and Glows>Drop Shadows. This opens the Drop Shadow dialogue in which the shadow can be highly customized. But the default drop shadow is a fairly decent as it is. Click “Apply” and the drop shadow will appear “behind” the frame. It is actually part of the layer and will move/resize with it. To edit this effect, just select the frame and go back to the Drop Shadow dialogue.




Drop shadows will add a sense of depth to any frame, enhancing the plot with a 3D feel. Many other effects are found under the “Filters” menu in Inkscape.


c. Arrow Pointers

Complex parametric curves (Bezier curves) can be dropped onto a plot in InkScape™ as arrows to simulate the organic look of handwritten marker notation. This effect is useful for callouts and has the advantage over actual marker notations because the arrow and comments are both cleanly defined and editable before printing.

To make such an arrow pointer, first select the Bezier Drawing Tool on the left side of the screen. Once selected, click on the screen once (1) with the tool to set the first point, then click a second time (2) to place the Bezier pivot point. Finally click a third time (3) after bending the hypothetical curve to create the end point. The straight line will disappear and only the curve will remain.




Once the curve is created, its style can be edited in the Fill, Stroke Paint and Stroke Style panels on the top right corner of the screen. This panel is available for many objects in InkScape™ and provides a wide array of customization options. Select the color under the Stroke paint tab.



To make the curve an arrow pointer, it is simply a matter of selecting a “Start Marker” and “End Marker” under the Stroke style tab. The choices are many under these drop-down menus and just by changing the endings a curve can transform into many different objects.

EDIT THE CURVE: Click on the “Edit Path Nodes” icon just below the black arrow icon on the top left of the screen, or hit F2 to go into “Edit Path Nodes” mode in order to reactivate the draw nodes of the curve. Now by dragging the nodes around, the arrow is re-drawn on the fly, but will retain its start and end markers. This is necessary for precision placement on a plot.

ADD TEXT: To add a text box, click on the “Text” icon on the bottom left, or hit F8 to go into Text Mode. Then draw a box onto the graphics window and type in any desired comments. This box can be placed at the end of the pointer to create a callout.



SAVE THE ARROW POINTER: Select the entire arrow, then go File>Save As and save the arrow as a .SVG file. This will save the arrow as an importable object that can later be added to other plots.

To **IMPORT** the arrow, just go File>Import... (Ctrl+I), then select the file from wherever it was saved. Editing the direction of the arrow in new plots simply requires hitting the F2 button to activate the Edit Nodes mode and then dragging those nodes around until it is shaped just right.

VI. BHA/DAILY




The BHA/Daily module in HawkEye is where users can input the following information:

- New/Edit Job IDs
- Tool Lists
- BHAs
- Daily Items

It is also where Daily, BHA and End-of-Well reports are generated. This chapter will cover the basic layout of the module, as well as some tips and tricks, but not exhaustively cover every single feature of the module.


Launch the BHA/Daily: Click on the “BHA Daily” icon at the far right of the row of icons in the Home tab of the main screen.




The layout of this module is broken down into seven main tabs at the top, as well as a brief “File” menu accessed from the top left.

1. File Menu


Export Current Job to .hwkjob: This allows you to save all BHA/Daily information from the current job (as entered into and displayed in the BHA/Daily module) to a special file. That file can then be imported back into HawkEye.



Importing a .hwkjob Job file: To import such a file, you need to be in the main screen of HawkEye. In the Data Tree, right-click on the curve that you want to import the job info to and select “Import Job From .hwkjob File.” **NOTE:** There is nowhere inside the BHA/Daily module to import a .hwkjob file. You have to be in the main screen and import it from the curve’s right-click menu, as show here.



Import a WinSurv2 .mdb database: You can bring in a legacy .MDB (Access 97 database) file that was created with PDT’s WinSURV2 program. The dialogue that opens will allow you to select specific jobs from that .MDB that will be imported and saved in the current HawkEye database.




1. Click “Browse” to select the .MDB from your computer.
2. Click “Load Jobs Below” to load the database into this dialogue.
3. Check or uncheck as desired in the “Import/Overwrite” column.
4. Click “Import Jobs” to bring in the selected jobs.

2. Job Overview

Current Job: When opening the module, the name of the current job that is associated with the current curve is shown in large white letters against a black background.

Jobs List: The column on the far left displays all jobs contained in the current HawkEye database. They are organized in alphabetical order under each Company.




Edit Current/Selected Job: The middle column displays whichever job is selected on the right. NOTE: This is not necessarily the current job. By clicking on any job other than the current one, the program will warn you that you are VIEWING another job. You can edit this job's basic information in the center column here, but it is not going to be the job associated with your current curve.


Current Job #	Ham 111-99-16B-201		Change Job ID
Company	EnerPlus		
Location	Beginnings Pad		
Rig	True 39		
Well Name	Ham 111-99-16-201		
API Job No.	3305309597	AFE	DRL200058
State/Province	ND	County/Parish	McKenzie
Contract No.		Field	Antelope
Work Order		Township	151N
Bid Number		Section	09
Job Type	Directional - LWC	Range	94W
Job Status	Active	Country	U.S.A.
Job Comments			

BHA/Daily Reports: On the right is the BHA/Daily's entire reporting module. It is repeated again in the last main tab of the module labeled "Reports," but is all here on the first tab as well. There are two formats of reports that you can generate:

- **PDF Reports:** The list of reports with the black background listed up front are all PDF reports that will show a preview when you click on them.



- **Excel Reports:** Click on the blue “Export Excel” button to open the report assembler that produces Excel-spreadsheet format reports.



1. Select the report that you would like to generate. The preview on the right does not contain the specific information of your report. It only shows you the format of the report.
2. Select the specific information for that report (e.g. date range, BHA number, etc).
3. Click Add Sheet(s). This will add the report into the bottom left black box titled “Your Report:”

By repeating Steps 1-3, you can assemble a multi-tabbed spreadsheet report. When you’re done compiling the kind of custom report that you want, click “Export to Excel” at the bottom.

3. Tool List

The Tool List displays all tools related to a job.

Current Job: Ham 111-99-16B-201

Job Overview | Tool List | BHA Manager | BHA Builder | DailyManager | Daily Items | Reports

On-Site Tools Only | Show Only Group: All ToolGroups | Copy From Previous

Tool Group	Tool Type	Serial Number	Description	Manufacturer	OD (In.)	ID (In.)	Length (Ft)	Fishing Neck (Ft)	Top Connection	Bottom Connection
Tool Group: Other (16 items)										
Other	Pin Down	113894-2	5" Agitator	NOV	5	2	10.95		XT-39	XT-39
Other	Pin Down	169-0004	5" Shock Sub	Stabil-Drill					XT-39	XT-39
Other	Pin Down	RIG	5" HWDP - 45 Joints	RIG	5	2	1382.48		4 1/2 IF	4 1/2 IF
Other	Pin Down	Rig 2b	15 Stands D425 HWDP	Quail	4 1/2	3	1392.54		D-425	D-425
Other	Pin Down	Rig 3	30 Stands of D425 Drill Pipe	Quail	4 1/2	3	2835.29		D-425	D-425
Other	Pin Down	Rig X	1 Jt D425 DP	Rig	4 1/2	3	31.49		D425	D425
Other	Pin Down	RIG X2	2 Jt D425 DP	Rig	4 1/2	3	62.97		D-425	D-425
Other	Pin Down	SD105008	Lift Sub - 4 1/2 IF	Stabil-Drill	0	0	0		(NONE)	4 1/2 IF
Other	Pin Down	SD112120	Lift Sub - 4 1/2 IF	Stabil-Drill	0	0	0		(NONE)	4 1/2 IF
Other	Pin Down	SD112257	Lift Sub - 3 1/2 IF	Stabil-Drill	0	0	0		(NONE)	3 1/2 IF
Other	Pin Down	SD118323	Lift Sub - 3 1/2 IF	Stabil-Drill	0	0	0		(NONE)	3 1/2 IF
Other	Pin Down	SD802390	5 7/8" 8 Blade PDC Phantom Reamer	Stabil-Drill	4 15/16	2 3/4	6.06		D-425	D-425
Other	Pin Down	SHTL0500-0031	Shock Sub	NOV	5	2	10.95		XT-39	XT-39
Other	Pin Down	W1378960-1	5" Agitator	Stabil-Drill					XT-39	XT-39
Other	Pin Down	W1543969-1	Agitator	NOV	5	2	11.2		XT-39	XT-39
Other	Pin Down	W1838010-6	5" - Shock Sub	NOV	5	2	11.14		XT-39	XT-39
Tool Group: Bits (6 items)										
Bits	PDC	13664973	6" GT54K (3-15's, 4-14's)	Security	6	2	1		NC35	(NONE)
Bits	PDC	5319873	8 3/4 DD506VTWX (6-16's)	Baker	8 3/4	2	1		4 1/2 REG	(NONE)

Add Tool | Delete Selected Tool | Shipping Ticket

- For best results, after clicking “Add Tool” and entering information on a new tool, fill out ALL columns of the new row.

4. BHA Manager

The BHA Manager is used to oversee all BHAs run on a job.

Current Job: Ham 111-99-16B-201

Job Overview | Tool List | **BHA Manager** | BHA Builder | DailyManager | Daily Items | Reports

Selected BHA 1 of 5

BHAs for This Job

1
2
3
4
5

Days This BHA Ran

March 2022

Su	Mo	Tu	We	Th	Fr	Sa
27	28	1	2	3	4	5
6	7	8	9	10	11	12
13	14	15	16	17	18	19
20	21	22	23	24	25	26
27	28	29	30	31	1	2
3	4	5	6	7	8	9

Last Casing Info

Casing OD: 9 5/8
Shoe@: 2105
Hanger@: 0

Expected Performance

Start Depth	100
End Depth	2150
Start INC	0
End INC	0
Drill Hours	0
ROP	N/A

Motor Data **Rotary Steerable** **More Motor Data**

Description	8" 1.50 ADJ, 7/8 Lobe, 4.0 Stage, 0.16 Revs		
BHA Type	Steerable Assembly	NB Stabilizer	8.86
Motor MFG.	NOV	Revolutions/gal	0.16
Model	ERT	Rotor Jet	0
Bend	1.5	Proposed BUR	8
Bit to Bend	7.2	Real BUR	0
Pad O.D.	8.35	Avg. Differential	
Lobe	7/8	Off Bottom Diff.	0
Stages	4	Stall Pressure	0

Bit Data

Bit Serial #	4012202	Description	13 1/2 - Varel R616		
Bit Length	1.5	O.D.	13 1/2	Connector	6 5/8 REG
Type of Bit	PDC	Bearing Type	Fixed Cutter	TFA (in ²)	3.34
# of Jets (32)	9	22	22	22	22
Bit MFG	Varel	IADC Dull Bit Code			
Bit Number	1	Cutting Structure			
Observed Condition of Bit		Inner Row	Outer Row	Dull Char.	Location
		1	1	WT	A
				X	I
				CT	TD

Sensor Distances

Mag to Gravity	3
Bit to Sensor	53
Bit to Gamma	47
Bit to Resistivity	0
Bit to Porosity	0
Bit to DNSC	0
Bit to Gyro	0

Comments

Bit to Sensor: 53'
Bit to Gamma: 47'
Max Diff: 1390
Make Up Torque
Max Rotary: 80 RPM
Max Torque 22,960
Bit: 46,000
Bit Cl: 1"

- Casing Data is one of the few data points that can be entered from the main screen of HawkEye, under the Edit tab.
- The “More Motor Data” button contains a lot more parameters that can be entered for any particular motor.

5. BHA Builder

The BHA Builder is used to build up individual bottom hole assemblies.

Current Job: Ham 111-99-16B-201

Job Overview | Tool List | BHA Manager | **BHA Builder** | DailyManager | Daily Items | Reports

Select BHA: Copy to a new BHA

Item #	Tool Group	Tool Type	SerialNumber	Description	OD (In.)	ID (In.)	Length (Ft)	Top Connection
1	Bits	PDC	4012202	13 1/2 - Varel...	13 1/2	2	1.5	6 5/8 REG
2	Motors	Steerable Slick	800-36-230	8" 1.50 ADJ, 7/...	8	2	29.31	6 5/8 REG
3	X-Overs	Pin Down	SD118219	Bell Sub XO - 4...	8 3/16	2 3/4	3.1	4 1/2 IF
4	Muleshoes	Standard	SD120113	6 3/4 - UBHO	6 1/2	3 1/4	3.76	4 1/2 IF
5	DC	DC Pin Down	SD51728	6 3/4 - NMDC	6 13/16	3 1/4	28.48	4 1/2 IF
6	DC	DC Pin Down	SD50517	6 3/4 - NMDC	6 11/16	3 1/4	28.59	4 1/2 IF
7	X-Overs	Pin Down	QT164496	XO - D425Box...	6 9/16	2 15/16	4.07	D-425

BHA Length (Ft): 98.81

Add BHA Item | Delete Selected Item



- Start with the Bit
- If you plan on using the Hydraulics module in the program's main screen (at the end of the row of icons on the Home tab), be sure to add HWDP at the end of your BHA here.

6. Daily Manager

The Daily Manager is for seeing all the days of where a job has activity, as denoted by red circles on the calendar in the top-middle of the screen. You can also track daily costs on the top right.

Current Job: Ham 111-99-16B-20I

Job Overview | Tool List | BHA Manager | BHA Builder | **DailyManager** | Daily Items | Reports

Copy Previous Day's Personnel | End of Reporting Day: 24:00 | Costs for: March 10, 2022 (Total cost = \$0.00) | Copy Previous Day's Costs

Lead Directional: Justin Rogers
 Second Directional: Scott Peterson
 Directional Co.: Badger Consulting
 Mud Company:
 Company Man: Rod / Darren
 MWD Engineer 1: Ishvan
 MWD Engineer 2: Alex Langley
 DD Trainee:
 MWD Trainee:
 Geologist:
 Inclination In: Inclination Out:
 Azimuth In: Azimuth Out:

March 2022

Su	Mo	Tu	We	Th	Fr	Sa
27	28	1	2	3	4	5
6	7	8	9	10	11	12
13	14	15	16	17	18	19
20	21	22	23	24	25	26
27	28	29	30	31	1	2
3	4	5	6	7	8	9

Day's Comments

Add Cost Item | Delete Cost Item

Thursday, March 10, 2022 | Add New Day | Clear Day

BHA #	MWD #	From Time	End Time	Activity Code	Comment	Start Depth (Ft)	End Depth (Ft)	Delta Depth (Ft)	ROP (Ft)	WOB (US Tons)	TFO	RPM	Surface Torque (Ft-lbs)	SPM	Flow Rate (GPM)	SP
4	3	00:00	03:00	TIH	TIH	9942	9942	0	0	0	0	0	0	0	0	0
4	3	03:00	03:28	Other	Wash to bottom	9942	9942	0	0	0	0	0	0	0	0	0
4	3	03:28	04:30	Drilling	Drilling - WOB: 25 GPM: 550 RPM:...	9942	9993	51	49.35	25	0	20	11	188	550	
4	3	04:30	04:45	Survey & Conn.	Survey & Conn.@MD 9945_Inc 14...	9993	9993	0	0	0	0	0	0	188	550	
4	3	04:45	04:56	Drilling	Drilling - WOB: 25 GPM: 550 RPM:...	9993	10004	11	60	25	0	20	12200	188	550	

- Make sure your “End of Reporting Day” time is set to the right time for your job (top left of the screen)
- Click on any day in the calendar with a red circle to see all of that day’s entered daily activities at the bottom.

7. Daily Items

The Daily Items are where you enter daily activities.

Current Job: Ham 111-99-16B-20I

Friday, March 18, 2022

Buttons: Add New Day, Clear Day, Link to Surveys

BHA #	MWD #	From Time	End Time	Activity Code	Comment	Start Depth (Ft)	End Depth (Ft)	Delta Depth (Ft)	ROP (Ft)	WOB (US Tons)	TFO	RPM	Surface Torque (Ft-lbs)	SPM	Flow Rate (GPM)	SP
0	0	00:00	00:15	Other	Run Liner / Stand By	21219	21219	0	0	0	0	0	0	0	0	0

Buttons: Add Activity, Delete Selected Activity

- After clicking “Add Activity” (bottom left), the best practice is to fill out all information for that row through End Depth.

VII. WELL PLANNING

TWO MODES: There are two overall modes in HawkEye. The Field Mode is default and available in both versions. It is used for directional drillers who are not creating much in the way of complex proposals or well plans. Whereas the Well Planning Mode, available only in the Well Planning Version, is used to create complex well plans.

To get into the Well Planning Mode, you need the Well Planning Version of HawkEye.

VERSION OF HAWKEYE	MODES AVAILABLE	
	Field	Well Planning
Field Version		
Well Planning Version		

TWO DIFFERENCES BETWEEN THE TWO VERSIONS

1. **PRINTING PLOTS:** The difference between the Field Version and Well Planning Version of HawkEye™ with plotting is that only in the Well Planning Version will the larger wall plot sizes be available for printing and exporting. Only the smaller paper sizes are available in the Field version since it is assumed that users of the Field Version will not need a plot printout larger than A3.


Exclusive Well Planning Version print sizes include: A4, A2, 11x17, ISO A0-2, ISO B1, B1-B4(JIS), ARCH A-E1, Folio [8.5x13in], 22x36in, 24x48in, 24x60in, 24x72in, 24x84in, 24x96in, 24x108in, 36x42in, 36x60in, 36x72in, 36x84in, 36x96in, 36x108in and PostScript Custom.

2. **WELL PLANNING:** The principle difference to keep in mind between the Field Version and Well Planning Version of HawkEye™ is that, although they both have the same arsenal of projections which can be appended end to end, only in the Well Planning Version can a projection be edited at any segment and tweaked in random fashion.

In other words, in the Field Version, only the last appended projection can be edited, so that in order to edit a part further up the curve, the user must delete all appended parts of the curve made subsequent to that higher up part before editing it. In Well Planning, the proposal is “poseable,” a model with hundreds of points of articulation.

1. Well Planning Control Panel

The Well Planning Mode is activated by clicking on the “Well Plan” tab at the top of the main screen. (This Icon does not appear in the Field Version of HawkEye™.)



The Control Panel that appears just below the tab contains a number of powerful tools, most of them centered around profiles that contain sets of projections. When this tab is selected, this is what is referred to as being in the “Well Planning Mode” as opposed to being in the Workspace, or Field Mode. In the “Well Planning Mode,” the curve you are working with is a temporary curve that is multicolored, representing the different projection segments that constitute the proposal.

In order to commit this curve as the proposal curve it is necessary to click the light blue “Apply to Prop.” Button at the far right. The ‘temporary’ curve that constitutes the projection segments is saved to the database so that should you desire to make changes at a later time you can return to the Well Planning Mode and alter what you want. Once you click the “Clear Proj.” button, however, this segmented curve is erased permanently.

Workspace/Field Mode View: Click on any main tab besides “Well Plan” to close the Well Planning control panel and brings HawkEye™ back into the default Field Mode.


INDIVIDUAL PROJECTIONS: You can add projections one-by-one to a well plan by selecting it from the “Projection” dropdown menu,” then putting in the parameters for that projection, then clicking “Add.” Depending on the projection you select, you may need to designate a target first.



Select the origin of your plan, either from surface (Well Head) or from an existing curve (WellPath).

KOP: This turns on the search for KOP flag for either the Aligned well, or the Slant well. Be aware that this can be a time consuming process, particularly with an Aligned well since there is a great deal of iteration that the computer does in order to find a solution.


DEFAULT PROFILES: The special controls of the Well Planning version allow the user to load well profiles, as well as save new ones. The default profiles are the most common type of profiles and are designed so that all the user need do is load the profile and fill in the white background grid cells, perhaps select a target if it isn't already selected, and have a solution.




The “Profile Name” drop-down menu contains several default profiles to choose from, and will also contain any saved user-created profiles. The default profiles are:

- **Simple 2D S-well** (w/special profiler tool)
- **Simple 2D Slant** (w/special profiler tool)
- **Find KOP Slant**
- **Find KOP Aligned**
- **Default Slant**
- **Default Aligned**
- **Default Horizontal**

LOAD PROFILE: Once a profile is selected from the drop-down menu, click “Load Profile” to the right of the menu.




If a “targeted” projection (Slant, Aligned, BOT and Horizontal) is selected, then HawkEye™ needs a First Target. Designate a target as First Target by right-clicking on one in the 3D space icon and hitting “Set as the First Target,” or by clicking on the large Target icon and designating First target from the dropdown list.



Then click “Load Profile” again.

SAVE AS NEW PROFILE: Click this button to save the current projection set, as displayed in the 3D and List Panel at the bottom of the screen, as a profile that can later be conveniently invoked as a whole. Any new profiles are saved to the current database, and they become available in the “Profile” drop-down menu.



WELL PLANNING CRITICAL POINTS (CP): In the Well Planning Mode, the Well Planning CP tab is displayed, allowing the **display of each projection of a curve in a list**. For each projection type, there are a number of columns of information in which the WHITE cells can be edited independently of other parameters.

3D	WellPlan CP	VS	Top	Proximity	Ladder	Alerts									
No	Projection	Target	MD (Ft)	CL (Ft)	Inc Deg	Azm Deg	RKB TVD (Ft)	NS (Ft)	EW (Ft)	Easting (Ft)	Northing (Ft)	VS (Ft)	DLS */100 R	TFA Deg	
1	Tie in	N/A	0.00	0.00	0.00	0.00	0.00	0.00	0.00	1422371.60	339264.71	0.00	0.00	0.00	
2	MD	N/A	100.00	100.00	0.00	0.00	100.00	0.00	0.00	1422371.61	339264.71	0.00	0.00	0.00	
3	Slant	N/A	1392.49	1292.49	38.77	165.94	1296.07	-408.29	102.29	1422462.04	338853.64	-408.29	3.00	0.00	
4	Slant	Default Target	13445.87	12053.38	38.77	165.94	10693.06	-7730.54	1936.71	1424083.93	331481.38	-7730.54	0.00	0.00	

The parameters for each projection in the well planning list are:

- Projection (type)
- Target
- MD
- CL
- Inc Deg
- Azm Deg
- EVD
- NS
- EW
- Easting
- Northing
- TVD
- DLS
- TFA Deg
- Comment

MAKE CHANGES: When a profile is loaded, it will have with it default values for KOP and DLS as well as other parameters. Any of these projections can be changed or nudged by finding the parameter in the Well Plan List Panel at the bottom of the screen, clicking on the field in question, and changing the number right there in the field. Changes to the projection are usually instantaneous, but are not automatically applied to the proposal. **NOTE:** For aligned projections, you must click “CALCULATE” after each change. After changes are made here, but before they are applied, they are still in the status of a projection.

Click on any projection in the List Panel at the bottom and its respective control panel will appear. Parameters in white may be changed in the special panel or in the List Panel. Click “Apply to Proposal” to lock in changes.

APPLY TO PROPOSAL: When it is decided that any changes made to a proposal are acceptable, click “Apply to Prop.” to integrate changes to the current proposal curve.

ADD NEW PROPOSAL: Clicking the “Add New Prop.” button will launch the “Add New Curve” dialogue, which can also be launched by right-clicking on a slot in the Data Tree. It will create either a Proposal or Survey curve under the current slot, and that curve can be assigned to any jobs from the database. The “Job” button here will launch the Jobs dialogue in which job information can be added and edited.

Add New Curve

Curve Name:

Job No: Job

Curve Type: Unit:

VSP (0-360): Color:

RKB: Apply RKB to all curves in the slot

Tie In Point

Tie In TVD:

Tin In NS:

Tie In EW:

Referenced Slot Coordinate

Northing:

Easting:

OK Cancel


Once this new curve is made, it will become the new “current” curve and a new blank slate onto which you can add wellplan projections.

PREVIOUS PROPOSAL CURVES: If you make a previous Proposal curve the current curve again, it will remember the last set of wellplan projections given to it.

a. Simple 2D S-Well Profiler


Within the Well Planning Control Panel, selecting the “Simple 2D S-Well” from the “Profile Type” pulldown menu will invoke the dedicated profiler for this well type.

The “Simple 2D SWell Profiler”:




FIRST TARGET: Since S-wells are “targeted projections,” a first target must usually be set. If a first target has not been set yet, find the target to be set either in the Data Tree, 3D space, right-click on it and select “Set as First Target.”

Or set it from the 1st Target pulldown list in the Well Planning panel.




LOAD THE PROFILE: Select the profile from the “Profile” dropdown menu. This is best done in every case AFTER designating target(s).



HOW TO USE 1ST TARGET: The top left option in the Profiler allows the user to either ignore First Target (for when creating an open plan) or treat it as the PBHL (Proposed Bottom Hole Location). When “Don’t Use” is selected, the profiler will *create* a target where the projection ends and call it “PBHL” by default.



S-CURVE PROPERTIES SOLVER: Throughout this colorful list of parameters, the important rule of thumb to keep in mind is that the fields in red cannot be changed, whereas the fields in white can be changed. These fields change depending on which solve mode is selected.



In the Solver, different fields are editable depending on which solve mode is selected (from the 6 radio buttons on right). Red fields are uneditable while white fields are editable. Click “Calculate” to register parameter changes.

The Solver has 10 different parameters which shape the S-Well. The properties are:

- **KOP-** The depth at which the first build in the S-Well begins.
- **Start Inc-** The starting inclination. It is always set to '0' and can't be changed for this type of plan.
- **Build Rate-** The degree of turn per 100 ft along the first turn.
- **Hold Angle-** Angle in degrees of the tangent / hold section.
- **Tangent-** Length of the tangent / hold section between the upper and lower curves. **If this is set to 0 and the radio button to the right is set, then the program will solve for a kick off point.**
- **Drop Rate-** Drop rate in degrees per 100ft or degrees per 30 meters. Note that this does not have to drop, it can also build if it is a horizontal well.
- **Entry Angle-** Degree at which the second turn ends. 0 degrees will make the curve going straight down at the end of the second turn.
- **Extension-** This is the distance of straight extension BEFORE the target and at the end of the drop of the second curve.
- **V. Section-** This is the closure distance or vertical section distance of the target point at the end of the proposal This can be a locked parameter with the "Locked" checkbox of the Well Properties just below the Solver. When this is locked it is in essence defining the target point, as opposed to an open solution in which the target pt would be defined by the solution.
- **Delta TVD-** Difference between the KOP and the Target TVD.

As changes and solutions are made, they are displayed in the vertical section view immediately to the right of the Solver, all color coded to the background color of the various solver parameters.


In addition, critical points data is displayed in spreadsheet format in the list panel at the bottom of the profiler. This allows the user to see details of the curve that are not always apparent in either the in-profiler VS View or Solver fields.

MD	Inc	Azm	TVD	EW	NS	VS	DLS	Comment
.000	.000	.000	.00	.00	.00	.00	.00	Surface
2000.000	.000	22.060	2000.00	.00	.00	.00	.00	KOP
3384.149	41.525	22.060	3266.12	180.28	444.86	430.00	3.00	End Build
5460.373	.000	22.060	5165.31	450.69	1112.15	1200.00	2.00	End Drop - Begin Hold
8295.068	.000	22.060	8000.00	450.69	1112.15	1200.00	.00	PBHL

WELL PROPERTIES: The “Target TVD” and “Well Direction” fields under this heading will only be activated if no target is used. To NOT use a target, just select “Don’t Use” at the top left of the profiler where it says “How to Use 1st Target.” The “Locked” checkbox will lock these parameters into place even other parameters are changed.

CREATE TARGET PLANE: Check this box in the Profiler to turn on a target plane in the 3D space. When the profile you make is sent to the 3D space, it will generate a target plane along the first straight tangent section. This target plane will remain even if the profile is cleared away.

CREATE WAY POINT TARGET: Check this box to automatically generate a target (default name: “Way Point”) at the beginning of the first turn in the S-Well. This target will remain even if the profile is cleared away. Example at right.



SEND TO 3D SPACE: This button acts as an “APPLY” button, porting all of the S-Well changes made in the Profiler into the 3D space. This option will be a prompt when clicking “OK” just in case the user forgets. When an S-Well is sent into the 3D space from the Well Planning Profiler, a Nudge projection is inserted for the first half of the first build.

This feature provides a sort of hinge, allowing the user to nudge the Nudge portion of the s-well and redirecting the entire curve left or right while retaining all features below the first turn. To tweak the Nudge component or any other part of the well, return to the Well Planner Mode, then click on the desired projection in the List Panel at the bottom of the screen.

No	Projection	Target	MD (Ft)	CL (Ft)	Inc Deg	Azm Deg	RKB TVD (Ft)	NS (Ft)	EW (Ft)	Easting (Ft)	Northing (Ft)	VS (Ft)	DLS */100 (Ft)	TFA Deg
1	Tie in	N/A	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	90.00
2	MD	N/A	4322.38	4322.38	0.00	0.00	4322.38	0.00	0.00	-26.47	-37.43	0.00	0.00	0.00
3	Quija	N/A	5092.37	769.99	42.78	44.84	5022.80	194.51	193.46	166.99	157.08	274.34	5.56	0.00
4	Slant	N/A	5862.31	769.94	85.55	44.85	5350.56	674.54	670.87	644.40	637.11	951.35	5.56	0.00
5	Slant	USB-446	7790.38	1928.07	85.55	44.85	5500.00	2037.43	2026.47	2000.00	2000.00	2873.62	0.00	0.00

When the Nudge row is clicked, its special control panel appears for editing. If the Tool Face, for example, is changed in this Nudge section, then the entire curve will be redirected yet maintain its build characteristics. You can edit any parameters directly in the List Panel which have a white background.


S-Well Defined Without Targets

The first three steps to creating an S-Well without targets is to:

1) Select “Don’t Use” at the top left of the Profiler, then

2) Check “Extension” to solve for extension.

3) Uncheck the “Lock” checkbox at the bottom in Well Properties in order to allow for the editing of the V. Section field. It may also be a good idea to click the Erase icon to clear all the fields.




From there, in the Solver, enter a KOP, Build Rate, Tangent, V.Section (Vertical Section) and Delta TVD. After the last two parameters are entered, the Profiler will solve for a Target TVD. The final step is to enter a desired Well Direction at the bottom.

Create the target points by checking “Create Target Plane” and “Create Way Point Target” at the bottom under the graph.

Then click “OK” and make sure to “Send to 3D Space” when prompted.

The curve will appear in the 3D space going through two targets and along a target plane. Just as with the targeted S-Well made from the Profiler, this S-Well contains a Nudge projection near the top that allows for powerful nudging options which preserve the S-Well’s characteristics. Any of the projection components of the well can be accessed and edited by clicking on the projection in the List Panel at the bottom of the screen.




Once the curve is nudged and adjusted, click “Apply to Prop.1” in the Well Planning Control Panel and it will make this curve a proposal curve.


Click any tab other than “Well Plan” to get back to the Field Mode and the S-Well will be displayed as a proposal curve along with the targets generated and listed.

b. Simple 2D Slant Profiler

Within the Well Planning Control Panel, selecting the “Simple 2D Slant” from the “Profile:” drop-down menu will invoke the dedicated Profiler for these well types. The parameter set for both slant wells and horizontal wells are identical since both consist of a single turn.



You will open up the “Simple 2D Slant / Horizontal Profiler:



FIRST TARGET: Since Both Slant and Horizontal projections are “targeted projections,” a first target must usually be set. If a first target has not been set yet, find the target to be set either in the Data Tree, 3D space, right-click on it and select “Set as First Target.”

Or set it from the 1st Target pulldown list in the Well Planning panel.




LOAD THE PROFILE: Select the profile from the “Profile” dropdown menu. This is best done in every case AFTER designating target(s).

HOW TO USE 1ST TARGET: Choose from the top left box in the Profiler how to build the profile around the target.



- **Don't Use-** This option allows the user to make the Profiler determine where a target should be after providing certain parameters. **When “Don't Use” is selected, the profiler will create a target where the projection ends and call it “PBHL” by default.**
- **As Landing-** This means set the target to the landing point which is another way of saying: “Solve for the minimum build rate that is required to achieve the desired inclination at the landing point. The KOP will be determined as a function of that.”
- **As PBHL-** Treating the target as a Proposed Bottom Hole Location is the default method of target utilization, with the target acting as the end point designation for the curve.


CURVE PROPERTIES SOLVER: As with the S-Well Properties Solver (found in the S-Well Profiler), the rule of thumb is that the fields in red cannot be changed, whereas the fields in white can be changed. These fields change depending on which solve mode is selected. Select for a solve mode by clicking on one of the three radio buttons on the right.



The Solver for Slant/Horizontal wells has 8 different parameters which define the well. The properties are:

- **KOP**- The depth at which the first turn in the S-Well begins, usually after the initial straightaway from the surface.
- **Build Rate**- The degree of turn per 100 ft along the first turn.
- **Start Inc**- This is the initial inclination, which is always zero for this type of plane
- **End Inc**- The landing inclination
- **Landing Disp**- Displacement in feet or meters to the landing point, illustrated by the **Dark Green** upper line in the diagram
- **Delta TVD**- The change in True vertical depth on the curve. The **Red Line** illustrates this distance.
- **Delta MD**- The change in measured depth from the beginning of the curve to the end of the curve. The **Blue Line** represents where this distance is calculated.
- **Dip Angle**- The dip angle is calculated as 90-Landing Inc. So a curve that has a landing angle of 88 degrees would have a 2 degree dip. The **Maroon Line** represents where this angle is calculated, relative to an imaginary horizontal line.
- **Above Dip**- The Above dip distance is represented by the **Black Line** on the left. This is the distance above the formation at the beginning of the kick off.


WELL PROPERTIES: Unlike the S-Well Profiler, the “Well Properties” fields are uneditable regardless of which solve mode is selected. These fields merely indicate the figures shown. These parameters indicate several crucial bits of information:



- **Landing TVD-** The Target TVD
- **Well Direction-** The azimuth direction in which the well is being planned.
- **Extension-** The extension is the amount of tangent Measured Depth *before* reaching the Landing TVD, aka. the Target.

CREATE TARGET PLANE: Check this box in the Profiler to turn on a target plane in the 3D space. Target Planes in the 3D space are a very useful visual tool. They can easily be created within the 3D space by selecting a tangent section on a curve that the right-clicking for the context menu and then selecting ‘Create Target Plane’. But, if you know you want to have a target plane then it is even easier to have one automatically created

CREATE WAY POINT TARGET: Common practice in directional drilling is to have the point at the end of the build section identified as a target. This is more commonly referred to as a waypoint. Selecting this option will have the program automatically create a waypoint target at the end of the first turn in the curve. The target will be named “Way Point” with its TVD by default.



SEND TO 3D SPACE: This button acts as an “APPLY” button, porting all of the Slant/Horizontal well changes made in the Profiler into the 3D space. This option will be a prompt when clicking “OK” just in case the user forgets.

COMES WITH A NUDGE INSTALLED: Just like the S-Well, when a Slant/Horizontal well is sent into the 3D space from the Well Planning Profiler, it is equipped with a Nudge projection at the first turn.

This feature acts as a sort of hinge, allowing the user to nudge the Nudge portion of the well and redirecting the entire curve elsewhere while retaining all features below the first turn. To tweak the Nudge component or any other part of the well, return to the

Well Planner Mode, then click on the desired projection in the List Panel at the bottom of the screen.


When the Nudge row is clicked, its special control panel appears for editing. If the Tool Face, for example, is changed in this Nudge section, then the entire curve will be redirected yet maintain its build characteristics.

c. Find KOP Slant


The “Find KOP Slant” is the first of the profiles to not have a dedicated profiler tool. It is styled like all the remaining profiles in that it gives you a series of projections with which you can tweak, add to or take projections out of. This profile will look for the optimal KOP given the parameters that you enter into your slant projection panel.

SET FIRST TARGET: Since the Slant projection is a targeted projection, a First Target must be set. Do so by finding the target in the 3D space, right-clicking and selecting “Set as First Target.”

Or set it from the 1st Target pulldown list in the Well Planning panel.



LOAD PROFILE: This profile does not have a dedicated profiler tool pop up when you select it. Remember to click “Load Profile” after selecting this and all profiles below this one.



CHANGE INCLINATION FROM THE LIST PANEL: If the resulting proposal curve is not exactly what is needed, any of the projections composing the curve can be edited. The fields in white can be edited directly in the List Panel. To change other parameters of a given projection, click on the name of the projection and its own control panel will appear.


Below is the projection series created by the “Find KOP S-Well,” with “Target1” set as the First Target. The inclination of the first slant can be changed to affect the KOP:

No	Projection	Target	MD (Ft)	CL (Ft)	Inc Deg	Azm Deg	RKB TVD (Ft)	NS (Ft)	EW (Ft)
1	Tie in	N/A	0.00	0.00	0.00	0.00	0.00	0.00	0.00
2	MD	N/A	2038.60	2038.60	0.00	0.00	2038.60	0.00	0.00
3	Slant	N/A	3038.53	999.93	30.00	45.00	2993.47	180.91	180.91
4	Slant	Target1	5355.42	2316.89	30.00	45.00	5000.00	1000.00	1000.00

Changes are updated instantaneously to the 2D and 3D space. To the right is a typical “Find KOP Slant” profile, with the parameters from the previous List Panel screenshot.

Here, the KOP is seen in the List Panel as 2038.6 feet. The build is at 30 degrees inclination and 45 degrees azimuth.

APPLY TO PROPOSAL: Remember that any list of projections that you create in the Well Planning Mode will not appear in the Field Mode and become a part of your Proposal Curve until you click “Apply to Prop.”




d. Find KOP Aligned


The “Find KOP Aligned” is a standard style Well Planning profile in that it gives you a series of projections with which you can tweak, add or take projections out of. This profile will look for the optimal KOP given the parameters that you enter into your aligned projection panel.

SET FIRST AND SECOND TARGET: Since the Aligned projection is a targeted projection, a First Target must be set. Additionally, it is the only projection which uses the Second Target. Set these targets by finding them in the 3D space, right-clicking and selecting “Set as First Target” and “Set as Second Target.”

Or set it from the 1st Target pulldown list in the Well Planning panel. You may also need to designate a 2nd target here if you are using the “Line up to hit 2nd Target feature (described just below).




LOAD PROFILE: This profile does not have a dedicated profiler tool pop up when you select it. Remember to click “Load Profile” after selecting this and all profiles below this one.



LINE UP TO HIT 2ND TARGET: With the Aligned projection, *if you want* to hit two targets you will need to open up the Aligned Projection control panel by clicking on the aligned projection in the Projects List.

Once the control panel is open, check the “Line up to hit 2nd Target” and “Extend to 2nd Target” boxes. This will ensure that the projection is calculated to pass through the First Target and end at the Second Target.



NOTE: With the Aligned projections, always remember to hit the “Calculate” button, either in the small control panel or the Well Planning Control Panel on the far right.


CHANGE INCLINATION FROM THE LIST PANEL: If the resulting proposal curve is not exactly what is needed, any of the projections composing the curve can be edited. Below is the projection series created by the “Find KOP Aligned,” with “Target1” set as the First Target and “Target2” set as Second Target:

No	Projection	Target	MD (Ft)	CL (Ft)	Inc Deg	Azm Deg	RKB TVD (Ft)	NS (Ft)	EW (Ft)
1	Tie in	N/A	0.00	0.00	0.00	0.00	0.00	0.00	0.00
2	MD	N/A	1731.84	1731.84	0.00	0.00	1731.84	0.00	0.00
3	Aligned	N/A	1774.52	42.68	2.56	45.00	1774.50	0.67	0.67
4	Aligned	N/A	3637.03	1862.52	2.56	45.00	3635.16	59.51	59.52
5	Aligned	Target1	5722.02	2084.98	85.96	45.00	5000.00	1000.00	1000.00
6	Aligned	Target2	7139.76	1417.74	85.96	45.00	5099.88	2000.01	2000.00

The fields in white in the List Panel can be edited directly. To change other parameters of a given projection, click on the name of the projection and its own control panel will appear. In the example above, since the “Find KOP” box is checked under our “Find KOP Aligned” profile, we can directly change the Inclination on the first aligned projection. This will cause the KOP to be recalculated.

MUST CLICK “CALCULATE”: For profiles containing aligned projections such as this one, changes are updated to the 2D and 3D space after clicking “Calculate.”

To the right is the vertical section view of a typical “Find KOP Aligned” profile, with the parameters from the List Panel above. Here, the KOP is seen in the List Panel as 1731.84 feet. The DLS values are at 6 and 4, according to the Aligned Projection control panel. The curve hits Target1 and extends in a straight tangent for 1417.74 feet to hit Target2.




APPLY TO PROPOSAL: Remember that any list of projections that you create in the Well Planning Mode will not appear in the Field Mode and become a part of your Proposal Curve until you click “Apply to Prop.”

e. Default Slant


The Default Slant profile is similar to the Find KOP Slant profile except that it is not solving for a KOP given a user-provided inclination. Instead, a KOP must be provided, as well as DLS and Hold Angle numbers for the slant projection portions.

SET FIRST TARGET: Since the Slant projection is a targeted projection, a First Target must be set. Do so by finding the target in the 3D space, right-clicking and selecting “Set as First Target.”

Or set it from the 1st Target pulldown list in the Well Planning panel.



LOAD PROFILE: This profile does not have a dedicated profiler tool pop up when you select it. Remember to click “Load Profile” after selecting this and all profiles below this one.



CHANGE KOP FROM THE LIST PANEL: If the resulting proposal curve is not exactly what is needed, any of the projections composing the curve can be edited. The fields in white can be edited directly in the List Panel. To change other parameters of a given projection, click on the name of the projection and its own control panel will appear.


Below is the projection series created by the “Default Slant,” with “Target1” set as the First Target. The KOP can be changed:

No	Projection	Target	MD (Ft)	CL (Ft)	Inc Deg	Azm Deg	RKB TVD (Ft)	NS (Ft)	EW (Ft)	Easting (Ft)	Northing (Ft)
1	Tie in	N/A	0.00	0.00	0.00	0.00	0.00	0.00	0.00	3455231.48	810940.54
2	MD	N/A	3000.00	3000.00	0.00	0.00	3000.00	0.00	0.00	3455231.48	810940.54
3	Slant	N/A	3540.26	540.26	27.01	79.30	3520.46	23.22	122.84	3455354.32	810963.76
4	Slant	Target1	4214.33	674.07	27.01	79.30	4121.00	80.07	423.67	3455655.15	811020.61

Changes are updated instantaneously to the 2D and 3D space. To the right is a typical “Default Slant” profile, with the parameters from the previous List Panel screenshot.

Here, the KOP was defined in the List Panel as 3000 feet. The build is at 27.01 degrees inclination and 79.30 degrees azimuth. The DLS for this curve is 5 degrees per hundred feet, and that could be reduced by decreasing the user-defined KOP.

APPLY TO PROPOSAL: Remember that any list of projections that you create in the Well Planning Mode will not appear in the Field Mode and become a part of your Proposal Curve until you click “Apply to Prop.”




f. Default Aligned


The “Default Aligned” is a standard style Well Planning profile in that it gives you a series of projections with which you can tweak, add to or take projections out of. This profile will allow you to change your KOP as well as your inclination and azimuth upon reaching the first target.

SET FIRST AND SECOND TARGET: Since the Aligned projection is a targeted projection, a First Target must be set. Additionally, it is the only projection which uses the Second Target. Set these targets by finding them in the 3D space, right-clicking and selecting “Set as First Target” and “Set as Second Target.”

Or set it from the 1st Target pulldown list in the Well Planning panel. You may also need to designate a 2nd target here if you are using the “Line up to hit 2nd Target feature (described just below).



LOAD PROFILE: This profile does not have a dedicated profiler tool pop up when you select it. Remember to click “Load Profile” after selecting this and all profiles below this one.




CHANGE KOP AND INC/AZM AT FIRST TARGET: If the resulting proposal curve is not exactly what is needed, any of the projections composing the curve can be edited. Below is the projection series created by the “Default Aligned,” with “Target1” set as the First Target:

No	Projection	Target	MD (Ft)	CL (Ft)	Inc Deg	Azm Deg	RKB TVD (Ft)	NS (Ft)	EW (Ft)	Easting (Ft)	Northing (Ft)
1	Tie in	N/A	0.00	0.00	0.00	0.00	0.00	0.00	0.00	3455231.48	810940.54
2	MD	N/A	781.64	781.64	0.00	0.00	781.64	0.00	0.00	3455231.48	810940.54
3	Aligned	N/A	1381.57	599.93	30.00	45.00	1354.54	108.53	108.53	3455340.01	811049.07
4	Aligned	N/A	6220.33	4838.76	30.00	45.00	5545.17	1819.11	1819.11	3457050.59	812759.65
5	Aligned	TARGET1	7220.21	999.88	0.00	0.00	6500.00	2000.00	2000.00	3457231.48	812940.54

The fields in white, here the KOP and Inc/Azm at First Target, can be edited directly. To change other parameters of a given projection, click on the name of the projection and its own control panel will appear.

MUST CLICK “CALCULATE”: For profiles containing aligned projections such as this one, changes are updated to the 2D and 3D space after clicking “Calculate.”

To the right is the vertical section view of a “Default Aligned” profile, with the parameters from the List Panel above. Here, the KOP was set in the List Panel at 781.64 feet. The curve hits Target1 at 0 degrees inclination and azimuth, or in other words straight down from the top.




EXTEND TO NEXT TARGET: With the Aligned projection, *if you want* to hit two targets you will need to open up the Aligned Projection control panel by clicking on the aligned projection in the List Panel below.

Once the control panel is open, check the “Use Vector to Second Target” and “Extend to Next Target” boxes. This will ensure that the projection is calculated to pass through the First Target and end at the Second Target.

NOTE: With the Aligned projections, always remember to hit the “Calculate” button, either in the small control panel or the Well Planning Control Panel on the far right.

LINE UP TO HIT 2ND TARGET: With the Aligned projection, *if you want* to hit two targets you will need to open up the Aligned Projection control panel by clicking on the aligned projection in the Projects List.


Once the control panel is open, check the “Line up to hit 2nd Target” and “Extend to 2nd Target” boxes. This will ensure that the projection is calculated to pass through the First Target and end at the Second Target.



NOTE: With the Aligned projections, always remember to hit the “Calculate” button, either in the small control panel or the Well Planning Control Panel on the far right.

When extending to the next target, the program will recalculate the aligned projection to automatically hit Second Target from the First Target. In the example below, once the projection was told to use vector to second target, it calculated that it needed to hit First Target at 90 degrees inclination and 45 degrees azimuth:

No	Projection	Target	MD (Ft)	CL (Ft)	Inc Deg	Azm Deg	DLS °/100 (Ft)
1	Tie in	N/A	0.00	0.00	0.00	0.00	0.00
2	MD	N/A	781.64	781.64	0.00	0.00	0.00
3	Aligned	N/A	1046.88	265.24	13.26	45.00	5.00
4	Aligned	N/A	5139.79	4092.91	13.26	45.00	0.00
5	Aligned	TARGET1	7697.72	2557.93	90.00	45.00	3.00
6	Aligned	TARGET2	10526.15	2828.43	90.00	45.00	0.00




APPLY TO PROPOSAL: Remember that any list of projections that you create in the Well Planning Mode will not appear in the Field Mode and become a part of your Proposal Curve until you click “Apply to Prop.”


g. Default Horizontal

The “Default Horizontal” profile contains the horizontal projection, which is a targeted projection but will not use First or Second Target. Instead, just like when making a horizontal projection in the Field Mode, you must define a target plane from within the control panel.

LOAD PROFILE: This profile does not have a dedicated profiler tool pop up when you select it. Remember to click “Load Profile” after selecting this and all profiles below this one.




DEFINE YOUR TARGET PLANE: Just as in the Field Mode, the Horizontal Projection **can only be calculated upon defining the target plane** which it is supposed to hit. So when the “Default Horizontal” profile is loaded, you must click on the “Horizontal” projection in the List Panel below and enter some parameters into the control panel that pops up.



Here, we have defined a plane that sits at 5000 feet RKBTV D, with no dip in any direction, and we want the curve to strike the plane at a 90 degree angle (flat), at a direction of 45 degrees, with no extension. The program calculates that this will require a low 1.91 DLS.


MAKE TARGET PLANE: By clicking the “Make Target Plane,” this projection will automatically generate a target plane in the 3D space that will be associated with your current structure. Generating the target plane may help to visualize how and where the curve strikes the plane.



MAKE CHANGES IN THE LIST PANEL: As is the case with all data in the Well Planning Mode's List Panel, white fields are editable. Taking a look at the List Panel below. Here, we can change the KOP, strike azimuth and total depth of the plane itself:

No	Projection	Target	MD (Ft)	CL (Ft)	Inc Deg	Azm Deg	RKB TVD (Ft)
1	Tie in	N/A	0.00	0.00	0.00	0.00	0.00
2	MD	N/A	2000.00	2000.00	0.00	0.00	2000.00
3	Horizontal	N/A	6712.39	4712.39	90.00	45.00	5000.00

As can be seen in the vertical section view to the right, the Horizontal projection profile can be used to make a smooth "landing" with a low DLS.




APPLY TO PROPOSAL: Remember that any list of projections that you create in the Well Planning Mode will not appear in the Field Mode and become a part of your Proposal Curve until you click "Apply to Prop."

h. Tie-Ins

Adding tie-ins in the Well Planning Mode is conceptually the same as doing it in the Field Mode. The advantage here is that it can be nudged and modified by any parameter at any point, which is the general advantage of working in the Well Planning Mode.

TIE TYPE: To create a tie-in from the Well Planning Control Panel, DON'T select a profile. Instead, first select the type of tie-in to be created from the "Tie Type" drop-down menu. The choices are Well Head or WellPath. In the following example, the tie-in will be off of the well path.

TIE CURVE: When "WellPath" is selected as the tie-in type, the "Tie Curve" drop-down menu is activated and a curve from which to tie in can be selected. Keep in mind that you cannot launch a tie-in from the current curve that you are on: it must be from either the survey curve or another proposal.




Once a tie-in base curve is selected, by default, the tie-in will start at the END of the selected tie-in base curve. This entry appears in the List Panel as "Tie in." Change where the tie-in starts by changing the MD in the List Panel.

No	Projection	Target	MD (Ft)	CL (Ft)	Inc Deg	Azm Deg	TVD (Ft)	NS (Ft)
1	Tie in	N/A	2050	0.00	87.00	78.00	2683.18	726.69

ADD PROJECTION: The next step is to select a projection type to use as the tie-in curve from the "Add Projection" drop-down menu. When any projection is selected, its special control panel appears inside of the 3D window, where it always normally appears.

In this example, a horizontal projection is used as the tie-in off of horizontal proposal. When a horizontal projection is made, a target plane must be defined and this is done in the Horizontal Projection panel. It is defined by its RKBTV D, Max Dip and Max Dip Direction. In this case, the target plane is contacted 2500 feet




below the surface location, its maximum dip angle is 3 degrees and its direction is 78 degrees.

For the tie in, the strike inclination is defined as 93 degrees, and the strike azimuth is 258 degrees, which is exactly 180 degrees opposite the proposal’s azimuth. The tie-in is also given an extension of 3000 feet and the DLS is automatically calculated at 14.61 in order to accommodate these parameters.

ADD: The next step is to click the “Add” button. This will create the curve and it will appear both in the 3D space as a translucent projection as well as the next projection entry in the Well Planning List Panel (just below “Tie in”). (See 9.1.8 video for reference)

Well Planning Curve Data #0 MD = 0.00 Inc = 0.00 Azm = 0.00 TVD = 0.00 EW = 0.00 NS = 0.00 DLS = 0.00 TFO = 0.00 VSP = 86.81											
No	Projection	Target	MD (Ft)	CL (Ft)	Inc Deg	Azm Deg	TVD (Ft)	NS (Ft)	EW (Ft)	East (F)	
1	Tie in	N/A	2050.00	0.00	5.44	78.00	2049.92	0.49	2.32	34552	
2	Horizontal	N/A	2723.57	673.57	93.00	258.00	2478.60	-84.92	-399.50	3454	
3	Horizontal	N/A	5723.57	3000.00	93.00	258.00	2321.59	-707.80	-3329.92	3451	

The new tie-in is also reflected in the 2D and 3D space as a translucent projection.




By changing the “MD” value of the Tie-in in the List Panel, the actual tie-in point can be manipulated. Notice that when the tie-in’s MD (tie-in point) is changed from 2050 to 2100, it starts lower off of the base curve and ultimately adopts a more severe dogleg severity to attain its assigned strike inclination.



To get the exact desired dogleg severity, the user can keep changing the MD until the right DLS value is generated. Such “what-if” games can be played in the Well Planning version for all sorts of parameters in order to create an optimal curve.


When the tie-in curve has been articulated to user spec, click “Apply to Prop.” and it becomes part of a multilateral proposal curve. Click any tab other than “Well Plan” to get back to the Field Mode and see the proposal curve.



2. BUILD A CUSTOM WELL PLANNING TEMPLATE

Once the Well Planning Control Panel has become familiar, creating customized profiles is straightforward. The principle tools are the “Add” button and the List Panel. Custom profiles can also be based on existing default profiles. Any sequence of projections that is currently displayed in the List Panel can be saved as a new user-created profile, making this aspect of the Well Planning Mode a potent time saving device.

ADD FIRST PROJECTION: When creating a profile from scratch, first click the “Clear” button in the Well Planning panel. Then add a projection at the top of the curve by selecting the type in the “Add Projection” drop-down menu. The special control panel for any of the projections appear where they normally do, just inside the 3D window. Edit the main parameters in this panel.



Then click the “Add” button. The projection as defined will appear in the List Panel below as well as the 3D space above. All parameters can be further edited in the List Panel by clicking on the projection row, or in the special control panel.

ADD ANOTHER PROJECTION: The next step in building a profile is to stack on a second projection. A common and useful second projection for ample customization room down the road is a Nudge projection since it acts as a flexible control point for any template. Select “Nudge” from the “Add Projection” drop-down menu and click “Add.” This will place a Nudge projection just after the first one.

No	Projection	Target	MD (Ft)	CL (Ft)	Inc Deg	Azm Deg	TVD (Ft)	NS (Ft)	EW (Ft)
1	Tie in	N/A	0.00	0.00	0.00	0.00	0.00	0.00	0.00
2	MD	N/A	2000.00	2000.00	0.00	0.00	2000.00	0.00	0.00
3	Quija	N/A	2300.00	300.00	9.00	90.00	2298.77	0.00	23.51

ADD TARGETED PROJECTIONS: Add targeted projections in the same manner as targetless, but keep in mind that a target will need to be set as First Target when adding the former. Set a target as First Target by right-clicking on it in the 3D window and selecting “Set as the First Target.” When loading the profile for later projects, the targeted sections of the profile will adjust to whichever current First Target is set.

MAKE FINAL CHANGES: Any tweaks to the projections can be made in the List Panel before saving by clicking on the parameter in question.

No	Projection	Target	MD (Ft)	CL (Ft)	Inc Deg	Azm Deg	TVD (Ft)	NS (Ft)	EW (Ft)	Easting (Ft)
1	Tie in	N/A	0.00	0.00	0.00	0.00	0.00	0.00	0.00	606983.89
2	MD	N/A	2000.00	2000.00	0.00	0.00	2000.00	0.00	0.00	3455231.48
3	Quija	N/A	2300.00	300.00	9.00	90.00	2298.77	0.00	23.51	3455254.99
4	MD	N/A	2600.00	300	9.00	90.00	2595.07	0.00	70.44	3455301.92
5	Slant	N/A	3340.42	740.42	27.71	44.95	3297.29	123.39	252.29	3455483.77
6	Slant	1st Target	9217.31	5876.43	27.71	44.95	8500.00	2057.46	2183.32	3457414.80
7	MD	N/A	9717.31	500.00	27.71	44.95	8942.66	2222.00	2347.58	3457579.06
8	Slant	N/A	10303.26	585.95	40.04	67.87	9430.15	2390.75	2620.57	3457852.05
9	Slant	2nd Target	11047.61	744.35	40.04	67.87	10000.00	2571.15	3064.18	3458295.66

Changes are reflected instantly in the 3D window above the List Panel.

SAVE AS NEW PROFILE: Once a list of projections has been compiled, they may all be saved as a template for future use.

Name the new profile when prompted, and it will be available in the “Profile Name” drop-down menu along with all the default profiles.



APPLY TO PROPOSAL: Anything created and displayed in the Well Planning Mode must be actively pushed over into the Work Space in order for it to become part of a proposal curve. To do that, just click “Apply to Proposal.” Click any tab other than “Well Plan” to get back to the Field Mode and see the proposal curve.

CHANGING THE TEMPLATE: Anytime a template needs to be altered, first get back to the Well Planning panel and load the profile. Then make the desired changes in the List Panel and individual control panels for any of the curves. Finally save as new profile again, naming it the same or something different.

VIII. TORQUE AND DRAG

The Torque and Drag Program

The Softdrill NL Torque and Drag module is a program offered with an additional charge for those ordering the Field Version of HawkEye™, or simply included in the Well Planning Version.

Performance Drilling Technology has enlisted Softdrill NL to embed its torque and drag program within HawkEye™ as an optional component module. T&D is an important component of many drilling operations and the ability to create useful T&D analysis quickly and accurately is important.

To this end, HawkEye™ passes survey information to the torque and drag program which provides the interface for setting up the calculation parameters for torque and drag, and also provides the reports and graphs. The following pages explain how to operate the Torque and Drag program.

1. OVERVIEW

Softdrill NL Torque & Drag can be used for a variety of engineering applications:

- Optimizing well path design and prediction of operational scenarios
- Drillstring design and prediction of expected tension and torque values exerted on drillstring elements
- Analysis of normal forces (predicting casing wear)
- Analyzing drilling problems (string “hang up”)
- Prediction of hook loads while tripping in or out of the hole and early detection of cuttings build up by comparing actual hook loads (“diverge/converge” method).


Each of these applications of the software will be introduced and described in this document.

NOTE: This manual has been written for the stand-alone version of Torque & Drag, which allows multiple calculation models to be opened simultaneously (multiple document interface). The Torque & Drag version embedded in Performance Drilling

Technology's HawkEye™ consists of a single document interface, but functionality of the software is similar to the stand-alone version. Please refer to section "Hawkeye™ Embedded Version" later in this chapter for further details.

a. Units of measurement


Common to all **Softdrill NL** applications, the Torque & Drag program has full flexibility with regards to the units of measurement used for input and output. All numeric data is stored in a consistent set of units (imperial) when it is saved in a file or stored in a database. This is schematically depicted in the figure below.



Conversion of units of measurement

The conversion mechanism is fully transparent to the user and allows the program(s) to function fully independently of the selected units. The advantage of this is two-fold: every user can work in his preferred units while working with the program and change to the required units just prior to printing the report(s) to be presented.

To access of variety of functions related to the selected units of measurements, click the  on the program tool bar or select [File] > [Conversions...] from the main menu. This opens the dialog window as displayed below in the next figure:



Conversion settings editor

This dialog window presents the user with several options related to units of measurement:

- The conversion families (or: groups of units) are sorted in the most logical manner in the context of an engineering application. However, you may choose to sort this list by Conversion Family by clicking on the column header (continued clicking will toggle between ascending and descending sort order).
- For each conversion family, you may select your preferred unit from the drop-down box in the Selected Unit column.
- The button [Set default file location] allows the user to define a folder (directory) where all conversion files will be saved. Typically this is My Documents\Softdrill NL data for the current user, but it may be changed to any folder. This folder's path is saved to the registry and becomes the default

location when storing your settings. (This can still be overridden because the user is asked for a storage location prior to opening or saving a settings file). Note that it is probably not a good idea to set a network location as the default. Specifically with a laptop computer, you may not be connected to the network and problems will occur when attempting to retrieve you default settings.

- If you check the checkbox labeled ‘Make current settings my default settings’, the currently selected settings will become the default (on startup) of all **Softdrill NL** applications installed on your computer.
- Click “OK” to keep your selected settings or “Cancel” to undo all changes and keep things as they were.

b. The Torque & Drag Toolbar

The following shortcut buttons are available on the toolbar in the main window:

 [File] > [New]

This option opens a new calculation model. Use this to start a new model from scratch.

 [File] > [Open...]

Open existing (saved) calculation model. Alternatively you can use this to open an existing model, input the required changes and save it under a new name using [File] – [Save As...] from the main menu. This is particularly useful in situations where several cases for similar situations must be calculated (e.g. only minor changes to BHA, various bit depths, different mud weights, etc.). Please note that specifically for this purpose the Case No. and Description input fields were added to allow easy distinction between several different cases.

 [File] > [Save]

Save changes to currently opened calculation model.

 [File] > [Calculate]

Calculate currently opened calculation model. This takes you to the resulting graph screen on completion of the calculation. The same function is executed when the [F9] key is pressed.



[File] > [Print...]

Print Torque & Drag report complete with selected graphs. This function prints to a preview window first, allowing the user to review the report prior to printing the actual hardcopy.

When you print the report from the preview window (click on printer icon), the print dialog opens where you can select and adjust the printer you want to use to print the report. Optionally you can print to a PDF file directly by checking the 'Print to file' checkbox and selecting 'PDF' from the combo-box.



[File] > [Conversions...]

Edit conversion settings (units of measurement) as described above.

2. INPUT SCREENS

a. General data

The main screen of the currently selected model window gives you access to the following general input data:

Well name	Customer	Well/job no.	BHA no.	Case no.
Demo well #1	Demo company	0000.000	1	1
Case data Result data Result graph				
Description	Sample case for a 12 1/4" BHA			
Bit depth	10000.0 ft	Mud weight	12.0 lbs/gal	M.O.P.
				100000 lbs
Step length	100.0 ft	Safety factor	1.25	Helical buckling
		Stiff string	<input type="checkbox"/>	Chen & Cheatham
				Calculation mode
				Scenario

Input of general data for calculation model

Most data input in this section is self-explanatory but the following may require some additional explanation:

- **Case no**- Allows distinction between models for the same BHA on the same well (use in conjunction with 'Description' field).

- **Step length**- The torque and drag is calculated cumulatively for various depths along the drillstring (from the bit upwards). These depths are calculated using the specified step length. Typically this value is set to 100 feet (or 30 meters). Different step lengths will yield different results but will also impact calculation time.
- **Safety factor**- This factor is used to adjust the tension and torsional yield curves for the operational scenario graph. The absolute yield values are divided by the safety factor to calculate the yield curve values on the graph. For example, a safety factor of 1.25 results in a graph value being plotted at $1 / 1.25 = 0.80 = 80\%$ of the absolute value
- **M.O.P.**- The margin of overpull applied in the calculation of the model.
- **Stiff string**- By default the model is calculated as 'Soft string' whereby additional forces, resulting from bending the drillstring elements, are not taken into account. Selecting this option will alter the calculation model where these additional forces will be taken into account. See the 'Calculation theory' section further in this document for further explanation.
- **Helical buckling**- Allows the user to select the applied method for calculation of the helical buckling force. The available options are 'Chen & Cheatham' and 'Wu & Juvkam-Wold', where 'Chen & Cheatham' is considered the most reliable and the default value.
- **Calculation mode**- Available options are: *Scenario* (also known as 'single depth analysis'), *Trip Log* (surface hook load vs. bit depth) and *Friction Factor* (back-calculates friction factor from known surface loads; used for post run analysis and in-field optimization of models).

b. Drilling parameters

Operational Mode	WOB (klbs)	RPM	Pipe speed (ft/hr)	BHA Drag (lbs)	BHA Torque (ft.lbs)	Bit Torque (ft.lbs)
Pick up without rotation			100.0	0		
Pick up with rotation		50	100.0	0	0	
Slack off without rotation			100.0	0		
Slack off with rotation		50	100.0	0	0	
Rotating off bottom		50			0	
Rotary drilling	20	50	30.0	0	0	2000
Oriented drilling	20		30.0	0		

Input of (drilling) parameters

This grid allows input of various (drilling) parameters for each operational mode. The operational modes are defined as shown in the left-most column. Cells for non-applicable values are grayed out and disabled.

Bit torque and BHA torque define the starting values for calculating torque values along the drillstring. These values are increased as a result of an increasing weight (and bending force in the case of stiff string models) along the drillstring. BHA Drag serves as a start value for calculation of tension along the drillstring.

Other data is considered to be self-explanatory.

c. Hole sections

MD Top (ft)	MD Bottom (ft)	Section Type	Hole Size (inch)	Friction Factor
0.0	3950.0	Casing	12.410	0.25
3950.0	9000.0	Liner	8.840	0.35
9000.0	11000.0	Open hole	8.500	0.35

Hole sections

When selected, the hole size column will display an ellipsis button (⋮). If the Section Type column is defined as *Casing* or *Liner*, the clicking the button displays a casing catalog from which the user can choose the applicable specifications.

The friction factor is a crucial parameter in the torque & drag calculation that allows modeling of a variety of surface-to-surface interactions resulting in drag and torsional

friction. The actual value of the friction factor used in a particular situation is a combination of several factors, including:

- Material and condition of cased hole sections and formation type in open hole sections
- Drilling fluid type and composition
- Tool joint material and condition
- Additional borehole tortuosity not correctly reflected by the survey data (i.e. 'micro doglegs').

At a specific point in time, the borehole tortuosity, drillstring composition, drillstring characteristics and mud type will be constant, but several sections of cased and open hole may exist. In most cases it will therefore be necessary to specify multiple friction factors.

d. Drillstring

Order	Type	Description	OD (inch)	ID (inch)	Length (ft)	Nom. Wt. (lbs/ft)	Act. Wt. (lbs/ft)	Tension Limit (lbs)	Torsion Limit (ft.lbs)	Make-up (ft.lbs)
1	Drill collar	5 3/4 x 2 13/16 in. - 101.0 lbs/ft ...	6.750	2.813	29.4	101.0	101.0	0	0	0
2	Hevi-wate	5" HWDP	5.000	3.000	213.6	49.3	49.3	691185	56495	29400
3	Drill pipe	5" DP - S	5.000	4.276	9757.0	19.5	22.6	560764	74100	28381

Drillstring

Type. Specify element type. Currently three values are valid: *Drill Collar*, *HWDP* and *Drill Pipe*⁹.

Description. Self-explanatory, but selecting this column (As shown in figure 6 above) will reveal a button that – when clicked - allows the user to select the element from a catalog¹⁰.

Actual weight is nominal pipe weight corrected for tool joints and used in actual calculation.

Tension limit, torsion limit and make-up torque are used for calculating the various yield curves in the result graphs (taking safety factor and margin of overpull into consideration).

⁹ Future editions of Softdrill NL Torque & Drag are planned to include additional element types such as *Casing*, *Tubing*, *Coiled tubing*, etc. Please check the website at www.softdrill.nl for further details.

¹⁰ Please note that updated catalogue files may be published on the website from time to time.

e. Survey data


MD (ft)	Δ	Inc. (deg)	Dir. (deg Az)	Build Rate (°/100ft)	Walk Rate (°/100ft)	DLS (°/100ft)	Radius (ft)
0.0		0.0	0.0	0.0	0.0	0.0	0.0
4000.0		0.0	0.0	0.0	0.0	0.0	0.0
6000.0		35.0	12.0	1.8	0.6	1.8	3274.1
8000.0		35.0	12.0	0.0	0.0	0.0	0.0
10000.0		90.0	30.0	2.8	0.9	2.9	2012.5
11000.0		90.0	30.0	0.0	0.0	0.0	0.0

Survey data

Survey (or wellplan) data can be input manually or imported from a text file. For wellplans only critical points (KOP, end of build, start of drop, etc.) have to be entered since intermediate points will be interpolated as required.

If the first section of a wellplan is vertical down to the kick off point (KOP), the resultant torque and drag values will be zero due to the absence of any inclination (theoretical absence of wall contact). To model a real-time situation it is recommended to adjust the inclination in the KOP to 1.00° (for example). Optionally, intermediate stations with low inclination and random direction can be entered to simulate borehole tortuosity in this section.

Select [Utility] – [Import surveys...] to display the dialog box below and import survey or wellplan data from a variety of text file types:



Import survey dialog box

Click the button in the ‘Selected file’ to select a *.txt or *.csv (Excel comma separated) text file. The ‘Value separator’ radio buttons specify which token to use a field separator when reading data.

Under ‘Import settings’ you can specify how many lines should be ignored before reading data (skip comment lines), what measurement units were used for measured depth values (feet or meters) and which columns contain measured depth, inclination and direction data. Specific attention should be given to the definition of the units used for the depth column to ensure correct conversion upon import of the data.

3. EMBEDDED VERSION

Softdrill NL Torque & Drag is also available as an embedded module in Hawkeye™. The single document interface may differ slightly from the multiple document interface of the stand-alone version at first sight, but the principle function of the application remains the same.

The primary differences lie in the file absence of the main menu and the standard toolbar. For the embedded version an alternative toolbar with primary functionality is made available to the user. This allows changing of setting and conversion units as well as saving and opening external data files for the purpose of exchanging models with other users.